





# Parts & Maintenance Manual Wartungsanleitung Und Stückliste

# HR-9016 Turbo<sup>™</sup> Rotary Mower

70528 - Kubota V3300-DI-E2B, 4WD

70529 - Kubota V3300-DI-E2B, 4WD with ROPS

70530 - Kubota V3300-DI-E2B, 4WD EC



WARNHINWEIS: Wenn diese Maschine nicht ordnungsgemäß verwendet wird, können ernsthafte Verletzungen verursacht werden. Personen, die diese Maschine verwenden und warten, müssen in ihrer richtigen Verwendung ausgebildet sein, auf die Gefahren aufmerksam gemacht worden sein und die Anleitung ganz gelesen haben, bevor sie versuchen, die Maschine aufzustellen, zu bedienen, einzustellen oder zu warten.



WARNING: If incorrectly used this machine can cause severe injury. Those who use and maintain this machine should be trained in its proper use, warned of its dangers and should read the entire manual before attempting to set up, operate, adjust or service the machine.







### To Order Parts

- Write your full name and complete address on the order
- 2. Explain where and how to make shipment.
- Give product number, name and serial number that is stamped on the name plate or serial plate of your product.
- Order by the quantity desired, the part number, paint code, and description of the part as given in the parts list.
- Send or bring the order to an authorized Jacobsen Dealer
- Inspect all shipments on receipt. If any parts are damaged or missing, file a claim with the carrier before accepting.
- 7. Do not return material without a letter of explanation, listing the parts being returned. Transportation charges must be prepaid.

Use of other than authorized parts will void the warranty.

# Table of Contents

1	Safety	4	Maintenance	
1.1	Operating Safety4	4.1	General	16
1.2	Important Safety Notes5	4.2	Inspecting Blades	16
		4.3	Sharpening Blades	17
2	Specifications	4.4	Engine	18
2.1	Product Identification6	4.5	Engine Oil	18
2.2	Engine6	4.6	Muffler and Exhaust	18
2.3	Tractor6	4.7	Air filter	19
2.4	Weights and Dimensions7	4.8	Fuel	19
2.5	Cutting Units7	4.9	Fuel System	20
2.6	Accessories & SUpport Literature 7	4.10	Battery	20
		4.11	Jump Starting	20
3	Adjustments	4.12	Charging Battery	21
3.1	General 8	4.13	Hydraulic Hoses	21
3.2	Leveling Decks8	4.14	Hydraulic Oil	22
3.3	Servicing Front Deck9	4.15	Hydraulic Filters	22
3.4	Winglet Adjustment 9	4.16	Radiator & Oil Cooler	23
3.5	Cutting Height 10	4.17	Care and Cleaning	24
3.6	Parking Brake11	4.18	Electrical System	24
3.7	Neutral Adjustment 11	4.19	Tires	26
3.8	Neutral Sensing Switch 12	4.20	Wheel Mounting Procedure	26
3.9	Forward Sensing Switch 12	4.21	Rollover Protection Structure	
3.10	Lift Limit Switches 13		(ROPS)	27
3.11	Traction Pedal14	4.22	Storage	27
3.12	Steering Toe-In 14	4.23	Maintenance Chart	28
3.13	Steering Stop Bolts 14	4.24	Lubrication Chart	29
3.14	Torque Specification 15			
		5	Troubleshooting	
		5.1	General	30
		6	Parts List	
		6.1	Table of Contents	3

# This manual is designed for the Maintenance and Adjustment of this equipment.

Use the maintenance and adjustment instructions included in this manual and the operating instructions included in the **Safety and Operation Manual** to service the machine.

The **Safety and Operation Manual** must be kept in the pouch on the back of the seat at all times for reference by the operator.

Copyright 2004 Textron Inc.

"All rights reserved, including the right to reproduce this material or portions thereof in any form."

All information in this publication is based on information available at time of approval for printing. Jacobsen reserves the right to make changes at any time without notice and without incurring any obligation.

Litho In U.S.A. 12-2004

# Suggested Stocking Guide

To Keep your Equipment fully operational and productive, maintain a stock of the more commonly used maintenance items. We have included part numbers for additional support materials and training aids. A more complete listing of accessories and attachments can be found in the Specifications Section

# Service Parts

Qty.	Part No.	Description	Qty.	Part No.	Description
	4137894	Engine Oil Filter			
	5003370	Engine Air Filter			
	557619	Engine Fuel Filter			
	5003691	Hydraulic Charge Filter			
	5002693	Hydraulic Return Filter			

# Service Support Material

Qty.	Part No.	Description
	4136606	Safety and Operation Manual
	4136607	Parts and Maintenance Manual
	4136876	Engine Parts Catalog

Qty.	Description
	Service Manual

# How To Use This Manual

#### **Abbreviations**

N/S - Not serviced seperately, can only be obtained by ordering main component or kit.

**AR** -Variable quantity or measurement is required to obtain correct adjustment.

**Symbols** such as ▲, next to the item number, indicate that a note exists which contain additional information important in ordering that part.

#### Indented Items

Bulleted items indicate component parts that are included as part of an assembly or another component. These parts can be ordered separetely or as part of the main component.

Item	Part No.	Qty	Description	Serial Numbers/Notes
<b>1</b>	123456	1	Mount, Valve	Indicates a piece part with note
2	789012	1	Valve, Lift	Includes Items 3 and 4
3	345678	1	Handle	Serviced part included with Item 2
4	N/S	1	Seal Kit	Non serviced part included with Item 2
5	901234	1	Screw, 1/4-20 x 2" Hex Head	Indicates Piece Part

#### 1.1 OPERATING SAFETY

# **A** WARNING

#### **EQUIPMENT OPERATED IMPROPERLY OR BY UNTRAINED PERSONNEL CAN BE DANGEROUS.**

Familiarize yourself with the location and proper use of all controls. Inexperienced operator's should receive instruction from someone familiar with the equipment before being allowed to operate the machine.

- Safety is dependent upon the awareness, concern and prudence of those who operate or service the equipment. Never allow minors to operate any equipment.
- 2. It is your responsibility to read this manual and all publications associated with this equipment (Safety and Operation manual, engine manual, accessories and attachments). If the operator can not read English it is the owner's responsibility to explain the material contained in this manual to them.
- Learn the proper use of the machine, the location and purpose of all the controls and gauges before you operate the equipment. Working with unfamiliar equipment can lead to accidents.
- Never allow anyone to operate or service the machine or its attachments without proper training and instructions; or while under the influence of alcohol or drugs.
- Wear all the necessary protective clothing and personal safety devices to protect your head, eyes, ears hands and feet. Operate the machine only in daylight or in good artificial light.
- Evaluate the terrain to determine what accessories and attachments are needed to properly and safely perform the job. Only use accessories and attachments approved by Jacobsen.
- Stay alert for holes in the terrain and other hidden hazards.
- 8. Inspect the area where the equipment will be used. Pick up all the debris you can find before operating. Beware of overhead obstructions (low tree limbs, electrical wires, etc.) and also underground obstacles (sprinklers, pipes, tree roots, etc.) Enter a new area cautiously. Stay alert for hidden hazards.
- Never direct discharge of material toward bystanders, nor allow anyone near the machine while in operation. The owner/operator can prevent and is responsible for injuries inflicted to themselves, to bystanders and damage to property.

- Do not carry passengers. Keep bystanders and pets a safe distance away.
- Never operate equipment that is not in perfect working order or is without decals, guards, shields, discharge deflectors or other protective devices securely fastened in place.
- 12. Never disconnect or bypass any switch.
- Do not change the engine governor setting or overspeed the engine
- 14. Carbon monoxide in the exhaust fumes can be fatal when inhaled. Never operate the engine without proper ventilation or in an enclosed area.
- 15. Fuel is highly flammable, handle with care.
- 16. Keep the engine clean. Allow the engine to cool before storing and always remove the ignition key.
- 17. Disengage all drives and engage parking brake before starting the engine (motor). Start the engine only when sitting in operator's seat, never while standing beside the unit.
- 18. Equipment must comply with the latest federal, state, and local requirements when driven or transported on public roads. Watch out for traffic when crossing or operating on or near roads.
- 19. Local regulations may restrict the age of the operator.
- Never use your hands to search for oil leaks. Hydraulic fluid under pressure can penetrate the skin and cause serious injury.
- 21. Operate the machine up and down the face of the slopes (vertically), not across the face (horizontally).
- 22. To prevent tipping or loss of control, do not start or stop suddenly on slopes. Reduce speed when making sharp turns. Use caution when changing directions.
- 23. Always use the seat belt when operating tractors equipped with a ROPS.
  - Never use a seat belt when operating tractors without a ROPS.
- 24. Keep legs, arms and body inside the seating compartment while the vehicle is in motion.

This machine is to be operated and maintained as specified in this manual and is intended for the professional maintenance of specialized turf grasses. It is not intended for use on rough terrain or long grasses.

#### 1.2 IMPORTANT SAFETY NOTES



This safety alert symbol is used to alert you to potential hazards.

DANGER - Indicates an imminently hazardous situation which, if not avoided, WILL result in death or serious injury.

**WARNING** - Indicates a potentially hazardous situation which, if not avoided, **COULD** result in death or serious injury.

**CAUTION** - Indicates a potentially hazardous situation which, if not avoided, **MAY** result in minor or moderate injury and property damage. It may also be used to alert against unsafe practices.

For pictoral clarity, some illustrations in this manual may show shields, guards or plates open or removed. Under no circumstances should this equipment be operated without these devices securely fastened in place



# WARNING

The operator back-up system on this tractor prevents the tractor from starting unless the brake pedal is engaged, mower switch is off and traction pedal is in neutral. The system will stop the engine if the operator leaves the seat without engaging the parking brake or setting the mower switch off.

NEVER operate tractor unless the operator back-up system is working.



# WARNING

- 1. Before leaving the operator's position for any reason:
  - a. Return traction pedal to neutral.
  - b. Disengage all drives.
  - c. Lower all implements to the ground.
  - d. Engage parking brake.
  - e. Stop engine and remove the ignition key.
- 2. Keep hands, feet, and clothing away from moving parts. Wait for all movement to stop before you clean, adjust or service the machine.
- 3. Keep the area of operation clear of all bystanders and pets.
- 4. Never carry passengers, unless a seat is provided for them.
- 5. Never operate mowing equipment without the discharge deflector securely fastened in place.

By following all instructions in this manual, you will prolong the life of your machine and maintain its maximum efficiency. Adjustments and maintenance should always be performed by a qualified technician.

If additional information or service is needed, contact your Authorized Jacobsen Dealer who is kept informed of the latest methods to service this equipment and can provide prompt and efficient service. **Use of other than original or authorized Jacobsen parts and Accessories will void the warranty.** 

# 2.1 PRODUCT IDENTIFICATION \_\_\_\_\_

70528	. HR 9016 Turbo, 4 Wheel Drive
70529	.HR 9016 Turbo, 4 Wheel Drive
	with ROPS
70530	. HR 9016 Turbo, 4 Wheel Drive EC
0 : 111 1	A . 1 . 100 . 1 . 11 . 11 . 11
Serial Number	. An identification plate, like the one
	shown, listing the serial number, is
	attached to the frame of the tractor
	and is located to the operator's

Always provide the serial number of the unit when ordering replacement parts or requesting service information.

right just over the rear axle.



Product*	EEC Sound	Sound Pressure	Vibration M/	
Troduct	Power	Level Operator Ear	Arms	Body
70530	105 dba	90 dba	.755	.026

<sup>\*</sup> With engine at 2400 RPM (No Load)

# 2.2 ENGINE\_\_\_\_\_

Make	Capacity
ModelV3300 DI-T-E2B	Governor Setting:
Horsepower	Throttle Stop On 2450 rpm (PTO off)
Note: Actual sustained horsepower will likely be lower	2300 rpm (PTO engaged)
than listed in specifications due to operating limitations	Throttle Stop Off 2750 rpm (Non EU only)
and enviromental factors.	Low Idle 950 rpm
	Lubrication:
Displacement	Capacity14 qts.
Torque	Type SAE 15 W40
Fuel:	API Classification CF 4, CD-II, CE
Type No. 2 Diesel (CUNA NC 630.01)	Air Filter Dry type with evacuator valve and
RatingMin. cetane rating 45	service indicator.

#### 2.3 TRACTOR

Tires:

Front	29 x 14 - 15: 12 ply	Mow	0 - 8.5 mph (13.6 kph)
Rear	24 x 12 -12: 6 ply	Transport - 2 WD	0-20 mph (29 kph)
Pressure	20-22 psi (138-152 kPa)	Reverse - 2WD	0-5.5 mph (8.9 kph)
Battery:		Reverse - 4 WD	0 - 3 mph (4.8 kph)
Туре	One Maintenance Free 12 Volt Battery	Production	16.5 acres per hour @ 8.5 mph
	600 CCA @ 0°F (-18°C)	Hydraulic System:	
Group	75DT	Capacity	55 U.S. gal. (208 liters) System
Brakes:		Reservoir	33 U.S. gal. (125 liters)
Service	Dynamic braking through traction	Fluid Type	ISO VG 68
	circuit.	Cooling	Hydraulic oil Cooler
Parking	Mechanical front wheel drum	Charge Filter	10 micron
	Hand lever actuated	Return Line Filter	10 micron
Turn-assist	Mechanical front wheel drum Two pedal actuation	Steering	Hydrostatic power steering

Speed:

#### 2.4 WEIGHTS AND DIMENSIONS \_\_\_\_\_\_

Dimensions:	Inches	(mm)	Weights:	Lbs.	(kg)
Length - Front deck down	174	(4420)	Overall (less operator)6	385	(2880)
Height - Top of Steering Wheel	60	(1524)			
Height - Top of ROPS	94	(2388)			
Width - Mow	198	(5029)			
Width - Transport	95	(2413)			

### 2.5 CUTTING UNITS \_\_\_\_\_

Width	Blade size	21 in. (533 mm)
Front Deck92 in. (2336 mm)	Tip speed	16,500 ft./min. (5029 m/min.)
Side Decks59 in. (1499 mm)	Tires	
Number of Blades	Size	Ten 11 x 4.00 - 5.0 (4 ply)
Front Deck5		Two 13 x 6.50 - 6.0 (4 ply)
Side Decks3	Pressure	20-25 psi (138-173 kPa)
Overall Cutting Width 16 ft. (2.4 m)		
Cutting Height1-5.5 in. (25 - 140 mm)		

### 2.6 ACCESSORIES & SUPPORT LITERATURE \_\_\_\_\_

Contact your area Jacobsen Dealer for a complete listing of accessories and attachments.

# **A** CAUTION

Use of other than Jacobsen authorized parts and accessories may cause personal injury or damage to the equipment and will void the warranty.

Air Blow Gun	JAC5098
Orange Touch-up Paint (12 oz. spray)	554598
2-Post ROPS with Seat Belt	78138
● All Weather Cab w ROPS and Seat Belt	See Below
Air Conditioner Kit	See Below
Leaf Mulching Kit	71055
High Lift Blade Kit	4116825
Light Harness Kit	5003564
Road Light Kit (Requires 5003564)	78154
Work Light Kit (Requires 5003564)	78155
Canopy / Sunshade	67857
Rear Steering Wheel Weight Kit	2812307

● Contact: Jodale Perry Corporation Box 990, 300 Route 100

Morden, Manitoba, Canada R6M 1A8

Phone: (204) 822-9100 Fax: (204) 822-9111

◆ Contact: Loftness Specialized Equipment, Inc.

South Highway 4 Hector, MN 55342 Phone 800-828-7624 Fax (320) 848-6269 ATTN Doug Haley

Carefree Tire Kit	2811453
Hood Locking Latch	1004049
Cold Start / Preheat Timer Kit	4137294
Cruise Control	67888
◆ Snowthrower	See Below
▲ Rotary Broom	See Below
Service and Support Literature	
Safety and Operation Manual	3010791
Parts and Maintenance Manual	2810223
Operator Training Video	5003465
Service & Repair Manual	

▲ Contact: M-B Companies, Inc.

1200 S. Park Street, Box 148

Chilton, WI 53014 Phone: (888) 558-5801 Fax: (920) 898-4588

#### 3.1 GENERAL

# **A** WARNING

To prevent injury, lower implements to the ground, disengage all drives, engage parking brake, stop engine and remove key from ignition switch before making any adjustments or performing maintenance.

Make sure the tractor is parked on a solid and level surface. Never work on a tractor that is supported only by the jack. Always use jack stands.

If only the front or rear of the tractor is raised, place chocks in front of and behind the wheels that are not raised.

1. Adjustments and maintenance should always be performed by a qualified technician. If proper

- adjustment cannot be made, contact an authorized Jacobsen Dealer.
- 2. Replace, do not adjust, worn or damaged components.
- Do not wear jewelry or loose fitting clothing when making adjustments or repairs.

# **A** CAUTION

Be careful to prevent entrapment of the hands and fingers between moving and fixed components of the machine.

4. Do not change governor settings or overspeed the engine.

#### 3.2 LEVELING DECKS

If the decks or casters have been removed for service or cutting height appears uneven, it may be necessary to level decks. Adjust casters so cutting heights of outer blades are within 1/8" (3 mm) of each other.

- Position tractor and decks on a hard, flat, level surface. Position blades parallel to tractor as shown.
- 2. Check that air pressure in all caster tires is adjusted equally.
- 3. Set desired cutting height of deck using the 1/2" (13 mm) spacers (E) provided. See Section 3.5
- 4. Measure the height from the ground surface to the front edge (B) of the two outer blades for the wing decks and the center section of the front deck. Position the 1/8" (3 mm) leveling washers (C) above or below caster pivot as needed to obtain an even cutting height across decks. Keep the 1/16" (1.5 mm) thrust washers (D) positioned as shown, one above and one below caster pivot.




Figure 3A

#### 3.3 SERVICING FRONT DECK

The front deck can be raised and tilted up to improve access to the cutting unit and blades for service and cleaning. Be sure to disengage all drives, engage parking brake, stop engine and remove ignition key before working around deck.

#### To tilt front deck up to its service position:

- 1. Rotate anti-sway mechanism **(F)**, located under left side floor panel, to Service position. Figure 3C
- 2. Start engine and raise deck until rear gauge wheels are off ground. Stop engine.
- 3. Remove cut height adjustment pins from gauge wheel bracket so yoke assembly floats freely.
- 4. Start engine and raise deck to full up position. Stop engine.
- 5. Manually lift and rotate front of deck up until it is securely latched.



# **WARNING**

The front deck is heavy and could cause serious injury or damage if dropped. Always use proper lifting techniques when lifting or lowering the front deck to the service position.

When lowering deck, pulling latch out will release the full weight of the deck. Make sure anyone assisting in this procedure is made aware of this before the latch is released.

#### To lower deck after servicing:

1. Lift up on deck and pull locking latch (A) out. Manually lower and pivot deck until supported by lift

- arms. To prevent personal injury or damage to deck or lift arms, **DO NOT** allow deck to drop from service position.
- 2. Start engine and lower deck until it is level and caster wheels are just above ground. Stop engine.
- 3. Insert height adjustment pin for rear casters to match cutting height. Figure 3F
- 4. Rotate anti-sway mechanism **(F)** to it's operating position. Figure 3C




Figure 3B




Figure 3C

#### 3.4 WINGLET ADJUSTMENT\_\_\_

- 1. Winglets must be adjusted to front deck to prevent scalping and possible damage to deck winglets.
- 2. Rotate front deck blades to positions shown in Figure 3A.
- Measure the height from the ground to the front edge of the center front deck blade (B) and the outside edges of winglet blades (L). Add or remove shims (G) as required between pad (H) and support bracket of winglets, until all front deck blades are at the same height.
- 4. Store excess shims (G) above support bracket.
- 5. Adjust front winglet support arms (J) up or down as required until arm is resting against stop (K).




Figure 3D

#### 3.5 CUTTING HEIGHT

Cutting height for decks can be adjusted from 1 to 5-1/2 in. (25-125 mm) in 1/2 in. (13 mm) increments. Actual cutting height may vary somewhat from the heights given depending on turf conditions and other factors.

**Note**: When cutting undulating areas, lower cutting heights may cause scalping. Adjust height accordingly to prevent turf damage.

 Park the tractor on a flat, level surface. Raise the decks until the caster wheels are raised off the ground enough so caster wheels can be removed from deck. Place blocks under decks so they are supported on all sides.

# A

### **WARNING**

To prevent serious injury, lower deck until it is resting completely on the supports. This will prevent it from accidentally lowering while making adjustments. Disengage all drives, engage parking brake, stop engine and remove ignition key.

To remove inside, front caster from side decks raise the decks to their full upright position and lock in the transport position.

2. Figure 3E shows the height adjustment decal for the casters.

Column 1 - Height of cut

Column 2 - Mount Location

Column 3 - Arrangement of spacers

Adjust spacers in quantity listed. Store extra spacers on top of spindle. If necessary, reposition wheel mount in holes indicated for height of cut.

**IMPORTANT:** Do not reposition the thin thrust washers (1/16") and leveling washers (1/8") on the spindle. These washers should remain in the same position and quantity they were originally installed. They need only be repositioned if needed to level new casters or decks, Section 3.2

- To adjust rear gauge wheels on front deck refer to Figure 3F. Raise front deck approximately 12" and support underneath with blocks. Lower deck so it is completely resting on blocks
- 4. Remove pin from rear gauge wheel yoke and reposition in bracket for desired height of cut. When setting cutting height at 5-1/2", gauge wheel must be repositioned in arm. Follow wheel mounting instructions on decal, Figure 3F.





Figure 3E



**Gauge Wheel Adjustment for Front Deck** 

Figure 3F

#### Tire pressure

Check air pressure in caster tires, while tires are cool. Maintain air pressure between 20-25 psi (138-173 kPa) to improve accuracy of cutting height.

**Note**: It is important to keep inflation pressures on all caster and gauge tires equal, within the range specified, to ensure an accurate, level cut.

#### 3.6 PARKING BRAKE

The brake switch is part of the operator back-up system and senses when the parking brake is engaged. If this switch fails the machine may not start and the operator back-up system will not operate correctly.

#### To adjust switch:

- 1. Place the parking brake in its full upright (engaged) position.
- 2. Adjust switch **(C)** by pivoting switch mounting bracket **(B)**. Align sensing area on switch with brake handle **(D)**.
- Adjust gap between sensing area on switch and brake lever to 1/16 - 1/8" (1.5 - 3 mm). To adjust gap use shims (E) or #10 washers (F) as required between switch and switch mount.

 When properly installed the switch will be closed when the parking brake is engaged and open when the brake is disengaged.

**Important:** Always check operator back-up system after replacing or adjusting switch. (See Safety and Operation Manual)




Figure 3G

#### 3.7 NEUTRAL ADJUSTMENT

**Important:** The neutral adjustment on the drive pump is preset at the factory on all new tractors and replacement pumps. Further adjustment is required **only** if the pump has been disassembled for service or neutral lever bracket **(F)** has become loose.

#### To adjust neutral on pump:

- 1. Disconnect traction pedal linkage from pump. Remove switch mounting bracket from pump.
- 2. Place tractor securely on jack stands so **All** wheels are raised off ground.
- 3. Check that tow valve (H) is completely closed.
- 4. Loosen screws **(G)** holding pump return arm bracket just enough so it can be moved.
- 5. Engage parking brake and set PTO switch to neutral.

The neutral sensing switch must be closed in order to start the tractor. At this point the switch may not yet be assembled to pump. To close switch so engine can be started, place it face down on metal frame.

- 6. Start engine and observe wheels. Rotate bracket **(F)** in slotted holes until wheels do not turn. Turn off engine and tighten bracket in place.
- 7. Connect traction pedal linkage, Section 3.11, and install and adjust switches, Sections 3.8 and 3.9.
- Start engine and check operation of traction pedal. Wheels must not turn when pedal returns to neutral.




Figure 3H

#### 3.8 NEUTRAL SENSING SWITCH

The neutral sensing switch is part of the operator backup system. It is designed to prevent the tractor from starting unless the traction pedal is in neutral. If this switch fails or is out of adjustment the tractor will not start.

- 1. Make sure drive pump and traction pedal linkage are adjusted to neutral. Sections 3.7 and 3.11.
- 2. Position switch so pointer **(A)** on activator plate is centered over sensing area on switch.
- Adjust switch so gap between sensing surface on switch and end of pointer is between 1/16" - 1/8" (1.5 - 3 mm). Secure switch in this position.
- 4. After adjustment check operation of operator backup system.




Figure 3I

#### 3.9 FORWARD SENSING SWITCH

The forward sensing switch allows the tractor to operate in four wheel drive only with the traction pedal in its forward position. When operating in reverse the switch opens and returns the tractor to two wheel drive. If four wheel drive fails to operate, check adjustment and operation of sensing switch.

- 1. Make sure drive pump, traction pedal linkage and neutral sensing switch are adjusted to neutral, Sections 3.7, 3.11 and 3.8.
- 2. Adjust switch so gap between sensing surface on switch and edge of activator plate is between 1/16" 1/8" (1.5 3 mm).
- Disconnect switch from wiring harness and connect a continuity meter across switch leads (B). With traction pedal in neutral, slide switch back until it opens, then forward until it closes. Secure switch in this position.
- 4. With continuity meter still attached check adjustment by pressing traction pedal.

**Switch closed** - traction pedal in neutral and during full forward range of pedal.

**Switch open** - Full reverse range of pedal.

5. Connect switch to wiring harness and check operation of four wheel drive.




Figure 3J

#### 3.10 LIFT LIMIT SWITCHES

The rotation of the cutting blades is controlled by limit switches positioned on the tractor frame near the lift arms for each deck. When a deck is raised the switch opens and automatically disengages the cutting blades. As the deck is lowered, the switch closes and the blades engage. If a switch fails, the cutting blades will not engage when lowered.

#### To adjust limit switches:

- 1. Park tractor on a level surface.
- 2. Start tractor and raise or lower decks until the highest point on the top corner of the deck reaches the height shown in Figure 3K.

- Shut off engine and remove key. Support decks using blocks. This will prevent them from accidently lowering while making adjustments.
- Position switch so sensing area (C) on switch is centered over leading edge (A) of activator plate on lift arm.
- Adjust gap between sensing area on switch and activator plate on lift arm to 1/16"-1/8" (1.5 3 mm).
   To adjust gap for front lift arm use shims (D) or #10 flat washers (B) between switch and switch mount.

Check operation of limit switches. Blades must stop rotating as decks are raised above heights shown.




Figure 3K

#### 3.11 TRACTION PEDAL

The traction pedal must be adjusted so the pump is at full stroke when the pedal is fully depressed in the forward position.

- 1. Make sure return arm **(K-Figure 3H)** on pump is adjusted to neutral, Section 3.7.
- 2. Push traction pedal forward (I) until it touches floor panel and hold in this position.
- Adjust turn buckle (J) until you feel the return arm hit the internal stop in pump. Backoff rod 2-3 turns from this position. This ensures that the traction pedal bottoms out before the return arm.




Figure 3L

#### 3.12 STEERING TOE-IN\_

- 1. Turn wheels to straight ahead position.
- 2. Loosen jam nuts (M) on both ends of tie rod (N).
- 3. Turn tie rod **(N)** to provide proper toe-in. Toe-in must not exceed **X** + 1/4" (6.3 mm). Tighten jam nuts **(M)**.




Figure 3M

#### 3.13 STEERING STOP BOLTS

- Steering toe-in must be set before adjusting stop bolts. If toe-in is changed, stop bolts must be readjusted.
- 2. Turn stop bolts (P and Q) out as far as possible without removing them.
- Turn steering wheel to the right until right rear tire is at a 45° angle to steering axle. Thread stop bolt (P) in until bolt touches axle.
- 4. Turn steering wheel to the left until left rear tire is at a 45° angle to steering axle. Thread stop bolt (Q) in until bolt touches axle.




Figure 3N

### 3.14 TORQUE SPECIFICATION\_

# **CAUTION**

All torque values included in these charts are approximate and are for reference only. Use of these torque values is at your sole risk. Jacobsen is not responsible for any loss, claim, or damage arising from the use of these charts.

Extreme caution should always be used when using any torque value.

Jacobsen uses Grade 5 Plated bolts as standard, unless otherwise noted. For tightening plated bolts, use the value given for lubricated.

	AMERICAN NATIONAL STANDARD FASTENERS										
SIZE	UNITS	GRA	DE 5	GRADE 8		SIZE	UNITS	GRADE 5		GRADE 8	
		Lubricated	Dry	Lubricated	Dry			Lubri-	Dry	Lubri-	Dry
								cated		cated	
#6-32	in-lb (Nm)	-	20 (2.3)	-	-	7/16-14	ft-lb (Nm)	37 (50.1)	50 (67.8)	53 (71.8)	70 (94.9)
#8-32	in-lb (Nm)	_	24 (2.7)	-	30 (3.4)	7/16-20	ft-lb (Nm)	42 (56.9)	55 (74.6)	59 (80.0)	78 (105)
#10-24	in-lb (Nm)	_	35 (4.0)	-	45 (5.1)	1/2-13	ft-lb (Nm)	57 (77.2)	75 (101)	80 (108)	107 (145)
#10-32	in-lb (Nm)	_	40 (4.5)	-	50 (5.7)	1/2-20	ft-lb (Nm)	64 (86.7)	85 (115)	90 (122)	120 (162)
#12-24	in-lb (Nm)	_	50 (5.7)	-	65 (7.3)	9/16-12	ft-lb (Nm)	82 (111)	109 (148)	115 (156)	154 (209)
1/4-20	in-lb (Nm)	75 (8.4)	100 (11.3)	107 (12.1)	143 (16.1)	9/16-18	ft-lb (Nm)	92 (124)	122 (165)	129 (174)	172 (233)
1/4-28	in-lb (Nm)	85 (9.6)	115 (13.0)	120 (13.5)	163 (18.4)	5/8-11	ft-lb (Nm)	113 (153)	151 (204)	159 (215)	211 (286)
5/16-18	in-lb (Nm)	157 (17.7)	210 (23.7)	220 (24.8)	305 (34.4)	5/8-18	ft-lb (Nm)	128 (173)	170 (230)	180 (244)	240 (325)
5/16-24	in-lb (Nm)	173 (19.5)	230 (26.0)	245 (27.6)	325 (36.7)	3/4-10	ft-lb (Nm)	200 (271)	266 (360)	282 (382)	376 (509)
3/8-16	ft-lb (Nm)	23 (31.1)	31 (42.0)	32 (43.3)	44 (59.6)	3/4-16	ft-lb (Nm)	223 (302)	298 404	315 (427)	420 (569)
3/8-24	ft-lb (Nm)	26 (35.2)	35 (47.4)	37 (50.1)	50 (67.8)	7/8-14	ft-lb (Nm)	355 (481)	473 (641)	500 (678)	668 (905)

	METRIC FASTENERS									
SIZE	UNITS	4.	6	8.	8	10.9		12.9		Non Critical Fasteners into Aluminum
		Lubricated	Dry	Lubricated	Dry	Lubricated	Dry	Lubricated	Dry	
M4	Nm (in-lb)	-	-	_	_	_	-	3.83 (34)	5.11 (45)	2.0 (18)
M5	Nm (in-lb)	1.80 (16)	2.40 (21)	4.63 (41)	6.18 (54)	6.63 (59)	8.84 (78)	7.75 (68)	10.3 (910	4.0 (35)
M6	Nm (in-lb)	3.05 (27)	4.07 (36)	7.87 (69)	10.5 (93)	11.3 (102)	15.0 (133)	13.2 (117)	17.6 (156)	6.8 (60)
M8	Nm (in-lb)	7.41 (65)	9.98 (88)	19.1 (69)	25.5 (226)	27.3 (241)	36.5 (323)	32.0 (283)	42.6 (377)	17.0 (150)
M10	Nm (ft-lb)	14.7 (11)	19.6 (14)	37.8 (29)	50.5 (37)	54.1 (40)	72.2 (53)	63.3 (46)	84.4 (62)	33.9 (25)
M12	Nm (ft-lb)	25.6 (19)	34.1 (25)	66.0 (48)	88.0 (65)	94.5 (70)	125 (92)	110 (81)	147 (108)	61.0 (45)
M14	Nm (ft-lb)	40.8 (30)	54.3 (40)	105 (77)	140 (103)	150 (110)	200 (147)	175 (129)	234 (172)	94.9 (70)

#### 4.1 GENERAL



# WARNING

Before you clean, adjust, or repair this equipment, disengage all drives, lower implements to the ground, engage parking brake, stop engine and remove key from ignition switch to prevent injuries

Make sure the tractor is parked on a solid and level surface. Never work on a tractor that is supported only by the jack. Always use jack stands.

- Adjustment and maintenance should always be performed by a qualified technician. If proper adjustments cannot be made, contact an Authorized Jacobsen Dealer.
- 2. Inspect the equipment on a regular basis, establish a maintenance schedule and keep detailed records.
  - a. Keep the equipment clean.

- Keep all moving parts properly adjusted and lubricated.
- Replace worn or damaged parts before operating the machine.
- d. Keep all fluids at their proper levels.
- e. Keep shields in place and all hardware securely fastened.
- f. Keep tires properly inflated.
- 3. Do not wear jewelry or loose fitting clothing when making adjustments or repairs.
- 4. Use the illustrations in the Parts List as reference for the disassembly and reassembly of components.
- 5. Recycle or dispose of all hazardous materials (batteries, fuel, lubricants, anti-freeze, etc.) according to local, state or federal regulations.

#### 4.2 INSPECTING BLADES

 Every 50 hours of operation or whenever mower is removed from tractor, carefully examine the blades to make sure they are in good operating condition. Blades showing any bends (G), grooves (H) or cracks (J) must be replaced.



#### CAUTION

Use care when checking blades to avoid pinching hands and fingers between blade ends.



# WARNING

Never attempt to straighten, weld or repair a damaged blade. Always replace a damaged blade.

- Any of the above conditions can cause a piece of the blade to break away and be hurled from the mower; causing very serious injury to bystanders or property damage.
- A bent blade could have a microscopic crack (G) that can grow and allow a piece of the blade to break. Bent blades will also create vibration and other stress on the machinery.
- 4. Dust or sand particles can wear a dangerous groove in the blade (H) between the air vanes and the flat portion of the blade that will rapidly grow and produce a crack (J), permitting a piece of the vane to break off.




Figure 4A

#### 4.3 SHARPENING BLADES

 Place a wooden block between the blade and mower housing to stop the blade from moving. To remove blade, turn screw holding blade counterclockwise.

# A

### WARNING

The mower blades can develop sharp edges. Use caution whenever servicing and handling.

 When dressing or sharpening the blade, do not follow the original pattern of grind as shown in (A). Grind new cutting edges at an angle as shown in (B).

If the maximum total loss of the blade reaches 1/2 in., (13 mm), do not sharpen further, replace blade.



# **WARNING**

Resharpening the blade beyond the allowable 1/2 in., (13 mm) may allow blade tip break off and be thrown from the mower. Such an incident can cause very serious injury to bystanders and/or property damage.

- 3. Make sure an equal amount of material is removed from both sides of blade to prevent having an unbalanced blade. An unbalanced blade will cause excessive vibration and may damage the mower.
- 4. Use a blade balancer to check the blade after sharpening.
- Attach blade to mower. Install blades so cutting edges (C) face the direction of rotation as shown in Figure 4C. Beveled cutting edge of blade must face in toward deck housing.

Torque center mounting screw holding blade to 75 to 90 ft. lb. (100 to 120 Nm).




Figure 4B




Figure 4C

#### 4.4 ENGINE

IMPORTANT: A separate Engine Manual, prepared by the engine manufacturer, is supplied with this tractor. Read the engine manual carefully until you are familiar with the operation and maintenance of the engine. Proper attention to the engine manufacturer's directions will assure maximum service life of the engine. To order replacement engine manuals contact the engine manufacturer.

The proper break-in of a new engine can make a considerable difference to the performance and life of the engine.

During the break-in period, Jacobsen recommends the following:

 During the first 50 hours of operation, a new engine should be allowed to reach an operating temperature of at least 140°F (60°C) prior to operation at full load.

- Check the engine oil level twice daily during the first 50 hours of operation. Higher than normal oil consumption is not uncommon during the initial break-in period.
- Change engine oil and oil filter element after first 50 hours of operation.
- Check and adjust fan and alternator belts.
- 5. Refer to Section 4.23 and Engine Manual for specific maintenance intervals and procedures.

If the injection pump, injectors or the fuel system require service, contact an authorized Jacobsen Dealer.

**Note:** The tractor is designed to operate and cut most efficiently at the preset governor setting. Do not change the engine governor settings or overspeed the engine.

#### 4.5 ENGINE OIL

Check the engine oil at the start of each day, before starting the engine. If the oil level is low, remove oil filler cap and add oil as required up to MAX mark on dipstick.

Perform initial oil change after first 25 hours of operation and every 250 hours thereafter. See Engine Manual.

Use engine oil with API classification CD-II, CE, CF-4. See Engine Manual for complete specifications.




Figure 4D

#### 4.6 MUFFLER AND EXHAUST



# **WARNING**

Exhaust fumes contain carbon monoxide that is toxic and can be fatal when inhaled.

**NEVER** operate an engine without proper ventilation.

To protect from carbon monoxide poisoning, inspect the complete exhaust system regularly and always replace a defective muffler. If you notice a change in the color or sound of the exhaust, stop the engine immediately. Identify the problem and have the system repaired.

Torque all exhaust manifold hardware evenly. Tighten or replace exhaust clamps.

#### 4.7 AIR FILTER

Check the service indicator daily. Replace air cleaner element immediately when red band becomes visible (A)

Do not remove the element for inspection or cleaning. Unnecessary removal of the filter increases the risk of injecting dust and other impurities into the engine.

When service is required, first clean the outside of the filter housing; then remove the old element as gently as possible and discard.

- 1. Carefully clean the inside of the filter housing without allowing dust into the air intake.
- 2. Inspect the new element. Do not use a damaged element and never use an incorrect element.
- 3. Assemble the new element and make sure it seats properly. Reset the indicator by depressing button (B).
- 4. Reassemble cap making sure it seals completely around the filter housing. Dust evacuator **(C)** must be facing down.

5. Check all hoses and air ducts. Tighten hose clamps.




Figure 4E

#### 4.8 FUEL

Handle fuel with care - it is highly flammable. Use an approved container, the spout must fit inside the fuel filler neck. Avoid using cans and funnels to transfer fuel.



### WARNING

Never remove the fuel cap from the fuel tank, or add fuel, when the engine is running or while the engine is hot.

Do not smoke when handling fuel. Never fill or drain the fuel tank indoors.

Use4 care to avoid spilling fuel. If fuel is spilled, clean it up immediately.

Never handle or store fuel containers near an open flame or any device that may create sparks and ignite the fuel or fuel vapors.

Be sure to reinstall and tighten fuel cap securely.

- Fill the fuel tank to within 1 in. (25 mm) below the filler neck.
- Use clean, fresh, #2 Diesel fuel. Minimum Cetane Rating 45. Refer to Engine Manual for additional information.

- Replace fuel lines and clamps at the first sign of damage.
- Store fuel according to local, state or federal ordinances and recommendations from your fuel supplier.
- Never overfill or allow the tank to become empty.

Read Engine Owner's Manual for additional fueling information.

#### 4.9 FUEL SYSTEM

Refer to Section 4.23 for specific maintenance intervals.

#### See Engine Manual for detailed procedures.

Before replacing any filter, thoroughly clean the filter housing and the area around the filter. Dirt must not be allowed to enter into fuel system.

Bleed the fuel system after the fuel filter and lines have been removed, or the fuel tank has become empty.

#### To change fuel filter:

- 1. Close fuel valve on tank; then remove and discard the existing filter.
- 2. Apply a light coat of oil to the gasket and hand tighten new filter.
- Fill fuel tank. Open fuel valve on tank and bleed the filter. See Engine Manual. Clean any spilled fuel immediately.

#### 4.10 BATTERY

Make absolutely certain the ignition switch is "Off" and the key has been removed before servicing the battery.



### **CAUTION**

Always use insulated tools, wear protective glasses or goggles and protective clothing when working with batteries. You must read and obey all battery manufacturer's instructions

Tighten cables securely to battery terminals and apply a light coat of silicone dielectric grease to terminals and cable ends to prevent corrosion. Keep vent caps and terminal covers in place

Keep the cable ends, battery and battery posts clean.

Verify battery polarity before connecting or disconnecting the battery cables.

- 1. When installing the battery, always assemble the RED, positive (+) battery cable first and the ground, BLACK, negative (-) cable last.
- 2. When removing the battery, always remove the ground, BLACK, negative (-) cable first and the RED, positive (+) cable last.
- 3. Make sure battery is properly installed and secured to the battery tray.



### WARNING

Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. Wash your hands after handling.

#### 4.11 JUMP STARTING \_\_\_\_\_

Before attempting to "jump start" the tractor, check the condition of the discharged battery. Section 4.10



### **WARNING**

Batteries generate explosive hydrogen gas. To reduce the chance of an explosion, avoid creating sparks near battery. Always connect the negative jumper cable to the frame of the tractor with the discharged battery, away from the battery.

#### When connecting jumper cables:

- 1. Stop the engine on vehicle with good battery.
- 2. Connect RED jumper cable to the positive (+) terminal on the good battery and to the positive (+) terminal on the "discharged" battery.
- Connect the BLACK jumper cable from the negative (-) terminal on the good battery to the **frame** of tractor with discharged battery.

After cables have been connected, start the engine on the vehicle with the good battery then start the tractor.

#### 4.12 CHARGING BATTERY



# **WARNING**

Charge battery in a well ventilated area. Batteries generate explosive gases. To prevent an explosion, keep any device that may create sparks or flames away from the battery.

To prevent injury, stand away from battery when the charger is turned on. A damaged battery could explode.

1. Refer to Section 4.10. Read the Battery and Charger's manual for specific instructions.

- Whenever possible, remove the battery from the tractor before charging. If battery is not sealed, check that the electrolyte covers the plates in all the cells.
- 3. Make sure the charger is "Off", then connect the charger to the battery terminals as specified in the charger's manual.
- 4. Always turn the charger "Off" before disconnecting charger from the battery terminals.

#### 4.13 HYDRAULIC HOSES \_\_\_\_\_



# WARNING

To prevent serious injury from hot, high pressure oil, never use your hands to check for oil leaks, use paper or cardboard.

Hydraulic fluid escaping under pressure can have sufficient force to penetrate skin. If fluid is injected into the skin it must be surgically removed within a few hours by a doctor familiar with this form of injury or gangrene may result.

- Always lower implements to ground, disengage all drives, engage parking brake, stop engine and remove key before inspecting or disconnecting hydraulic lines or hoses.
- 2. Check visible hoses and tubes daily. Look for wet hoses or oil spots. Replace worn or damaged hoses and tubes before operating the machine.
- 3. The replacement tube or hoses must be routed in the same path as the existing hose, do not move clamps, brackets and ties to a new location.
- 4. Thoroughly inspect all tubes, hoses and connections every 300 hours.

IMPORTANT: The hydraulic system can be permanently damaged if the oil becomes contaminated. Before disconnecting any hydraulic component, clean the area around the fittings and the hose ends to keep impurities out of the system.

- Before disconnecting any hydraulic component, tag or mark the location of each hose then clean the area around the fittings.
- b. As you disconnect the component, be prepared to assemble plugs or caps to the hose ends and

- open ports. This will keep impurities out of the hydraulic system and also prevent oil spills.
- c. Make sure "O" rings are clean and hose fittings are properly seated before tightening.
- d. Keep the hose from twisting. Twisted hoses can cause couplers to loosen as the hose flexes during operation resulting in oil leaks.
- e. Kinked or twisted hoses can restrict the oil flow causing the system to malfunction and the oil to overheat and also lead to hose failure.

#### 4 MAINTENANCE

#### 4.14 HYDRAULIC OIL

Refer to Section for specific maintenance intervals.

Drain and replace the hydraulic oil if you notice the presence of water or foam in the oil, a rancid odor (indicating excessive heat), or after a major component failure,

Always replace both hydraulic filters when oil filter light stays on or when changing oil.

#### To change hydraulic oil:

 Clean the area around the oil cap to prevent impurities from entering and contaminating the system.

- 2. Remove drain plug from bottom of tank.
- 3. After oil has drained install drain plug and fill with Jacobsen Hydraulic oil.
- 4. Purge air from system.
  - Operate all tractor functions for about 5 minutes to purge air out of the system and stabilize the oil level. During this time, the oil level alarm may sound.
  - Once the level has stabilized and the air is purged, fill the tank to the full mark on dipstick.
     Start engine and check that oil alarm remains off.

#### 4.15 HYDRAULIC FILTERS

The hydraulic system is protected by two 10 micron filters; a charge filter **(B)** and return line filter **(A)**. Flow though the filters is monitored during operation. When pressure drop across the filters is too high the hydraulic oil filter warning light will come on. To ensure continued protection to the hydraulic system, replace filters as soon as possible if light continues to remain on even after hydraulic fluid has warmed up.

**Note:** The warning light will normally come on immediately after starting tractor and remain on until oil has warmed to operating temperature. Wait until oil has warmed up and light goes out before operating tractor.

#### To replace hydraulic filters:

Replace filters once a year when changing hydraulic fluid, or when filter warning light on instrument panel remains on.

The return line filter is mounted to the left side of the oil cooler. The charge filter is mounted to the lower part of the tractor frame behind the left side lift arm.

1. Remove the old filters.

**Note:** Some hydraulic fluid will drain when removing the lower charge filter. Place a drip pan under filter before removing.

- 2. Install new filters. Hand tighten only.
- Operate engine at idle speed with hydraulic system in neutral for five minutes. The oil level alarm may sound during this time.
- 4. Check hydraulic oil level in reservoir and fill to full mark on dipstick.

#### 4.16 RADIATOR & OIL COOLER

# A

### **WARNING**

To prevent serious bodily injury from hot coolant or steam blow-out, never attempt to remove the radiator cap while the engine is running. Stop the engine and wait until it is cool. Even then, use extreme care when removing the cap.

# A

# **CAUTION**

Do not pour cold water into a hot radiator. Do not operate engine without a proper coolant mixture. Install cap and tighten securely.

Check coolant level daily. Radiator should be full and recovery bottle should be up to the **cold** mark.

If you have to add coolant more than once a month, or add more than one quart at a time, have a Jacobsen Dealer check the cooling system.

Drain and refill annually. Remove the radiator cap, open the engine block drain and the radiator drain. Empty and clean the recovery bottle.

Mix clean water with ethylene glycol based anti-freeze for the coldest ambient temperature. Read and follow the instructions on the anti-freeze container and engine manual.

Keep screen, oil cooler and radiator air passages clean. Use compressed air (30 psi maximum) to clean the fins.

#### **Front Screen**

Inspect front screen **(B)** daily and clean as required to remove grass clippings, leaves and other debris that may restrict air flow through oil cooler and radiator.

To remove screen, remove end cap (A) from left side of oil cooler. Slide screen out from side and blow out from back side using compressed air.

#### Oil Cooler and Radiator

Inspect oil cooler and radiator daily and clean as required to maintain good air flow.

- 1. Remove screen (B) from front of oil cooler.
- 2. Unfasten knobs **(C)** located on top of oil cooler and remove plastic shield from front of oil cooler.

- Release prop rod (D) at bottom of cooler and position hydraulic line to the front of it so hose can move freely. Swing cooler up and away from radiator as shown (E). Insert prop rod into hole in frame to hold oil cooler in its service position.
- 4. Use a blow gun to clean the radiator and oil cooler fins.
- 5. After cleaning, swing cooler back in place in front of radiator. Secure prop rod **(D)** down so it holds hydraulic line running behind it in place.
- 6. Replace front screen and shields, and install knobs on top of oil cooler to secure assembly in place.

HR022




Figure 4F

#### 4.17 CARE AND CLEANING

Wash the tractor and implements after each use. Keep the equipment clean.

**Note:** Do not wash any portion of the equipment while it is hot. Do not use high pressure spray or steam. Use cold water and automotive cleaners.

- Use compressed air to clean engine and radiator fins. A special blow gun is available through your Jacobsen Dealer.
- 2. Use only fresh water for cleaning your equipment.

**Note:** Use of salt water or affluent water has been known to encourage rust and corrosion of metel parts resulting in premature deterioration or failure. Damage of this nature is not covered by the factory warranty.

3. Do not spray water directly at the instrument panel, ignition switch, controller or any other electrical components, or at bearing housings and seals.

 Clean all plastic or rubber trim with a mild soap solution or use commercially available vinyl/rubber cleaners.

Repair damaged metal surfaces and use Jacobsen touch-up paint. Wax the equipment for maximum paint protection.



# **CAUTION**

Clean grass and debris from cutting units, drives, muffler and engine to prevent fires.



#### **WARNING**

**NEVER** use your hands to clean cutting units. Use a brush to remove grass clippings from blades. Blades are extremely sharp and can cause serious injuries.

#### 4.18 ELECTRICAL SYSTEM



# **CAUTION**

Always turn the igniton switch off and remove the negative battery cable (Black) before inspecting or working on the electrical system.

General precautions that can be taken to reduce electrical problems are listed below.

- 1. Make certain all terminals and connections are clean and properly secured.
- 2. Check the operator backup system, fuses and circuit breakers regularly.

If the operator backup system does not function properly and the problem cannot be corrected, contact an authorized Jacobsen Dealer.

- 3. Keep the wire harness and all individual wires away from moving parts to prevent damage.
- 4. Make sure the seat switch harness is connected to the main wire harness.
- 5. Check the battery and battery charging circuit.
- 6. Do not wash or pressure spray around electrical connections and components.

Circuits are protected by a circuit breaker (located above batteries), plus fuses and relays mounted under the instrument panel (See Figure 4G and).





Figure 4G

identifies the location and basic functions of the electrical relays located under the control panel. For more detailed information refer to the electrical schematic in this manual.

# Always check Interlock System after servicing the electrical system!



Relay	Description	Function
KYA / K2	Key Switch "A"	Holds fuel stop solenoid valve open when ignition switch is in the RUN position and operator is seated.  Activates glow plug timer if engine isn't running.
KYI / K1	Key Switch "I"	Opens fuel stop solenoid valve when ignition switch is in the START position, power take- off switch is OFF, parking brake and neutral switches are closed.
KYS / K3	Key Switch "S"	Cranks starter motor when ignition switch is in the START position, power take-off switch is OFF, parking brake and neutral switches are closed.
BK1 / K4	Brake -Start	Part of starting circuit. Relay closes when parking brake is engaged.
BK2 / K5	Brake-Run	Disconnects power to cruise control relay (CRS) with parking brake engaged.  Disconnects power to the fuel valve when the operator leaves seat with parking brake disengaged.
NT1 / K6	Neutral-Start	Part of starting circuit. Relay closes when traction pedal is in neutral.
NT2 / K7	Neutral-Run	Disconnects power to the fuel stop solenoid valve when operator leaves seat with neutral switch still open (traction pedal pressed).
NT3 / K8	Neutral-Cruise	Disconnects power to cruise control when neutral switch is closed (traction pedal in neutral).
ML/K9	Mow -Left Deck	Energizes solenoid to left side deck valve when deck is lowered and power take-off switch is ON.
MC / K10	Mow-Center Deck	Energizes solenoid to front deck valve when deck is lowered and power take-off switch is ON.
MR / K11	Mow-RIght Deck	Energizes solenoid to right side deck valve when deck is lowered and power take-off switch is ON.
CRS / K12	Cruise Control	Activates cruise control when cruise control switch is closed, traction pedal is pressed and parking brake is disengaged.
4WD / K13	Four Wheel Drive	Energizes solenoid to four wheel drive valve when four wheel drive switch on instrument panel and forward sensing switch on traction pump are closed.
LTS	Lights	Included with light harness kit 5003564. Controls operation of lights.
K15	Run Circuit Cutout	Disables run circuit when keyswitch is turned to START position.
K16	Auxilliary	Provides power to ignition circuit with keyswitch in RUN position. Disables ignition circuit in START position
K17	Ignition	Provides power to gauges, mow circuit, 4WD circuit and seat switch circuit

#### **4.19 TIRES**

# **A** CAUTION

Unless you have the proper training tools and experience, DO Not attempt to mount a tire on a rim. Improper mounting can produce an explosion which may result in serious injury.

- Keep tires properly inflated to prolong tire life. Check inflation pressure while the tires are cool. Inspect tread wear.
- 2. Check pressure yearly. Use an accurate, low pressure tire gauge.
- 3. Keep tires inflated to proper pressure

Tractor: 20-22 psi (138 -152kPa). Decks: 20-25 psi (138 -173 kPa)

#### 4.20 WHEEL MOUNTING PROCEDURE

#### **Tractor Wheels**



### **WARNING**

Make sure the tractor is parked on a solid and level surface. Never work on a tractor that is supported only by the jack. Always use jack stands.

If only the front or rear of the tractor is raised, place chocks in front of and behind the wheels that are not raised.

- Remove dirt, grease and oil from stud thread. Do not lubricate threads.
- 2. Position wheel on hub and inspect to insure full contact between mounting surface of wheel and hub or brake drum.
- 3. Finger tighten all hardware then torque hardware in crisis-cross order; always tighten nuts in the top position.

**NOTE:** Check and torque lug bolts daily for the first 100 hours of operation.

4. After recieving new unit or if tires were removed, check and torque lug bolts daily until torque is maintained, 65-75 ft.lbs. (88-102 Nm)

#### **Caster Wheels**

To extend bearing life check and adjust caster and gauge wheels every year. Lubricate bearings every 100 hours using NLGI Grade 2 grease.

- 1. Raise deck so wheels are off ground and can be rotated freely by hand.
- 2. Check wheels for end play (I). Wheels should rotate freely with zero end play.
- 3. To eliminate end play, tighten inner nut **(G)** until wheel just begins to bind then loosen it 1/4 turn.

Lock inner nut in position using outer nut **(H)**. Do not allow inner nut to rotate while tightening outer nut.

4. Repeat step 2 and check for end play.




Figure 4H

# 4.21 ROLLOVER PROTECTION STRUCTURE (ROPS)

A Rollover Protection System (ROPS), designed for this tractor, is available as an optional accessory. If your tractor is equipped with this device, inspect it periodically and follow operating procedures described in Safety and Operation Manual



Do not loosen or remove bolts, do not weld, drill, modify, bend or straighten a damaged structure.

- The seat, the seat belt, mounting hardware and any accessories within the ROPS, should be inspected regularly and all damaged parts replaced immediately.
- Once the ROPS has been subjected to any form of impact it should be replaced.
- 3. Check and retorque all hardware. All replacement components used for the ROPS must be as specified in the Jacobsen Parts List.

#### 4.22 STORAGE

#### General

- 1. Wash the tractor thoroughly and lubricate. Repair and paint damaged or exposed metal.
- 2. Inspect the tractor, tighten all hardware, replace worn or damaged components.
- 3. Drain and refill radiator.
- Clean the tires thoroughly and store the tractor so the load is off the tires. If tractor is not on jack stands, check tires at regular intervals and reinflate as necessary.
- 5. Keep the machine and all its accessories clean, dry and protected from the elements during storage. Never store equipment near an open flame or spark which could ignite fuel or fuel vapors.

#### **Battery**

- 1. Remove, clean and store battery in upright position in a cool, dry place.
- 2. Check and recharge battery every 60 to 90 days while in storage.
- Store batteries in a cool, dry place. To reduce the self discharge rate, room temperature should not be above 80°F (27°C) or fall below 20°F (-7°C) to prevent electrolyte from freezing.

#### **Engine**

- 1. While the engine is warm, remove drain plug, drain the oil from the crankcase and change oil filter. Install drain plug and refill with fresh oil. Torque drain plug to 22 ft. lb. (30 Nm).
- 2. Clean exterior of engine. Paint exposed metal or apply a light coat of rust preventative oil.

 Add a fuel conditioner or biocide to prevent gelling or bacterial growth in fuel. See your local fuel supplier.

#### **Cutting Units**

- 1. Wash the cutting units thoroughly, then repair and paint any damaged or exposed metal.
- 2. Lubricate all fittings and friction points.
- 3. Apply a light coat of rust preventative oil to the sharpened edges of the blades.

#### **After Storage**

- 1. Check and reinstall battery
- Check or service fuel filter and air cleaner.
- 3. Check the radiator coolant level.
- 4. Check oil level in the engine crankcase and hydraulic system.
- 5. Fill the fuel tank with fresh fuel. Bleed the fuel system.
- 6. Make certain that the tires are properly inflated.
- Remove all oil from the deck blades. Readjust cutting height.
- 8. Start and operate the engine at 1/2 throttle. Allow enough time for the engine to become properly warmed and lubricated.



Never operate the engine without proper ventilation; exhaust fumes can be fatal when inhaled.

### 4.23 MAINTENANCE CHART \_

# **A** WARNING

Before you clean, adjust, or repair this equipment, disengage all drives, lower implements to the ground, engage parking brake, stop engine and remove key from ignition switch to prevent injuries.

For smooth operation of pivot points and other friction points, apply several drops of SAE 30 oil every 50 hours or as required.

Remove wheels and repack bearings once a year.

#### **Recommended Service and Lubrication Intervals**

	Daily Before Starting	Every 25 Hours	Every 50 Hours	Every 100 Hours	Every 250 Hours	Every Year	See Section	Lubricant Type
Air Cleaner Indicator	I						4.7	
Air Cleaner Element			R-AR			R	4.7	
Battery				I-C		I-C	4.10	
Caster Wheel Bearings		A*		L		I-A	4.20	I
Engine Fan Belt		l*		I-A			**	
Engine Oil	I-A	R*			R		4.5	III
Engine Oil Filter		R*			R		4.5	
Fuel Filter						R	4.9	
Drain Water from Fuel Filter				С			**	
Grease Fittings - F1			L				4.24	II
Grease Fittings - F2				L			4.24	II
Hydraulic Fluid	I-A					R	4.14	IV
Hydraulic Fluid Fllters		1	R-AR			R	4.15	
Oil Cooler	I-C***						4.16	
Radiator Screen	I-C						4.16	
Radiator Coolant	I-A					R	4.16	
Tires	l****					I-A	4.19	

A - Add or Adjust C - Clean I - Inspect L - Lubricate R - Replace AR - As Required

- I Pack bearings with NLGI Grade 2 (Service Class GB)
- II Manual grease gun with NLGI Grade 2 (Service Class LB).
- III Engine Oil See Section 4.5
- IV Jacobsen Hydraulic Oil VG ISO 68


<sup>\*</sup> Indicates initial service for new machines.

<sup>\*\*</sup> See Engine Manual

<sup>\*\*\*</sup>Clean as Required

<sup>\*\*\*\*</sup> Check lug bolt torque daily for first 100 hours of operation.

# 4.24 LUBRICATION CHART



### **Grease Fitting Locations**

ise i ittilig Locations				
50 Hours (Every Week)	Qty	F2 -	150 Hours	Qty
Caster Spindles	(10)	13	Drive Shaft U-Joint	(2)
Caster Wheel Axles	(10)	14	Drive Shaft Slip Joint	(1)
Gauge Wheel Axles	(2)	15	Return Canister Pivot	(6)
Lift Cylinder - Front Deck	(4)			
Lift Arm - Front Deck	(2)			
Side Deck Pivots	(6)			
Steering Cylinder	(2)			
Tie Rod	(2)			
Axle Pivot	(1)			
Wheel Pivot	(2)			
Lift Arm - Side Deck	(2)			
Lift Cylinder - Side Deck	(4)			
	Caster Spindles Caster Wheel Axles Caster Wheel Axles Gauge Wheel Axles Lift Cylinder - Front Deck Lift Arm - Front Deck Side Deck Pivots Steering Cylinder Tie Rod Axle Pivot Wheel Pivot Lift Arm - Side Deck	Caster Spindles (10) Caster Wheel Axles (10) Gauge Wheel Axles (2) Lift Cylinder - Front Deck (2) Side Deck Pivots (6) Steering Cylinder (2) Tie Rod (2) Axle Pivot (2) Lift Arm - Side Deck (2)	Caster Spindles (10) 13 Caster Wheel Axles (10) 14 Gauge Wheel Axles (2) 15 Lift Cylinder - Front Deck (4) Lift Arm - Front Deck (2) Side Deck Pivots (6) Steering Cylinder (2) Tie Rod (2) Axle Pivot (1) Wheel Pivot (2) Lift Arm - Side Deck (2)	Caster Spindles (10) 13 Drive Shaft U-Joint Caster Wheel Axles (10) 14 Drive Shaft Slip Joint Gauge Wheel Axles (2) 15 Return Canister Pivot Lift Cylinder - Front Deck (4) Lift Arm - Front Deck (2) Side Deck Pivots (6) Steering Cylinder (2) Tie Rod (2) Axle Pivot (1) Wheel Pivot (2) Lift Arm - Side Deck (2)

### 5.1 GENERAL\_

The troubleshooting chart below lists basic problems that may occur during start-up and operation. For more detailed information regarding the hydraulic and electrical systems contact your area Jacobsen Dealer.

Symptoms		Possible Causes		Action
Engine will not start.	1.	Parking brake disengaged or power take-off switch on.	1.	Check operator back-up system and start-up procedure.
	2.	Glow plug has not timed out.	2.	Reset ignition switch and allow glow plug to time out before cranking engine.
	3.	Battery low on charge or defective.	3.	Inspect condition of battery and battery connections.
	4.	Fuel tank empty or dirty.	4.	Fill with fresh fuel. Change fuel filter. Bleed fuel lines.
	5.	Fuse blown.	5.	Replace fuse.
	6.	Relay(s) defective	6.	Test and replace relay.
	7.	Traction pedal not in neutral.	7.	Check position of pedal. Adjust Linkage.
	8.	Neutral switch on drive pump not working.	8.	Test, adjust or replace switch.
	9.	Forward sensing switch on drive pump not working.	9.	Test, adjust or replace switch.
Engine hard to start or runs poorly.	1.	Fuel level low, fuel or fuel filter dirty.	1.	Fill with fresh fuel. Change fuel filter. Bleed fuel lines.
	2.	Air cleaner dirty.	2.	Inspect and replace air filter.
	3.	Injectors, fuel pump	3.	Consult engine manual.
	4.	Engine problem.	4.	Consult engine manual
Engine stops.	1.	Fuel tank empty.	1.	Fill with fresh fuel and bleed fuel lines.
	2.	Interlocks not set before leaving operator's seat.	2.	Engage parking brake and set power take-off switch to OFF.
Engine overheating	1.	Coolant level low.	1.	Inspect and add coolant.
	2.	Air intake restricted.	2.	Clean air intake at radiator.
	3.	Water pump belt broken or loose.	3.	Tighten or replace belt. See engine manual.
Battery not holding charge.	1.	Loose or corroded battery terminals.	1.	Inspect and clean terminals
Battery light on.	2.	Low electrolyte.	2.	Refill to correct level.
	3.	Alternator belt loose or broken	3.	Tighten or replace belt. See engine manual.
	4.	Charging system defective.	4.	See engine manual
Cutting units not cutting evenly	1.	Cutting heights not set evenly.	1.	Check that decks are level. Check and adjust cutting height.
	2.	Engine speed too low.	2.	Check engine speed with throttle in its fast position.
	3.	Mow speed not adjusted for turf conditions.	3.	Adjust mow speed for best cut.
	4.	Air pressure in caster tires not adjusted correctly.	4.	Check tires and adjust to correct pressure.

# Ersatzteilbestellung

- Geben Sie Ihren vollen Namen und die vollständige Adresse auf der Bestellung an.
- 2. Erklären Sie, wohin die Teile zu liefern sind und wie.
- 3. Geben Sie Produktnummer, Namen und die Seriennummer an, die auf dem Typenschild des Produkts aufgedruckt ist.
- 4. Bestellen Sie die gewünschte Anzahl, die Teilenummer, den Farbcode und die Teilebeschreibung, wie in der Ersatzteilliste aufgeführt.
- 5. Schicken Sie die Bestellung an den Vertragshändler von Jacobsen oder geben Sie sie persönlich ab.
- Prüfen Sie alle Sendungen bei Empfang. Wenn Teile beschädigt sein oder fehlen sollten, melden Sie dies der Transportfirma vor Annahme.
- Senden Sie Teile nicht ohne erklärenden Brief mit einer Aufstellung der zurückgegebenen Teile zurück. Die Transportkosten hierfür sind von Ihnen zu übernehmen.

Die Verwendung nicht genehmigter Ersatzteile lässt die Garantie ungültig werden.

### Inhalt

1	SICHERHEIT	4	WARTUNG	
1.1	Betriebssicherheit 4	4.1	Allgemeine Informationen	16
1.2	Wichtige Hinweise zur Sicherheit5	4.2	Prüfen der Klingen	16
		4.3	Schleifen der Klingen	17
2	TECHNISCHE DATEN	4.4	Motor	18
2.1	Produktidentifizierung6	4.5	Motoröl	18
2.2	Motor6	4.6	Geräuschdämpfer und Auspuff	18
2.3	Traktor6	4.7	Luftfilter	
2.4	Gewichte und Masse7	4.8	Kraftstoff	19
2.5	Schneidvorrichtungen7	4.9	Kraftstoffsystem	20
2.6	Zubehör & Unterstützungsliteratur7	4.10	Batterie	20
		4.11	Mit Starthilfe Anlassen	20
3	EINSTELLUNGEN	4.12	Aufladen Der Batterie	21
3.1	Allgemeine Informationen8	4.13	Hydraulikschläuche	21
3.2	Ausgleich der Schneidvorrichtungen8	4.14	Hydrauliköl	22
3.3	Wartung der Vorderen Schneidvorrichtung9		Hydraulikfilter	
3.4	Einstellung der Ausleger9	4.16	Kühler & Ölkühler	23
3.5	Schnitthöhe10	4.17	Pflege und Reinigung	24
3.6	Feststellbremse11	4.18	Elektrisches System	24
3.7	Leerlaufeinstellung11	4.19	Reifen	26
3.8	Neutralsensorschalter12	4.20	Verfahren zur Radmontage	26
3.9	Vorwärtssensorschalter12	4.21	Überrollschutz	27
3.10	Hubgrenzschalter13	4.22	Lagerung	27
3.11	Fahrpedal14		Wartungsplan	
3.12	Spurwinkel14	4.24	Schmiertabelle	29
	Lenkanschlagbolzen14			
3.14	Drehmomentdaten15	5	FEHLERSUCHE	
		5.1	Allgemeine Informationen	30

#### Diese Anleitung dient der Wartung und Einstellung dieses Geräts.

Konsultieren Sie die in dieser Anleitung aufgeführten Anweisungen zu Wartung und Einstellung und die in der **Sicherheits- und Bedienungshandbuch** enthaltenen Betriebsanweisungen für die Wartung der Maschine.

Die **Sicherheits- und Bedienungshandbuch** muß in der Tasche hinter dem Sitz aufbewahrt werden, wo sie für den Betreiber jederzeit erreichbar ist.

Copyright 2004 Textron Inc.

"Alle Rechte vorbehalten, einschließlich des Rechts zur Reproduktion dieses Buchs oder Teile dessen in jeglicher Form."

Alle Informationen in dieser Veröffentlichung beruhen auf den Informationen, die zum Zeitpunkt der Drucklegung zur Verfügung standen. Jacobsen behält sich das Recht vor, jederzeit Änderungen ohne vorherige Mitteilung vorzunehmen und ohne dass dem Unternehmen dadurch irgendwelche Verpflichtungen entstehen.

# Vorschläge zur Ersatzteilhaltung

Um Ihre Geräte voll einsatzfähig zu halten, sollten Sie die häufiger gebrauchten Wartungsteile auf Lager haben. Wir geben auch die Teilenummern für zusätzliche Unterstützungsmaterialien und Trainingshilfen an. Eine vollständigere Liste des Zubehörs und der Zusatzgeräte finden Sie in den technischen Daten.

# Ersatzteile

Anz.	Teil-Nr.	Beschreibung	Anz.	Teil-Nr.	Beschreibung
	4137894	Motorölfilter			
	5003370	Luftfilterelement			
	557619	Kraftstofffilterelement			
	5003691	Hydraulikladenfilter			
	5002693	Hydraulikrückholfilter			

# Wartungsunterstützungsmaterial

Anz.	Teil-Nr.	Beschreibung
	4136606	Sicherheits- und Bedienungshandbuch
	4136607	Stückliste und Wartungshandbuch
	4136876	Motor Teilekatalog

	Anz.	Beschreibung
		Wartungshandbuch
ļ		

# Wie dieses Handbuch zu verwenden ist

#### Abkürzungen

N/S - Nicht separat erhältlich, nur durch Bestellung des ganzen Bauteils oder Bausatzes erhältlich.

**AR** -Variable Menge oder Messung für die korrekte Einstellung erforderlich.

**Symbole,** wie ▲, neben der Teilenummer zeigen an, dass eine Fußnote mit zusätzlichen Informationen vorhanden ist, die für die Bestellung des Teils wichtig sind.

#### Eingerückte Teile

Teile hinter Aufzählungszeichen geben Teile an, die zu einer Baugruppe oder einem anderen Bauteil gehören. Diese Teile können separat oder als Teil des Hauptbauteils bestellt werden.

Teil	Teil-Nr.	Anz.	Beschreibung	Seriennummer/Anmerkung	
<b>1</b>	123456 1 Halterung, Ventil		Halterung, Ventil	Zeigt an, dass dies Teil eines Bauteils ist	
2	789012	1	Ventil, Hub-	Enthält Teil 3 und 4	
3	345678	1	• Griff	In Teil 2 eingeschlossenes wartungsfähiges Teil	
4	N/S	1	Dichtungssatz	In Teil 2 eingeschlossenes nicht wartungsfähiges Teil	
5	901234	1	Schraube, Sechskant 1/4-20 x 2"	Zeigt an, dass dies Teil eines Bauteils ist	

#### 1.1 BETRIEBSSICHERHEIT

# ACHTUNG

# GERÄTE, DIE UNSACHGEMÄSS ODER DURCH UNGESCHULTES PERSONAL OPERIERT WERDEN, KÖNNEN GEFÄHRLICH SEIN.

Machen Sie sich mit der Position und ordnungsgemäßen Verwendung aller Kontrolleinrichtungen vertraut. Unerfahrene Bediener sollten von jemanden, der mit dem Gerät vertraut ist, eingewiesen werden, bevor die Maschine bedienen dürfen.

- Sicherheit hängt vom Bewusstsein, der Vorsorge und Vorsicht derer, die die Maschine bedienen oder warten ab. Minderjährige sollten nie irgendwelche Maschinen bedienen dürfen.
- Sie sind dafür verantwortlich, dieses Handbuch und alle mit der Maschine verbundenen Veröffentlichungen (Sicherheits- und Betriebshandbuch, Motorhandbuch, Zubehöre und Zusatzgeräte) zu lesen. Wenn der Bediener nicht in der Lage ist, die deutsche Version zu lesen, dann ist der Eigentümer dafür verantwortlich, dass ihm die in diesem Handbuch enthaltene Information erklärt wird.
- Lernen Sie, wie die Maschine ordnungsgemäß eingesetzt wird, sowie die Position und den Zweck aller Kontroll- und Messeinrichtungen, bevor Sie sie in Betrieb nehmen. Arbeiten mit unvertrauten Geräten kann zu Unfällen führen.
- Erlauben Sie nie, dass jemand ohne ordnungsgemäße Schulung oder Einweisung oder unter Einfluss von Alkohol oder Medikamenten/Drogen die Maschine bedient oder wartet.
- Zum Schutz von Kopf, Augen, Ohren, Händen und Füßen alle notwendige Schutzkleidung und Schutzausrüstung tragen. Die Maschine nur bei Tageslicht oder guter künstlicher Beleuchtung verwenden.
- Das Terrain beurteilen, um zu bestimmen, welches Zubehör und Zusatzgeräte zur ordnungsgemäßen und sicheren Durchführung der Arbeit notwendig sind. Nur von Jacobsen genehmigtes Zubehör und Zusatzgeräte verwenden.
- Auf Löcher im Boden und andere versteckte Gefahren achten.
- 8. Das Gelände, auf dem die Maschine eingesetzt wird, inspizieren. Vor der Arbeit, wo möglich, jeglichen Schutt beseitigen. Auf Behinderungen über dem Arbeitsbereich (niedrige Baumteile, Stromleitungen usw.) sowie auf unterirdische Hindernisse (Sprinkler, Rohrleitungen, Baumwurzeln usw.) achten. Ein neues Gelände vorsichtig angehen. Immer auf versteckte Gefahren vorbereitet sein.
- Material nie direkt in Richtung umstehender Personen entleeren und auch während des Betriebs niemanden in Nähe der Maschine erlauben. Der Eigentümer/Bediener kann Verletzungen an sich selbst und Umstehenden sowie Sachschäden verhindern und ist für diese verantwortlich.
- 10. Keine Passagiere mitnehmen. Umstehende und Tiere in sicherem Abstand halten.

- Nie Maschinen in Betrieb nehmen, die nicht in perfektem Arbeitszustand sind, oder an denen Aufkleber, Schutzvorrichtungen, Schilder, Entleerungsablenker oder andere Schutzvorrichtungen nicht sicher in Position angebracht sind.
- 12. Niemals irgendwelche Schalter abtrennen oder umgehen.
- Die Einstellung des Motordrehzahlreglers nicht ändern und den Motor nicht bei Übergeschwindigkeit laufen lassen.
- 14. Kohlenmonoxid in den Abgasdämpfen kann bei Einatmung tödlich sein. Den Motor nie ohne ordnungsgemäße Entlüftung oder in geschlossenen Bereichen operieren.
- 15. Kraftstoff ist äußerst entzündlich, mit Sorgfalt handhaben.
- Den Motor sauber halten. Vor dem Lagern den Motor abkühlen lassen und immer den Zündschlüssel herausziehen.
- 17. Vor Anlassen des Motors alle Gänge auskuppeln und die Feststellbremse anlegen. Den Motor nur, wenn Sie im Fahrersitz sitzen und niemals, wenn Sie neben der Maschine stehen, anlassen.
- 18. Die Maschine muss beim Fahren oder Transport auf öffentlichen Verkehrsstraßen die neusten bundesstaatlichen, staatlichen und örtlichen Vorschriften erfüllen. Beim Überqueren von oder Betrieb in Nähe von Straßen auf den Verkehr achten.
- 19. Örtliche Bestimmungen können eine Altersgrenze für den Bediener vorschreiben.
- Nie mit den Händen nach Ölauslaufstellen suchen. Unter Druck stehende Hydraulikflüssigkeit kann in die Haut eindringen und ernsthafte Verletzungen verursachen.
- 21. Die Maschine an Hängen (vertikal) auf- und abwärts und nicht guer (horizontal) über die Fläche einsetzen.
- 22. Um ein Umkippen oder Kontrollverlust zu vermeiden, an Hängen nicht plötzlich starten und stoppen. Beim engen Wenden die Geschwindigkeit verlangsamen. Bei Richtungswechsel vorsichtig sein.
- 23. Beim Betrieb von Traktoren, die mit einem Überrollschutz ausgestattet sind, ist immer ein Sitzgurt zu verwenden.
  - Beim Betrieb von Traktoren ohne Überrollschutz niemals den Sitzgurt verwenden.
- Beine, Arme und Körper innerhalb der Kabine halten, während das Fahrzeug in Bewegung ist.

Diese Maschine muss gemäß der Spezifikationen in diesem Handbuch operiert und instand gehalten werden. Sie ist für professionellen Einsatz gedacht und mit Zusatzgeräten ausgerüstet, die Sandmaterial auf Golfplätzen und Sportplätzen bewegen, glätten und lockern sollen. Sie ist nicht zum Einsatz auf hartem, kompaktierten Boden oder Kies gedacht.

#### 1.2 WICHTIGE HINWEISE ZUR SICHERHEIT



Dieses Warnsymbol wird verwendet, um Sie auf potentielle Gefahren aufmerksam zu machen.

**GEFAHR** - Weist auf eine sofortige Gefahrensituation hin, die einen Todesfall oder eine ernsthafte Verletzung zur Folge **HAT**, falls diese Gefahr nicht verhindert wird.

**ACHTUNG** - Weist auf eine potentiell gefährliche Situation hin, die einen Todesfall oder eine ernsthafte Verletzung zur Folge haben **KÖNNTE**, falls diese Gefahr nicht verhindert wird.

**WARNUNG** - Weist auf eine potentiell gefährliche Situation hin, die evtl. eine kleinere oder geringere Verletzung oder Sachbeschädigung zur Folge haben **KÖNNTE**, falls diese Gefahr nicht verhindert wird. Dieser Hinweis dient evtl. auch dazu, auf unsichere Praktiken aufmerksam zu machen.

Um die Bilder zu verdeutlichen, werden einige Abbildungen in dieser Anleitung mit entfernten oder geöffneten Abschirmungen, Schutzvorrichtungen oder Platten gezeigt. Diese Ausrüstung darf unter keinen Umständen verwendet werden, wenn diese Vorrichtungen nicht sicher an ihrem Platz befestigt sind.



# **ACHTUNG**

Das Verriegelungssystem dieses Traktors bewirkt, daß der Traktor nur angelassen werden kann, wenn das Bremspedal betätigt, der Mäherschalter auf AUS und das Fahrpedal im Leerlauf ist. Wenn der Bediener den Sitz verläßt, ohne die Feststellbremse anzuziehen oder den Mäherschalter auf AUS zu stellen, bewirkt das System ein Abstellen des Motors.

Der Traktor darf NUR betrieben werden, wenn das Verriegelungssystem richtig funktioniert.



# **ACHTUNG**

- 1. Vor Verlassen der Bedienerposition aus irgendeinem Grund:
  - a. Das Fahrpedal auf Leerlauf stellen.
  - b. Alle Antriebe lösen.
  - c. Alle Vorrichtungen auf den Boden senken.
  - d. Die Feststellbremse anziehen.
  - e. Den Motor abstellen und den Zündschlüssel abziehen.
- Hände, Füße und Kleidungsstücke von beweglichen Teilen entfernt halten. Vor dem Reinigen, Einstellen oder Warten der Maschine muß man warten, bis sie vollkommen zum Stillstand gekommen ist.
- 3. Alle Umstehenden oder Haustiere vom Betriebsbereich fernhalten.
- 4. Beifahrer sind nur erlaubt, wenn eigens ein Sitz für sie vorhanden ist.
- 5. Die Mähausrüstung darf nur bedient werden, wenn der Auswurfabweiser sicher an seinem Platz befestigt ist.

Durch Befolgen aller Anweisungen in dieser Anleitung können Sie die Lebensdauer Ihrer Maschine verlängern und eine optimale Leistungsfähigkeit aufrechterhalten. Einstellungen und Wartungsarbeiten müssen immer von einem qualifizierten Techniker vorgenommen werden.

Wenn zusätzliche Informationen oder Dienstleistungen erforderlich sind, wenden Sie sich bitte an Ihren zugelassenen Vertragshändler von Jacobsen, der über die neuesten Methoden zum Instandhalten dieser Ausrüstung informiert wird und einen prompten und effizienten Dienst bereitstellen kann. Bei Verwendung von Teilen, die keine Originalteile oder von Jacobsen genehmigten Teile und Zubehör sind, wird die Garantie ungültig.

### 2.1 PRODUKTIDENTIFIZIERUNG \_\_\_\_\_

Seriennummer ...... Ein Typenschild (siehe unten),
das die Seriennummer enthält, ist
am Rahmen des Traktors
angebracht und befindet sich
rechts vom Bediener direkt über

der hinteren Achse.

Bei der Bestellung von Ersatzteilen oder bei der Anforderung von Wartungsinformationen immer die Seriennummer der Maschine angeben.



Produkt*	EG	Schalldruckpegel am Ohr des	Vibrieren m/s <sup>2</sup>	
FIOUUK	Schallpegel	Bedieners	Arme	Körper
70530	105 dba	90 dba	,755	,026

<sup>\*</sup> Bei Motor bei 2400 U/Min (ohne Last)

#### 2.2 MOTOR

 Marke
 Kubota

 Modell
 V3300 DI-T-E2B

 Pferdestärke
 67 kW @ 2600 U/Min

**Hinweis:** Aufgrund der betrieblichen Einschränkungen und Umweltfaktoren liegt die tatsächliche Dauerleistung wahrscheinlich niedriger als in den technischen Daten angegeben.

Verdrängung ......3,32 Liter

Drehmoment ...... 285 Nm @ 1600 U/Min.

Kraftstoff:

Typ ...... No. 2 Diesel (CUNA NC 630.01)

Leistung ...... Mindestcetanwert 45

Fassungsvermögen .. 151 Liter

Reglereinstellung:

Gashebelanschlag

Ein ...... 2450 U/Min (PTO Aus)

2300 U/Min (PTO Eingelegt)

Gashebelanschlag

Aus ...... 2750 U/Min (nicht EG)

Leerlauf niedrig...... 950 rpm

Schmierung:

Fassungsvermögen.. 14 qts.
Typ...... SAE 15 W40
API-Klassifizierung .. CF 4, CD-II, CE

Luftfilter...... Trockenfilter mit Entlüfterventil

und Wartungsanzeige.

#### 2.3 TRAKTOR \_\_\_\_\_

Rei	tan:
1/61	ıeıı.

Druck ...... 138-152 kPa

Batterie:

Typ ...... Eine wartungsfreie 12-Volt-

Batterie

600 CCA @ -18°C

Gruppe......75DT

Bremsen:

Betriebsbremse ....... Dynamisches Bremsen durch

Zugstromkreis

Feststellbremse...... Mechanische Vorderradtrommel

Handhebelauslösung

Wendehilfe...... Mechanische Vorderradtrommel

Zwei-Pedal-Auslösung

#### Geschwindigkeit:

Mähen....... 0 - 13,6 km/h Transport. (2WD)..... 0 - 29 km/h Rückwärtsfahren (2WD)... 0 - 8,9 km/h Rückwärtsfahren (4WD)... 0 - 4,8 km/h

Produktion ...... 16,5 acres/h bei 14 km/h

#### Hydrauliksystem:

Lenkung...... Hydrostatische Servolenkung

#### 2.4 **GEWICHTE UND MASSE**

Maße:	mm
Länge: vordere Schneidvorrichtung unten	4420
Höhe: Oberer Teil des Lenkrads	
Höhe: Oberer Teil des Überrollschutzes	2388
Breite: Mähposition	5029
Breite: Fahrstellung	2413

Gewichte: kg 

#### SCHNEIDVORRICHTUNGEN

Breite:	
Vordere Schneidvorrichtung	2336 mm
Seitliche Schneidvorrichtungen	1499 mm
Anzahl der Messer:	
Vordere Schneidvorrichtung	5
Seitliche Schneidvorrichtungen	3
Gesamtschnittbreite	2,4 m
Schnitthöhe	25 - 140 mm

Klingengröße ......533 mm Klingenspitzengeschwindigkeit .... 5029 m/Min Reifen: Größe.....Zehn 11 x 4,0 - 5,0 (4-fach) Zwei 13 x 6,50 - 6,0 (4-fach) Druck ...... 138 - 173 kPa

## ZUBEHÖR & UNTERSTÜTZUNGSLITERATUR \_\_\_\_\_

Fordern Sie eine vollständige Liste von Zubehör und Zusatzgeräten von Ihrem Vertragshändler von Jacobsen an.



# **WARNUNG**

Wenn andere Ersatzteile und Zubehör als die von Jacobsen verwendet werden, dann kann dies zu Personenverletzung oder Beschädigung der Einrichtung führen, wodurch die Garantie verfällt.

LuftblaspistoleJAC5098
Oranger Lack (Sprühdose 340 ml) 554598
Überrollschutz mit zwei Pfosten und Sitzgurt 78138
I Allwetterkabine mit
Überrollschutz und SitzgurtSiehe weiter unten
I KlimaanlageSiehe weiter unten
Laubmulchsatz71055
Messer mit hohem Hub4116825
Beleuchtungssatz5003564
Straßenbeleuchtungssatz (5003564 erforderlich) 78154
Arbeitsbeleuchtungssatz (5003564 erforderlich) 78155
Verdeck / Sonnenblende
Lenkgewichte, Hinterrad

Carefree-Reifensatz	2811453
Haubenverriegelung	1004049
Kaltstart-/Vorheizzeitschaltersatz	
Tempomat	67888
u Schneegebläse	Siehe weiter unten
s Drehbesen	Siehe weiter unten
Unterstützungsliteratur	
Sicherheits- und Bedienungshandbuch	3010791
Fine at the House of AM and the size has a sillent about	0040000

Ersatzteil- und Wartungshandbuch......2810223 Ausbildungsvideo für das Bedienungspersonal......5003465 Wartungs- & Reparaturanleitung

Ansprechpartner: Jodale Perry Corporation

Box 990, 300 Route 100

Morden, Manitoba, Canada R6M 1A8

Tel: (204) 822-9100 Fax: (204) 822-9111

◆ Ansprechpartner: Loftness Specialized Equipment, Inc.

South Highway 4 Hector, MN 55342 Tel 800-828-7624 Fax: (320) 848-6269 z.Hd. Doug Haley

▲ Ansprechpartner: M-B Companies, Inc.

1200 S. Park Street, Box 148

Chilton, WI 53014 Tel: (888) 558-5801 Fax: (920) 898-4588

#### ALLGEMEINE INFORMATIONEN

# **ACHTUNG**

Durchführung von Einstellungen Wartungsarbeiten die Vorrichtungen auf den Boden senken, alle Antriebe lösen, die Feststellbremse anziehen, den Motor abstellen und den Zündschlüssel abziehen, um eine Verletzung zu verhindern.

Sicherstellen, daß der Traktor auf einem festen und ebenen Boden geparkt ist. Niemals an einem Traktor arbeiten, der nur durch den Heber gestützt ist. Immer Heberstützen verwenden.

Wenn nur das vordere oder hintere Teil des Traktors angehoben wird, sind die Räder, die nicht angehoben werden, vorn und hinten mit Unterlegekeilen abzusichern.

- 1. Die Einstellungen und Wartungsarbeiten müssen immer von einem qualifizierten Techniker durchgeführt werden. Wenn es nicht möglich ist, die richtige Einstellung vorzunehmen, wenden Sie sich an einen zugelassenen Vertragshändler von Jacobsen.
- Verschlissene oder beschädigte Komponenten nicht einstellen, sondern auswechseln.
- Langes Haar, Schmuck oder lockere Kleidungsstücke könnten sich in den beweglichen Teilen verfangen.



# **WARNUNG**

Darauf achten, daß Hände und Finger nicht zwischen die beweglichen und festen Teile der Maschine.


Nicht die Reglereinstellungen ändern oder den Motor mit zu hoher Drehzahl betreiben.

#### 3.2 AUSGLEICH DER SCHNEIDVORRICHTUNGEN

Wenn die Schneidvorrichtungen oder Schwenkräder zwecks Wartung entfernt wurden oder die Schnitthöhe ungleichmäßig scheint, dann kann es sein, daß die Schneidvorrichtungen abgeglichen werden müssen. Die Schwenkräder so positionieren, daß die Schnitthöhen der Außenmesser innerhalb von 3 mm voneinander sind.

- Den Traktor und die Schneidvorrichtungen auf einer harten, flachen, ebenen Stellfläche positionieren. Die Messer wie abgebildet parallel zum Traktor in Position bringen.
- Prüfen, daß der Reifendruck in allen Schwenkradreifen gleich ist.

- 3. Unter Verwendung der mitgelieferten 13mm Abstandstücke (E) die gewünschte Schnitthöhe der Schneidvorrichtung einstellen. Siehe Abschnitt 3.5.
- Messen Sie die Höhe vom Boden bis zur Vorderkante der beiden äußeren Blätter für (B) Schneidetischausleger und den mittleren Bereich des vorderen Schneidetisches. Der beiden Außenklingen (C) je nach Bedarf 3 mm über oder unterhalb der Schwenkradschwenkung messen, um über die Schneidvorrichtungen eine gleichmäßige Schnitthöhe zu erhalten. Die 1,5 mm Druckscheiben (D) wie abgebildet in Position halten, eine über und eine unterhalb der Schwenkradschwenkung.



#### 3.3 WARTUNG DER VORDEREN SCHNEIDVORRICHTUNG

Die vordere Schneidvorrichtung kann angehoben und gekippt werden, um Zugang zu den Scheineinheiten und Messern zwecks Wartung und Reinigung zur ermöglichen. Hierbei sicherstellen, daß alle Antriebe ausgekuppelt wurden, die Feststellbremse anziehen und den Zündschlüssel herausziehen, bevor an der Vorrichtung gearbeitet wird.

#### Um die Vorrichtung in ihre Wartungsposition zu kippen:

- 1. Den Schwenkschutzmechanismus in die Wartungsposition rotieren **(F)**, er befindet sich unter der linken Bodenplatte; Abb. 3C.
- Den Motor anlassen und die Vorrichtung anheben, bis die hinteren Radstelzen vom Boden abgehoben sind. Den Motor abschalten.
- Die Schnitthöheneinstellstifte von der Radstelzenhalterung entfernen, damit die Jocheinheit frei schwebt.
- Den Motor einschalten und die Vorrichtung in die oberste Position anheben. Den Motor abschalten.
- Die vordere Vorrichtung anheben und rotieren, bis sie sicher eingerastet ist.

# **A** ACHTUNG

Das vordere Mähwerk ist schwer und kann schwere Verletzungen oder Schäden verursachen, wenn es fallen gelassen wird. Zum Heben und Senken des vorderen Mähwerks in die Wartungsposition immer korrekte Hebetechniken verwenden.

Beim Absenken des Mähwerks wird das ganze Gewicht des Mähwerks freigegeben, wenn der Riegel herausgezogen wird. Stellen Sie sicher, dass ein Helfer darüber informiert ist.

#### Absenken des Mähwerks nach Wartungsarbeiten:

- Mähwerk etwas anheben und Riegel (A) herausziehen. Das Mähwerk von Hand absenken, bis es durch die Hubarme gestützt wird. Um Körperverletzungen oder eine Beschädigung des Mähwerks oder der Hubarme zu vermeiden, das Mähwerk NICHT aus der Wartungsposition fallen assen.
- Den Motor anlassen und die Vorrichtung senken, bis die Schwenkräder gerade über dem Boden sind. Den Motor abschalten.
- 3. Die Höheneinstellstifte für die hinteren Schwenkräder entsprechend der Schnitthöhe einsetzen (Abb. 3F).
- 4. Den Schwenkschutzmechanismus **(F)** in seine Betriebsposition rotieren (Abb. 3C).




Abb. 3B




Abb. 3C

### 3.4 EINSTELLUNG DER AUSLEGER \_\_\_

- 1. Die Ausleger müssen am vorderen Schneidetisch ausgerichtet sein, damit das Gerät nicht in den Erdboden greift und die Schneidetischausleger nicht beschädigt werden.
- 2. Bringen Sie die Blätter des vorderen Schneidetischs in die Stellungen gemäß **Abbildung 3A**.
- 3. Messen Sie die Höhe vom Erdboden zur Vorderkante des mittleren Blattes am Vorderdeck (B) und den äußeren Kanten der Blätter auf den Auslegern (L). Setzen Sie je nach Bedarf zwischen der Unterlage (H) und den Befestigungen der Ausleger Ausgleichsscheiben (G) ein bzw. entfernen Sie diese, bis alle Blätter des vorderen Schneidetisches die gleiche Höhe haben.
- 4. Bewahren Sie nicht benötigte Ausgleichsscheiben **(G)** oberhalb der Befestigung auf.

5. Richten Sie die vorderen Stützarme (J) für die Ausleger je nach Bedarf nach oben oder unten aus, bis der Arm am Anschlag (K) aufliegt.




Abb. 3D

### 3.5 SCHNITTHÖHE

Die Schnitthöhe für Schneidvorrichtungs kann von 25 - 125 mm in Stufen von 13 mm verstellt werden. Die tatsächliche Schnitthöhe kann sich von den angegebenen Höhen etwas unterscheiden, was vom Zustand des Rasens und anderen Faktoren abhängig ist.

**Hinweis:** Beim Mähen auf hügeligen Bereichen könnten niedrigere Schnitthöhen evtl. ein Skalpieren der Erde verursachen. Die Höhe entsprechend einstellen, um eine Beschädigung des Rasens zu verhindern.

 Den Traktor auf einem flachen, ebenen Boden abstellen. Die Schneidvorrichtungs anheben, bis die Schwenkräder weit genug vom Boden angehoben sind, damit die Räder vom Schneidvorrichtungs entfernt werden können. Unter den Schneidvorrichtungs Blöcke anbringen, damit sie von allen Seiten gestützt werden.

# **A** ACHTUNG

Zum Verhindern einer ernsthaften Verletzung das Schneidvorrichtungs senken, bis es vollständig auf den Stützen aufliegt. Das verhindert sein versehentliches Senken, während Einstellungen vorgenommen werden. Alle Antriebe lösen, die Feststellbremse anziehen, den Motor abstellen und den Zündschlüssel abziehen.

Zum Entfernen der inneren, vorderen Schwenkräder von den seitlichen Schneidvorrichtungen diese in ihre volle aufrechte Position bringen und in der Transportposition verriegeln.

- Abb. 3E zeigt das Hinweisschild zur Höheneinstellung der Schwenkräder.
  - Spalte: Schnitthöhe
     Spalte: Halterungsposition
  - 3. Spalte: Anordnung der Abstandsstücke

Die angegebene Menge Abstandsstücke einstellen. Zusätzliche Abstandsstücke oben auf der Spindel lagern. Soweit erforderlich, die Radhalterung in den für die Schnitthöhe angezeigten Löchern neu positionieren.

WICHTIG: Die dünnen Druckscheiben (1,5 mm) und Ausgleichsscheiben (3 mm) an der Spindel nicht versetzen. Diese Unterlegscheiben sollten in der gleichen Position und Anzahl bleiben, wie sie ursprünglich installiert wurden. Sie brauchen bei Bedarf nur zum Ausgleich neuer Schwenkräder oder Schneidvorrichtungen neu positioniert werden (Abb. 3.2).

 Zum Einstellen der hinteren Meßräder auf dem vorderen Schneidvorrichtungs siehe Abb. 3F. Die Schneidvorrichtungsflügel ca. 30 cm anheben und darunter mit Blöcken abstützen. Das Schneidvorrichtungs so senken, daß es vollständig auf den Blöcken aufliegt. 4. Den Stift vom hinteren Meßräderrand entfernen und im Träger für die gewünschte Schnitthöhe neu positionieren. Bei Einstellen der Schnitthöhe auf 150 mm muß die Radstelze im Arm neu positioniert werden. Befolgen Sie die entsprechenden Anleitungen auf dem Schild, Abb. 3F.





Abb. 3E



Einstellung des Meßrads für Schneidvorrichtungsflügel

Abb. 3F

#### Reifendruck

Den Reifendruck der Schwenkräder prüfen, während die Reifen kühl sind. Den Druck zwischen 138 - 173 kPa aufrechterhalten, um die Genauigkeit der Schnitthöhe zu verbessern.

Hinweis: Es ist wichtig, den Reifendruck an allen Schwenk-und Meßrädern gleichmäßig im vorgeschriebenen Bereich zu halten, um einen genauen und gleichmäßigen Schnitt zu gewährleisten.

#### 3.6 FESTSTELLBREMSE

Der Bremsschalter ist Bestandteil des Bedienerbackupsystems und stellt fest, wenn die Feststellbremse angezogen wurde. Wenn der Schalter versagt, dann kann die Maschine nicht starten und das Bedienerbackupsystem funktioniert nicht korrekt.

#### Zur Nachstellen des Schalters:

- 1. Die Feststellbremse in ihre ganz aufrechte (angezogene) Position bringen.
- Den Schalter (C) durch Drehen der Schalterbefestigungsklammer (B) nachstellen. Den Sensorbereich am Schalter auf den Bremsengriff abstimmen (D).
- Den Abstand zwischen dem Sensorbereich am Schalter und Bremshebel auf 1,5 - 3 mm einstellen. Zur Anpassung des Abstands Unterlagen (E) oder #10 Unterlegscheiben (F) je nach Bedarf zwischen Schalter und Schalterhalterung verwenden.

 Bei ordnungsgemäßer Installation ist der Schalter geschlossen, wenn die Feststellbremse angezogen und offen, wenn die Bremse freigegeben ist.

**Wichtig:** Nach Austausch oder Nachstellen des Schalters immer das Bedienerbackupsystem überprüfen. (Siehe Sicherheits- und Betriebsanleitung).




Abb. 3G

#### 3.7 LEERLAUFEINSTELLUNG

**Wichtig:** Die Leerlaufeinstellung an der Antriebspumpe wird bei allen neuen Traktoren und Austauschpumpen im Werk eingestellt. Eine weitere Einstellung ist **nur** erforderlich, wenn die Pumpe zur Reparatur oder Wartung demontiert wurde oder die Halterung **(F)** für den Neutralhebel sich gelockert hat.

# Zur Nachstellung der Leerlaufeinstellung an der Pumpe:

- Das Fahrpedalgestänge von der Pumpe entfernen. Die Schaltermontageklammer von der Pumpe entfernen.
- 2. Den Traktor sicher mit Hebern stützen, wobei **alle** Räder vom Boden abgehoben sein müssen.
- 3. Prüfen, ob das Zugventil (H) geschlossen ist.
- 4. Die Schrauben **(G)**, welche die Pumpenrückführarmhalterung halten, gerade soweit lockern, daß sie entfernt werden kann.
- Die Feststellbremse anziehen und den PTO-Schalter auf neutral stellen.

Der Neutralsensorschalter muß geschlossen sein, damit der Traktor gestartet werden kann. Es ist möglich, daß der Schalter an dieser stelle noch nicht an der Pumpe montiert ist. Zum Schließen des Schalters, damit der Motor angelassen werden kann, diesen mit der Oberseite nach unten auf den Metallrahmen legen.

- Den Motor anlassen und die R\u00e4der beobachten. Die Klammer (F) in den Schlitzl\u00f6chern rotieren, bis die R\u00e4der sich nicht drehen. Den Motor abstellen und die Klammer in Position festziehen.
- 7. Die Traktorpedalverbindung verbinden, Abschnitt 3.11 und die Schalter installieren und einstellen, Abschnitt 3.8 und 3.9.
- Den Motor anlassen und den Betrieb des Fahrpedals prüfen. Die Räder dürfen sich nicht drehen, wenn das Pedal in die Neutralstellung zurückkehrt.




Abb. 3H

#### 3.8 NEUTRALSENSORSCHALTER

Der Neutralsensorschalter gehört zum Bedienerbackupsystem. Er dient dazu, das Anfahren des Traktors zu verhindern, wenn sich das Fahrpedal nicht in der Neutralstellung befindet. Wenn dieser Schalter versagt oder nicht korrekt eingestellt ist, dann springt der Traktor nicht an.

- 1. Sicherstellen, daß Antriebspumpe und Fahrpedalverbindung auf neutral eingestellt sind. Abschnitt 3.7 und 3.11.
- Den Schalterzeiger (A) an der Auslöserplatte so positionieren, daß er über Mitte des Sensorbereichs am Schalter ist.
- Den Schalter so einstellen, das der Abstand zwischen Sensorfläche am Schalter und Zeigerende zwischen 1,5 – 3 mm ist. Den Schalter in dieser Position absichern.

4. Nach dem Einstellen die Operation des Backupsystems überprüfen.




Abb. 3I

### 3.9 VORWÄRTSSENSORSCHALTER

Der Vorwärtssensorschalter erlaubt dem Traktor nur dann Vierradantrieb, wenn sich das Fahrpedal in der Vorwärtsposition befindet. Bei Betrieb im Rückwärtsgang öffnet sich der Schalter und schaltet den Traktor auf Zweiradantrieb zurück. Wenn der Vierradantrieb nicht in Operation geht, sollten Einstellung und Operation des Sensorschalters überprüft werden.

- 1. Sicherstellen, daß Antriebspumpe, Fahrpedalverbindung und Neutralsensorschalter auf neutral eingestellt sind, Abschnitt 3.7, 3.11 und 3.8.
- Den Schalter so einstellen, daß der Abstand zwischen der Sensorfläche am Schalter und der Kante der Auslöserplatte zwischen 1,5 – 3 mm ist.
- Den Schalter vom Kabelbaum trennen und über die Schalterleitungen einen Durchgangsmesser anschließen (B). Mit Fahrpedal in der Neutralposition den Schalter zurückschieben, bis er sich öffnet, und dann nach vorne, bis er sich schließt. Den Schalter in dieser Position absichern.
- 4. Bei noch angeschlossenem Durchgangsmesser die Einstellung durch Niederdrücken des Fahrpedals prüfen.

**Schalter geschlossen** – Fahrpedal in Neutral und während gesamtem Vorwärtsbereich des Pedals.

**Schalter offen** – Voller Rückwärtsbereich des Pedals.

Den Schalter an den Kabelbaum anschließen und die Operation des Vierradantriebs prüfen.




Abb. 3J

#### 3.10 HUBGRENZSCHALTER

Die Rotation der Schneidmesser wird durch Grenzschalter kontrolliert, die am Traktorrahmen in Nähe der Hubarme für jede Schneidvorrichtung angebracht sind. Wenn eine Vorrichtung angehoben wird, dann öffnet sich der Schalter und kuppelt automatisch die Schneidmesser aus. Wenn die Vorrichtung gesenkt wird, dann schließt sich der Schalter und die Messer kuppeln ein. Wenn ein Schalter versagt. Dann kuppeln die Messer beim senken nicht ein.

#### Zum Einstellen der Grenzschalter:

- 1. Den Traktor auf einer ebenen Fläche parken.
- Den Traktor anlassen und die Schneidvorrichtungen anheben oder senken, bis die höchste Stelle an der oberen Ecke der Vorrichtung die auf Abbildung 3K angezeigte Höhe erreicht.

- Den Motor abschalten und den Zündschlüssel herausziehen. Die Vorrichtung durch Blöcke abstützen. Hierdurch wird ein versehentliches Senken während des Einstellens vermieden.
- Den Schalter so positionieren, daß der Sensorbereich (C) am Schalter über der Mitte der Führungskante (A) der Auslöserplatte am Hubarm ist.
- 5. Den Abstand zwischen Sensorbereich am Schalter und Auslöserplatte am Hubarm auf 1,5 – 3 mm einstellen. Zur Nachstellung des Abstands am Hubarm Unterlegplatten (D) oder #10 flache Unterlegscheiben (B) zwischen Schalter und Schaltermontage verwenden.

Die Operation der Grenzschalter prüfen. Die Messer müssen aufhören zu rotieren, wenn die Schneidvorrichtungen über die angezeigten Höhen angehoben werden.




Abb. 3K

#### 3.11 FAHRPEDAL

Das Fahrpedal muß so eingestellt sein, daß die Pumpe in der vollen Hubposition ist, wenn das Pedal in der Vorwärtsposition ganz niedergedrückt wird.

- 1. Sicherstellen, daß der Rückführarm (K-Abb. 3H) an der Pumpe auf neutral eingestellt ist, Abschnitt 3.7.
- 2. Das Fahrpedal nach vorne niederdrücken (I), bis es die Bodenplatte berührt, und in dieser Position halten.
- Die Spannschraube (J) nachstellen, bis man spürt, das der Rückführarm auf den internen Pumpenanschlag trifft. Die Stange von dieser Position 2-3 Umdrehungen zurückstellen. Hierdurch wird sicher-gestellt, daß das Zugpedal vor dem Rückführarm seine tiefste Position erreicht.




Abb. 3L

#### 3.12 SPURWINKEL

- 1. Die Räder geradeaus richten.
- 2. Die Kontermuttern (M) an beiden Enden der Spurstange (N) lösen.
- 3. Die Spurstange **(N)** in den richtigen Spurwinkel drehen. Der Spurwinkel darf **X** + 6,3 mm nicht überschreiten. Kontermuttern **(M)** wieder festziehen.




Abb. 3M

### 3.13 LENKANSCHLAGBOLZEN

- Der Lenkspurwinkel muss eingestellt werden, ehe die Anschlagbolzen eingestellt werden. Wenn der Spurwinkel geändert wird, müssen die Anschlagbolzen neu justiert werden.
- 2. Anschlagbolzen (**P und Q**) soweit wie möglich herausdrehen, ohne sie herauszunehmen.
- 3. Das Lenkrad nach rechts drehen, bis der rechte Hinterreifen im Winkel von 45° zur Lenkachse steht. Anschlagbolzen (P) einschrauben, bis der Bolzen die Achse berührt.
- Das Lenkrad nach links drehen, bis der linke Hinterreifen im Winkel von 45° zur Lenkachse steht. Anschlagbolzen (Q) einschrauben, bis der Bolzen die Achse berührt.




Abb. 3N

### 3.14 DREHMOMENTDATEN

# **WARNUNG**

Alle Drehmomente in diesen Tabellen sind ungefähre Wert und nur als Anhaltspunkt gedacht. Sie verwenden diese Drehmomente auf Ihr eigenes Risiko. Jacobsen übernimmt keine Verantwortung für Verluste, Ansprüche oder Schäden, die sich aus der Verwendung dieser Tabellen ergeben. Bei Verwendung eines Drehmomentwertes ist immer äußerste Warnung anzuwenden.

Jacobsen verwendet standardmäßig plattierte Schrauben der Festigkeitsklasse 5, wenn nicht anders angegeben. Beim Anziehen plattierter Schrauben ist der Wert für geschmiert zu verwenden.

	AMERIKANISCHE STANDARDSCHRAUBEN										
GRÖ- SSE	EIN- HEITEN	FESTIGKEITSKLASSE 5		FESTIGKEITSKLASSE 8		GRÖ- SSE	EIN- HEITEN		SKEITS- SSE 5	FESTIG KLAS	
		Geschmiert	Trocken	Geschmiert	Trocken			Geschmi-	Trocken	Geschmi-	Trocken
								ert		ert	
#6-32	in-lb (Nm)	1	20 (2.3)	-	-	7/16-14	ft-lb (Nm)	37 (50.1)	50 (67.8)	53 (71.8)	70 (94.9)
#8-32	in-lb (Nm)	-	24 (2.7)	-	30 (3.4)	7/16-20	ft-lb (Nm)	42 (56.9)	55 (74.6)	59 (80.0)	78 (105)
#10-24	in-lb (Nm)	-	35 (4.0)	-	45 (5.1)	1/2-13	ft-lb (Nm)	57 (77.2)	75 (101)	80 (108)	107 (145)
#10-32	in-lb (Nm)	-	40 (4.5)	-	50 (5.7)	1/2-20	ft-lb (Nm)	64 (86.7)	85 (115)	90 (122)	120 (162)
#12-24	in-lb (Nm)	-	50 (5.7)	-	65 (7.3)	9/16-12	ft-lb (Nm)	82 (111)	109 (148)	115 (156)	154 (209)
1/4-20	in-lb (Nm)	75 (8.4)	100 (11.3)	107 (12.1)	143 (16.1)	9/16-18	ft-lb (Nm)	92 (124)	122 (165)	129 (174)	172 (233)
1/4-28	in-lb (Nm)	85 (9.6)	115 (13.0)	120 (13.5)	163 (18.4)	5/8-11	ft-lb (Nm)	113 (153)	151 (204)	159 (215)	211 (286)
5/16-18	in-lb (Nm)	157 (17.7)	210 (23.7)	220 (24.8)	305 (34.4)	5/8-18	ft-lb (Nm)	128 (173)	170 (230)	180 (244)	240 (325)
5/16-24	in-lb (Nm)	173 (19.5)	230 (26.0)	245 (27.6)	325 (36.7)	3/4-10	ft-lb (Nm)	200 (271)	266 (360)	282 (382)	376 (509)
3/8-16	ft-lb (Nm)	23 (31.1)	31 (42.0)	32 (43.3)	44 (59.6)	3/4-16	ft-lb (Nm)	223 (302)	298 404	315 (427)	420 (569)
3/8-24	ft-lb (Nm)	26 (35.2)	35 (47.4)	37 (50.1)	50 (67.8)	7/8-14	ft-lb (Nm)	355 (481)	473 (641)	500 (678)	668 (905)

	METRISCHE SCHRAUBEN									
GRÖ- SSE	EIN- HEITEN	4.	6	8.8		10.9		12.9		Nicht- kritische Befestigungs -elemente in Aluminium
		Geschmiert	Trocken	Geschmiert	Trocken	Geschmiert	Trocken	Geschmiert	Trocken	
M4	Nm (in-lb)	-	-	_	_	_	_	3.83 (34)	5.11 (45)	2.0 (18)
M5	Nm (in-lb)	1.80 (16)	2.40 (21)	4.63 (41)	6.18 (54)	6.63 (59)	8.84 (78)	7.75 (68)	10.3 (910	4.0 (35)
M6	Nm (in-lb)	3.05 (27)	4.07 (36)	7.87 (69)	10.5 (93)	11.3 (102)	15.0 (133)	13.2 (117)	17.6 (156)	6.8 (60)
M8	Nm (in-lb)	7.41 (65)	9.98 (88)	19.1 (69)	25.5 (226)	27.3 (241)	36.5 (323)	32.0 (283)	42.6 (377)	17.0 (150)
M10	Nm (ft-lb)	14.7 (11)	19.6 (14)	37.8 (29)	50.5 (37)	54.1 (40)	72.2 (53)	63.3 (46)	84.4 (62)	33.9 (25)
M12	Nm (ft-lb)	25.6 (19)	34.1 (25)	66.0 (48)	88.0 (65)	94.5 (70)	125 (92)	110 (81)	147 (108)	61.0 (45)
M14	Nm (ft-lb)	40.8 (30)	54.3 (40)	105 (77)	140 (103)	150 (110)	200 (147)	175 (129)	234 (172)	94.9 (70)

#### ALLGEMEINE INFORMATIONEN

# A ACHTUNG

Vor dem Reinigen, Einstellen oder Reparieren dieser Ausrüstung alle Antriebe lösen, die Vorrichtungen auf den Boden senken, die Feststellbremse anziehen, den Motor abstellen und den Zündschlüssel abziehen. um Verletzungen zu verhindern.

Sicherstellen, daß der Traktor auf einem festen und ebenen Boden geparkt wird. Niemals auf einem Traktor arbeiten, der nur durch den Heber gestützt ist. Immer Heberstützen verwenden.

- 1. Die Einstellung und Wartungsarbeiten müssen immer von einem qualifizierten Techniker durchgeführt werden. Wenn keine ordnungsgemäßen Einstellungen vorgenommen werden können, wenden Sie sich bitte an einen zugelassenen Vertragshändler von Jacobsen.
- Die Ausrüstung regelmäßig überprüfen, Wartungsplan aufstellen und ausführliche Notizen machen.
  - a. Die Ausrüstung sauber halten.

- b. Alle beweglichen Teile müssen immer richtig eingestellt und geschmiert sein.
- Verschlissene oder beschädigte Teile vor dem Betrieb der Maschine auswechseln.
- Den ordnungsgemäßen Stand aller Flüssigkeiten aufrechterhalten.
- Schutzschilder müssen an ihrem Platz bleiben und alle Schrauben müssen fest angezogen sein.
- Reifen müssen immer den richtigen Luftdruck haben.
- 3. Beim Vornehmen Einstellungen der oder Reparaturen keinen Schmuck oder lose Kleidung tragen.
- Die Abbildungen im Ersatzteilkatalog als Hinweis zum Demontieren und erneuten Zusammenbau der Komponenten verwenden.
- Alle gefährlichen Materialien (Batterien, Kraftstoff, Schmiermittel, Gefrierschutzmittel, etc.) örtlichen, Bundes- und Landesgesetz entsprechend wiederverwerten oder entsorgen.

# PRÜFEN DER KLINGEN \_

1. Alle 50 Betriebsstunden, oder immer, wenn die Mähvorrichtung vom Traktor entfernt wird, sind die Klingen sorgfältig zu überprüfen, um sicherzustellen, daß sie in einem guten Betriebszustand sind. Klingen, die Krümmungen (G), Rillen (H) oder Risse (J) aufweisen, müssen ausgewechselt werden.



# WARNUNG

Beim Prüfen der Klingen vorsichtig vorgehen, um ein Einklemmen von Händen oder Fingern zwischen den Enden der Klingen zu vermeiden.



# **ACHTUNG**

**Niemals** versuchen. eine beschädigte geradezubiegen, zu schweißen oder zu reparieren. Eine beschädigte Klinge muß immer ausgewechselt werden.

Jede der oben angegebenen Zustände kann das Abbrechen eines Klingenstücks verursachen, das von der Mähvorrichtung herausgeschleudert werden kann und eine außerordentlich ernsthafte Körperverletzung Umstehenden von oder Sachschäden verursachen könnte.

- Eine gekrümmte Klinge könnte einen mikroskopischen Riß (G) haben. Wenn er sich vergrößert, könnte ein Stück der Klinge abbrechen. Gekrümmte Klingen verursachen außerdem ein Vibrieren und andere Belastungen an der Maschine.
- Staub oder Sand könnte zwischen den Windflügeln und dem flachen Teil der Klinge eine gefährliche Rille in der Klinge (H) verursachen, die schnell anwachsen und einen Riß (J) bilden könnte, wodurch ein Stück der Klinge abbrechen könnte.




Abb. 4A

### 4.3 SCHLEIFEN DER KLINGEN

 Zwischen Messer und Mähergehäuse einen Holzblock positionieren, damit sich das Messer nicht bewegt. Zum Entfernen des Messers die Halteschraube des Messers im Uhrzeigersinn drehen.

# **A** ACHTUNG

An den Klingen der Mähvorrichtung könnten sich scharfe Ränder bilden. Bei der Wartung und Handhabung immer vorsichtig vorgehen.

 Beim Glätten oder Schleifen der Klingen nicht dem ursprünglichen Schleifmuster folgen, wie in (A) gezeigt, sondern neue Schnittränder mit einem Winkel schleifen, wie in (B) gezeigt.

Wenn der maximale Gesamtverlust der Klinge 13 mm erreicht, nicht mehr weiterschleifen, sondern die Klinge auswechseln.



Ein Abschleifen der Klinge über die zulässigen 13 mm hinaus könnte ein Abbrechen der Klingenspitze verursachen, die von der Mähvorrichtung herausgeschleudert werden könnte. In diesem Fall könnte eine außerordentlich ernsthaft Körperverletzung von Umstehenden bzw. ein Sachschaden verursacht werden.

- Sicherstellen, daß von beiden Seiten der Klinge die gleiche Menge Material entfernt wird, um zu verhindern, daß mit einer einseitigen Klinge gearbeitet wird. Eine einseitige Klinge verursacht ein übermäßiges Vibrieren und könnte die Mähmaschine beschädigen.
- 4. Zum Prüfen der Klinge nach dem Schleifen eine Klingenausgleichsvorrichtung verwenden.
- Die Klinge an der Mähvorrichtung anbringen. Die Klingen so anbringen, daß die Schneidkanten (C) in Drehrichtung zeigen, wie in Abb. 4C gezeigt. Abgeschrägte Schneidkanten der Klinge müssen in Richtung Schneidvorrichtungsgehäuse zeigen.

Die mittlere Befestigungsschraube, die die Klinge befestigt, auf ein Drehmoment zwischen 100 und 120 Nm anziehen.




Abb. 4B




Abb. 4C

#### 4.4 MOTOR

WICHTIG: Eine separate Anleitung für den Motor wird vom Motorhersteller mit diesem Traktor geliefert. Diese Anleitung für den Motor genau durchlesen, bis Sie mit dem Betrieb und der Wartung des Motors vertraut sind. Ein Befolgen der Anweisungen des Motorherstellers gewährleistet eine optimale Nutzlebensdauer des Motors. Zum Bestellen einer Ersatzanleitung für den Motor wenden Sie sich bitte an den Motorhersteller.

Das ordnungsgemäße Einfahren eines neuen Motors kann eine bedeutende Auswirkung auf die Leistung und Nutzlebensdauer des Motors haben.

Während der Einfahrperiode empfiehlt Jacobsen folgendes:

 Während der ersten 50 Betriebsstunden muß der neue Motor eine Betriebstemperatur von mindestens 60 °C erreichen, bevor er bei voller Belastung betrieben wird.

- Während der ersten 50 Betriebsstunden den Motorölstand zweimal täglich prüfen. Während der ursprünglichen Einfahrperiode ist ein höherer Ölverbrauch als normal nicht ungewöhnlich.
- 3. Nach den ersten 50 Betriebsstunden das Motoröl und das Ölfilterelement auswechseln.
- 4. Den Ventilator- und Lichtmaschinenriemen prüfen und einstellen.
- 5. Die spezifischen Wartungsabstände sind in Abschnitt 4.23 und in der Anleitung für den Motor angegeben.

Wenn die Einspritzpumpe, Einspritzdüsen oder das Kraftstoffsystem gewartet werden müssen, wenden Sie sich bitte an einen zugelassenen Vertragshändler von Jacobsen.

Hinweis: Der Traktor ist so konstruiert, daß er bei der Voreinstellung des Reglers am wirksamsten funktioniert und schneidet. Die Reglereinstellungen des Motors nicht ändern, oder den Motor mit überhöhter Drehzahl betreiben.

### 4.5 MOTORÖL

Zu Beginn eines jeden Tages vor dem Anlassen des Motors das Motoröl prüfen. Wenn der Ölstand niedrig ist, die Ölfüllerkappe abnehmen und nach Bedarf bis zur Markierung MAX am Pegelstab mit Öl nachfüllen.

Nach den ersten 25 Betriebsstunden und alle 250 Stunden danach einen Ölwechsel durchführen (siehe Motorhandbuch).

Nur Motoröl mit der API-Klassifizierung CD-II, CE, CF-4. verwenden. Komplette Spezifikationen finden sich im Motorhandbuch




Abb. 4D

# 4.6 GERÄUSCHDÄMPFER UND AUSPUFF



Auspuffgase enthalten Kohlenmonoxid, das giftig ist und beim Inhalieren tödlich sein kann.

Der Motor darf **NUR** bei ordnungsgemäßer Lüftung betrieben werden.

Um eine Vergiftung durch Kohlenmonoxid zu verhindern, das komplette Auspuffsystem regelmäßig prüfen und einen fehlerhaften Geräuschdämpfer immer auswechseln. Wenn festgestellt wird, daß sich die Farbe oder der Ton des Auspuffs verändert, ist der Motor sofort abzustellen. Das Problem identifizieren und das System reparieren lassen.

Alle Schrauben des Auspuffverteilers auf ein gleichmäßiges Drehmoment anziehen. Die Auspuffklemmen anziehen oder auswechseln.

#### 4.7 LUFTFILTER

Die Wartungsanzeige täglich prüfen. Das Luftreinigerelement sofort austauschen, wenn der rote Streifen sichtbar wird (A).

Das Element zur Prüfung oder Reinigung nicht entfernen. Ein unnötiges Entfernen des Filters erhöht das Risiko des Eindringens von Staub und anderen Fremdkörpern in den Motor.

Wenn eine Wartung erforderlich ist, zuerst die Außenseite des Filtergehäuses reinigen, dann das alte Element so vorsichtig wie möglich entfernen und entsorgen.

- 1. Die Innenseite des Filtergehäuses vorsichtig reinigen und dabei sicherstellen, daß kein Staub in den Lufteinlaß gelangt.
- 2. Das neue Element überprüfen. Niemals beschädigtes Element oder ein falsches Element verwenden.
- 3. Das neue Element anbringen und sicherstellen, daß es richtig sitzt. Die Anzeige durch Drücken der Taste (B) rücksetzen.
- 4. Die Kappe wieder anbringen und sicherstellen, daß sie das Filtergehäuse vollkommen abdichtet. Der

- Staubabscheider (C) muß nach unten zeigend angebracht sein.
- 5. Alle Schläuche und Luftkanäle überprüfen. Die Schlauchschellen anziehen.




Abb. 4E

#### KRAFTSTOFF 4.8

Den Kraftstoff vorsichtig handhaben, da er leicht entzündlich ist. Einen zugelassenen Container verwenden, dessen Schnabel in den Tankeinfüllstutzen passen muß. Zum Umfüllen des Kraftstoffs keine Dosen und Trichter verwenden.

# ACHTUNG

Niemals bei laufendem oder heißem Motor den Einfüllverschluß vom Kraftstofftank entfernen oder Kraftstoff nachfüllen.

Beim Handhaben von Kraftstoff ist Rauchen verboten. Niemals den Tank in einem Gebäude füllen oder ablassen.

Darauf achten, daß kein Kraftstoff verschüttet wird. Verschütteten Kraftstoff sofort beseitigen.

Niemals Kraftstoffcontainer in der Nähe von Feuer oder Geräten, die Funken erzeugen und somit den Kraftstoff oder die Kraftstoffdämpfe entzünden könnten, handhaben oder lagern.

Den Einfüllverschluß unbedingt wieder anbringen und fest anziehen.

- Den Kraftstofftank des Traktors bis zu 25 mm unter dem Kühlerstutzen füllen.
- · Sauberes und frisches Dieselöl Nr. 2 mit einem Cetanwert von mindestens 45 verwenden. Weitere Informationen befinden sich in der Anleitung für den Motor.
- · Schon beim ersten Anzeichen einer Beschädigung die Kraftstoffleitungen und Schellen müssen ausgewechselt werden.
- Die Lagerung des Kraftstoffes muß den Anforderungen der gültigen Bundes-, Landes- und örtlichen Vorschriften und den Empfehlungen Kraftstofflieferanten gerecht werden.
- Den Tank niemals überfüllen oder leer werden lassen.

Zusätzlich Information zum Kraftstoff findet sich im Motorenhandbuch.

#### 4.9 KRAFTSTOFFSYSTEM

Die spezifischen Wartungsabstände sind in Abschnitt 4.23 enthalten.

#### Siehe Motorenhandbuch für detailliertes Vorgehen.

Vor dem Auswechseln eines Filters das Filtergehäuse und den Bereich um das Filter herum gründlich reinigen. Es darf kein Schmutz in das Kraftstoffsystem eindringen.

Nach dem Entfernen der Kraftstoffilter und -leitungen, oder wenn der Kraftstofftank leer wird, das Kraftstoffsystem entlüften.

#### Auswechseln des Kraftstoffilters:

- Das Kraftstoffventil am Tank schließen und anschließend das vorhandene Filter entfernen und entsorgen.
- 2. Auf die Dichtung eine dünne Schicht Öl auftragen und das neue Filter mit der Hand anziehen.
- Den Kraftstofftank füllen. Das Kraftstoffventil am Tank öffnen und das Filter entlüften (siehe Anleitung für den Motor). Verschütteten Kraftstoff sofort beseitigen.

### 4.10 BATTERIE \_\_\_\_

Unbedingt sicherstellen, daß der Zündschalter auf "Aus" ist und der Zündschlüssel abgezogen ist, bevor man an der Batterie arbeitet.



### WARNUNG

Bei der Arbeit an Batterien immer isolierte Werkzeuge verwenden und eine Schutzbrille und Schutzkleidung tragen. Alle Anweisungen des Batterieherstellers lesen und befolgen.

Die Kabel sicher an den Batterieklemmen anschließen und eine dünne Schicht dielektrisches Silikonfett auf die Klemmen und Kabelenden auftragen, um ein Rosten zu verhindern. Die Entlüftungskappen und Klemmenabdeckungen an ihrem Platz halten.

Kabelenden, Batterie und Batteriepfosten sauber halten.

Die Polarität der Batterie prüfen, bevor die Batteriekabel angeschlossen oder getrennt werden.

- Beim Anbringen der Batterie immer zuerst das ROTE positive (+) Batteriekabel und zuletzt das SCHWARZE negative (-) Erdungskabel anbringen.
- Beim Entfernen der Batterie immer zuerst das SCHWARZE negative (-) Erdungskabel und zuletzt das ROTE positive (+) Kabel entfernen.
- Sicherstellen, daß die Batterie richtig angebracht und am Batterietrog befestigt ist.



# **ACHTUNG**

Batterieständer, Klemmen und Zubehörteile enthalten Blei und Bleiverbindungen; dies sind Chemikalien, von denen dem Staat Kalifornien bekannt ist, dass sie Krebs und Geburtsfehler verursachen. Nach der Handhabung die Hände waschen.

#### 4.11 MIT STARTHILFE ANLASSEN

Bevor man versucht, den Traktor mit Starthilfe anzulassen, den Zustand der leeren Batterie prüfen (siehe Abschnitt 4.10).



# **ACHTUNG**

Batterien erzeugen ein explosions-gefährdetes Wasserstoffgas. Um das Risiko einer Explosion zu reduzieren, ist eine Funkenbildung in der Nähe der Batterie zu verhindern. Das negative Starthilfekabel immer am Rahmen des Traktors mit der entladenen Batterie und von der Batterie entfernt anschließen.

#### Beim Anschließen der Starthilfekabel:

- 1. Den Motor am Fahrzeug mit einer aufgeladenen Batterie abstellen.
- Das ROTE Starthilfekabel an der positiven (+) Anschlußklemme der aufgeladenen Batterie und an der positiven (+) Klemme der entladenen Batterie anbringen.
- Das SCHWARZE Starthilfekabel an der negativen (-) Anschlußklemme der aufgeladenen Batterie und am Rahmen des Traktors mit der entladenen Batterie anschließen.

Nachdem die Kabel angeschlossen wurden, den Motor am Fahrzeug mit der aufgeladenen Batterie anlassen und anschließend den Traktor anlassen.

#### 4.12 AUFLADEN DER BATTERIE



# **ACHTUNG**

Die Batterie in einem gut belüfteten Bereich aufladen. Batterien erzeugen explosionsgefährdete Gase. Um eine Explosion zu verhindern, dürfen keine Flammen in die Nähe der Batterie kommen.

Um eine Verletzung zu verhindern, nicht bei eingeschaltetem Ladegerät in der Nähe der Batterie stehen. Eine beschädigte Batterie könnte explodieren.

1. Den Abschnitt 4.10 einsehen. Spezifische Anweisungen befinden sich in der Anleitung für Batterie und Ladegerät, die gelesen werden muß.

- Wenn immer möglich, die Batterie vor dem Aufladen vom Traktor entfernen. Wenn die Batterie nicht versiegelt ist, prüfen, ob der Elektrolyt die Platten in allen Zellen bedeckt.
- Sicherstellen, daß das Ladegerät auf "Aus" geschaltet ist. Anschließend das Ladegerät, wie in der Anleitung für das Ladegerät angegeben, an den Batterieklemmen anschließen.
- 4. Vor dem Trennen des Ladegeräts von den Batterieklemmen immer das Ladegerät ausschalten.

## 4.13 HYDRAULIKSCHLÄUCHE \_\_\_\_\_



# **ACHTUNG**

Niemals die Hände zum Prüfen auf Öllecks verwenden, um eine ernsthafte Personenverletzung durch heißes, unter Druck stehendes Öl zu verhindern. Zu diesem Zweck Papier oder Pappe verwenden.

Die Kraft der unter Druck entweichenden Hydraulikflüssigkeit kann ein Eindringen unter die Haut bewirken. Wenn diese Flüssigkeit unter die Haut gespritzt wird, muß sie innerhalb von ein paar Stunden von einem Arzt, der mit dieser Art von Verletzung vertraut ist, operativ entfernt werden, da sonst Gangrän verursacht werden könnte.

- Vor dem Prüfen oder Trennen von Hydraulikleitungen oder -schläuchen die Vorrichtungen immer auf den Boden senken, alle Antriebe lösen, die Feststellbremse anziehen, den Motor abstellen und den Zündschlüssel abziehen.
- Sichtbare Schläuche und Rohre täglich prüfen. Auf nasse Schläuche und Ölflecken Ausschau halten. Verschlissene oder beschädigte Schläuche und Rohre vor dem Betrieb der Maschine auswechseln.
- Die Ersatzrohre und -schläuche müssen auf demselben Pfad verlegt werden, wie die vorhandenen. Die Schlauchschellen, Halterung und Verbindungen dürfen nicht an einer anderen Stelle angebracht werden.
- 4. Alle Rohre, Schläuche und Anschlüsse alle 300 Stunden gründlich überprüfen.

WICHTIG: Das Hydrauliksystem kann permanent beschädigt werden, wenn das Öl verschmutzt wird. Vor dem Trennen irgendwelcher Hydraulikkomponenten den Bereich um die Armaturen und die Schlauchenden herum reinigen, damit keine Fremdkörper in das System eindringen.

- Vor dem Trennen irgendwelcher Hydraulikkomponenten den Platz eines jeden Schlauchs markieren, dann den Bereich um die Armaturen herum reinigen.
- b. Beim Trennen der Komponenten bereit sein, Verschlußschrauben oder -kappen an den Schlauchenden und offenen Anschlüssen anzubringen. Dadurch wird verhindert, daß Fremdkörper in das Hydrauliksystem eindringen oder Öl ausläuft.
- c. Vor dem Anziehen sicherstellen, daß die O-Ringe sauber sind und die Schlaucharmaturen richtig sitzen.
- d. Ein Verdrehen des Schlauchs verhindern. Verdrehte Schläuche können ein Lösen der Kuppler verursachen, wenn sich der Schlauch während des Betriebs verbiegt, was Öllecks zur Folge hat.
- e. Abgeknickte oder verdrehte Schläuche können den Durchfluß des Öls einschränken, was zu einer Funktionsstörung des Systems, zu einem Überhitzen des Öls und zu einem Ausfall des Schlauchs führt.

### 4.14 HYDRAULIKÖL

Die spezifischen Wartungsabstände sind in Abschnitt 4.23 angegeben.

Nach dem Ausfall einer Hauptkomponente, oder wenn das Vorhandensein von Wasser oder Schaum im Öl, oder ein ranziger Geruch festgestellt wird (was ein Anzeichen auf übermäßige Hitze ist), das Hydrauliköl ablassen und neu auffüllen.

Beim Ölwechsel auch immer das Hydraulikfilter auswechseln.

#### Hydraulikölwechsel:

 Den Bereich um den Öleinfüllverschluß herum reinigen, um zu verhindern, daß Fremdkörper in das System eindringen und es verschmutzen.

- 2. Die Ölablaßschraube vom Boden des Haupttanks entfernen.
- Wenn das Öl abgelaufen ist, die Ölablaßschraube wieder anbringen und Hydrauliköl von Jacobsen einfüllen.
- 4. Die Luft vom System ablassen.
  - a. Ca. 5 Minuten lang alle Traktorfunktionen durchführen, um die Luft vom System zu entfernen und den Ölstand zu stabilisieren. Dabei ertönt eventuell der Ölstandsalarm.
  - b. Wenn sich der Ölstand stabilisiert hat und die Luft entfernt ist, den Tank bis zur Markierung 'voll' am Ölmeßstab füllen. Den Motor anlassen und prüfen, ob der Ölalarm ausgeschaltet bleibt.

#### 4.15 HYDRAULIKFILTER

Das Hydrauliksystem wird durch zwei Filter mit 10 Mikron geschützt: dem Hauptstromfilter (B) und Rückleitungsfilter (A). Während des Betriebs wird der Durchfluß durch die Filter überwacht. Wenn der Druckabfall quer über die Filter zu hoch ist, leuchtet die Warnlampe Hydraulikölfilter auf. Um fortlaufenden Schutz des Hydrauliksystems zu gewährleisten, die Filter sobald wie möglich austauschen, wenn die Lichtanzeige auch dann noch eingeschaltet bleibt, wenn sich die Hydraulikflüssigkeit erwärmt hat.

**Hinweis:** Bei kaltem Wetter leuchtet evtl. die Warnlampe auf, bis sich das Öl zur Betriebstemperatur erwärmt hat. Warten, bis das Öl erwärmt ist und die Lampe erlischt, bevor der Traktor betrieben wird.

#### Auswechseln der Hydraulikfilter:

Die Filter einmal pro Jahr bei Wechsel der Hydraulikflüssigkeit austauschen, oder dann, wenn die Filterwarnlampe am Armaturenbrett sich nicht ausschaltet.

Der Rückleitungsfilter befindet sich links vom Ölkühler. Der Hauptstromfilter befindet sich im unteren Teil des Traktorgestells hinter dem linken seitlichen Hubarm.

- 1. Die alten Filter entfernen.
  - **Hinweis:** Beim Entfernen des unteren Hauptstromfilter läuft etwas Hydraulikflüssigkeit ab. Vor dem Ausbau eine Auffangwanne unter den Filter stellen.
- 2. Neue Filter anbringen. Nur mit der Hand anziehen.

- 3. Mit dem Motor im Leerlauf und dem Hydrauliksystem auf neutral fünf Minuten lang betreiben. Dabei ertönt evtl. der Ölstandsalarm.
- 4. Den Hydraulikölstand im Behälter prüfen und bis zur Markierung 'voll' am Ölmeßstab füllen.

## 4.16 KÜHLER & ÖLKÜHLER

# A

# **ACHTUNG**

Niemals versuchen, bei laufendem Motor den Kühlerdeckel zu entfernen, um eine ernsthafte Körperverletzung durch heiße Kühlflüssigkeit oder Dampfausbruch zu verhindern. Den Motor abstellen und warten, bis er kühl ist. Auch dann ist beim Entfernen des Deckels noch extreme Vorsicht geboten.

# A

# WARNUNG

Kein kaltes Wasser in einen heißen Kühler gießen und den Motor nicht ohne richtige Kühlflüssigkeitsmischung betreiben. Den Deckel wieder anbringen und fest anziehen.

Den Kühlmittelstand täglich prüfen. Der Kühler muß voll sein und die Auffangflasche muß bis zur Markierung 'Max.' voll sein.

Wenn Sie mehr als einmal im Monat Kühlflüssigkeit nachfüllen oder jedesmal mehr als ein Viertel zufüllen müssen, dann sollten Sie das Kühlsystem von einem Händler von Jacobsen überprüfen lassen.

Jährlich ablassen und wieder auffüllen. Den Kühlerdeckel entfernen, den Motorblockabfluß und Kühlerabfluß öffnen. Die Auffangflasche leeren und reinigen.

Sauberes Wasser mit Gefrierschutzmittel auf Ethylenglykolbasis für die kälteste Umgebungstemperatur mischen. Die Anweisungen auf dem Behälter des Gefrierschutzmittels und in der Anleitung für den Motor lesen und befolgen.

Die Luftleitungen des Kühlers und Hydraulikölkühlers sauber halten. Zum Reinigen der Lamellen Druckluft (maximal 208 kPa) verwenden.

#### Vorderer Kühlergrill

Den vorderen Kühlergrill **(B)** täglich prüfen und nach bedarf säubern, um Grasreste, Blätter oder andere Abfallstoffe, die den Luftstrom durch den Ölkühler und den Kühler behindern, zu entfernen.

Zur Abnahme des Grills die Endkappe (A) von der linken Seite des Ölkühlers abnehmen. Den Grill seitlich herausschieben und von hinten mit Druckluft durchblasen.

#### Ölkühler und Kühler

Den Ölkühler und Kühler täglich überprüfen und nach Bedarf reinigen, um einen guten Luftstrom zu erhalten.

- 1. Den Grill (B) vorne am Kühler abnehmen.
- 2. Die Knöpfe **(C)** oben am Ölkühler lösen und die Plastikplatte vorne am Ölkühler abnehmen.
- 3. Die Stützstange (D) unten am Kühler freigeben und die Hydraulikleitung nach vorne bringen, damit der Schlauch sich frei bewegen kann. Den Kühler wie abgebildet nach oben und vom Hauptkühler wegschwenken (E). Die Stützstange in das Loch im Gestell einstecken, damit der Ölkühler in seiner Wartungsposition abgesichert wird.
- 4. Mit einer Luftpistole den Grill und die Ölkühlerrippen reinigen.
- Nach dem Reinigen den Ölkühler wieder vor den Hauptkühler schwenken. Die Stützstange unten absichern (D), damit sie die dahinter verlaufende Hydraulikleitung in Position hält.
- 6. Den vorderen Grill und die Platten wieder anbringen, die Knöpfe oben am Ölkühler einsetzen, um die Einheit in Position abzusichern. schwenken.




Abb. 4F

### 4.17 PFLEGE UND REINIGUNG

Den Traktor und die Vorrichtungen nach jedem Gebrauch abwaschen. Die Ausrüstung sauber halten.

**Hinweis**: Keinen Teil der Ausrüstung abwaschen, wenn sie heiß ist. Keine Hochdruckspritzvorrichtung oder Dampf verwenden. Kaltes Wasser und ein Autoreinigungsmittel verwenden.

- Zum Reinigen des Motors und der Kühlerlamellen Druckluft verwenden. Eine Spezialspritzvorrichtung ist vom Vertragshändler von Jacobsen erhältlich.
- Verwenden Sie zur Reinigung der Geräte nur frisches Wasser.

Hinweis: Salzwasser oder Brauchwasser beschleunigt bekanntlich das Rosten und die Korrosion der Metallteile, wodurch Abnutzungserscheinungen oder Störungen vorzeitig auftreten. Schäden dieser Art sind von der Werksgarantie ausgeschlossen.

 Wasser nicht direkt auf das Instrumentenbrett, den Zündschalter, die Regler oder irgendwelche anderen elektrischen Komponenten, oder auf das Lagergehäuse und die Dichtungen spritzen.  Alle Kunststoff- oder Gummileisten mit einer milden Seifenlösung reinigen, oder dazu im Handel erhältliche Reinigungsmittel für Vinyl bzw. Gummi verwenden.

Beschädigte Metalloberflächen reparieren und Ausbesserungslack von Jacobsen verwenden. Zum optimalen Schutz des Lacks die Ausrüstung mit Wachs einreiben.



# WARNUNG

Zur Brandverhinderung Gras und Abfälle von den Schneidvorrichtungen, Antrieben, Schalldämpfern und vom Motor entfernen.



# **ACHTUNG**

**NIEMALS** die Schneidvorrichtungen mit den Händen reinigen. Zum Entfernen von geschnittenem Gras von den Klingen eine Bürste verwenden. Die Klingen sind extrem scharf und können ernsthafte Verletzungen verursachen.

### 4.18 ELEKTRISCHES SYSTEM



## **WARNUNG**

Vor der Prüfung des elektrischen Systems oder bevor man daran arbeitet, immer den Zündschalter auf AUS stellen und das negative Batteriekabel (schwarz) entfernen.


Es folgen allgemeine Vorsichtsmaßnahmen, die zum Reduzieren von Problemen mit dem elektrischen System getroffen werden können.

- Sicherstellen, daß alle Anschlußklemmen und Verbindungen sauber und richtig befestigt sind.
- 2. Das Bedienerschutzsystem und die Stromkreisunterbrecher regelmäßig prüfen.

Wenn das Bedienerschutzsystem nicht richtig funktioniert und das Problem nicht berichtigt werden kann, wenden Sie sich an einen zugelassenen Vertragshändler von Jacobsen.

- Den Kabelbaum und alle einzelnen Drähte von beweglichen Teilen fernhalten, um eine Beschädigung zu verhindern.
- 4. Sicherstellen, daß der Kabelbaum des Sitzschalters am Hauptkabelbaum angeschlossen ist.
- 5. Die Batterie und den Batterieladekreis prüfen.
- 6. Die elektrischen Anschlüsse und Komponenten nicht waschen oder unter Druck abspritzen.

Die Schaltkreise werden durch einen Leistungsschalter (befindet sich über den Batterien), sowie Sicherungen und Relais unter dem Armaturenbrett geschützt. (Siehe Abb. 4G und Tabelle).



F1 5A Ersatz F2 5A Ersatz

**F3** 15A Ersatz **F4** 15A Ersatz

F4 15A Ersatz F5 5A Zündung

F6 5A MeßeinrichtungenF7 5A Kraftstoffmagnetventil,

Zündkerzen

F8 15A SitzluftsystemF9 5A Fahrtregler

F10 5A 4-Radantr.-Magnetventil


F11 5A Schneidvorrichtungsgrenzschalter

F12 15A Schneidvorrichtungsventil

Abb. 4G

Tabelle identifiziert Standort und Grundfunktionen der elektrischen Relais unter dem Armaturenbrett. Genauere Information findet sich auf dem Schaltplan in diesem Handbuch.

#### Nach Wartung der Elektroanlage immer das Bedienerbackupsystem überprüfen!



### 4.19 REIFEN

# **A** WARNUNG

NICHT versuchen, einen Reifen auf einem Felgen anzubringen, außer wenn Sie dazu die richtige Ausbildung und Erfahrung sowie die richtigen Werkzeuge haben. Eine nicht ordnungsgemäße Montage kann eine Explosion verursachen, die eine ernsthafte Verletzung zur Folge haben könnte.

 Reifen müssen jederzeit richtig mit Luft gefüllt sein, um ihre Nutzlebensdauer zu verlängern. Den Reifendruck prüfen, während die Reifen kühl sind. Das Profil auf Verschleiß überprüfen.

- 2. Den Druck jährlich prüfen. Dazu einen genauen Niedrigdruck-Luftdruckprüfer verwenden.
- 3. Achten Sie auf den richtigen Reifendruck:

Traktor: 138 -152 kPa

Schneidetische: 138 -173 kPa

### 4.20 VERFAHREN ZUR RADMONTAGE\_

#### Traktorräder



Sicherstellen, daß der Traktor immer auf einem festen und ebenen Boden geparkt wird. Niemals an einem Traktor arbeiten, der nur durch den Heber gestützt ist. Immer Heberstützen verwenden.

Wenn nur das vordere oder hintere Teil des Traktors angehoben wird, sind die Rädern, die nicht angehoben werden, vorn und hinten mit Unterlegekeilen abzusichern.

- Schmutz, Schmiere und Öl vom Gewinde der Stiftschraube entfernen. Das Gewinde darf nicht geschmiert werden.
- Das Rad an der Radnabe anbringen und sicherstellen, daß ein vollständiger Kontakt zwischen der Montagefläche des Rads und der Nabe oder Bremstrommel besteht.
- Alle Schrauben handfest anziehen, und anschließend in Zickzack-Reihenfolge auf das entsprechende Drehmoment anziehen. Die Muttern immer in der oberen Position anziehen.

**HINWEIS:** Die Schrauben während der ersten 100 Betriebsstunden täglich überprüfen und nachziehen.

 Nach Anbau einer neuen Einheit oder nach Abnahme der Reifen sind die Schrauben täglich zu überprüfen und nachzuziehen, bis das Drehmoment von 88-102 Nm erhalten bleibt.

#### Schwenkräder

Zur Verlängerung der Lebensdauer der Lager die Schwenkräder und Radstelzen jährlich überprüfen. Die

Lager alle 100 Stunden unter Verwendung von Fett NLGI Klasse 2 schmieren.

- Die Schneidvorrichtung anheben, damit sich die Räder vom Boden abheben und mit der Hand frei rotiert werden können.
- 2. Die Räder auf Endspiel prüfen (I). Die Räder sollten frei und ohne jegliches Endspiel rotieren.
- Zur Eliminierung von Endspiel die innere Mutter (G) festziehen, bis das Rad gerade eben anstreift, und dann um eine ¼ Drehung lockern. Die Innenmutter mit Hilfe der Außenmutter in Position absichern (H). Beim Festziehen der Außenmutter darauf achten, daß sich die Innenmutter nicht dreht.
- 4. Schritt 2 wiederholen und auf Endspiel prüfen.




Abb. 4H

### 4.21 ÜBERROLLSCHUTZ

Ein für diesen Traktor konstruierter Überrollschutz ist wahlweise erhältlich. Wenn Ihr Traktor mit dieser Vorrichtung ausgestattet ist, muß sie regelmäßig überprüft und die in der Sicherheits- und Bedienungsanleitung beschriebenen Betriebsverfahren befolgt werden

# WARNUNG

Keine Schrauben lösen oder entfernen. Eine beschädigte Struktur darf weder geschweißt, gebohrt, geändert, gebogen noch geradegerichtet werden.

- 1. Sitz, Sitzgurt, Befestigungsschrauben und das gesamte Zubehör im Überrollschutz müssen regelmäßig geprüft und alle beschädigten Teile sofort ausgewechselt werden.
- Sobald der Überrollschutz irgendeiner Form von Aufprall ausgesetzt war, muß er ausgewechselt werden. Alle Schrauben prüfen und wieder mit dem entsprechenden Drehmoment anziehen. Alle am Überrollschutz verwendeten Ersatzteile müssen wie im Ersatzteilkatalog angegeben sein.
- Alle Schrauben prüfen und wieder mit dem entsprechenden Drehmoment anziehen. Alle am Überrollschutz verwendeten Ersatzteile müssen wie im Jacobsen Ersatzteilkatalog angegeben sein.

#### 4.22 LAGERUNG

#### **Allgemeine Informationen**

- Den Traktor gründlich waschen und schmieren. Beschädigtes und freigelegtes Metall reparieren und lackieren.
- Den Traktor überprüfen, alle Schrauben anziehen, verschlissene oder beschädigte Komponenten auswechseln.
- 3. Den Kühler ablassen und wieder auffüllen.
- Die Reifen gründlich reinigen und den Traktor so abstellen, daß die Last von den Reifen entfernt ist. Wenn sich der Traktor nicht auf Heberstützen befindet, muß der Reifendruck in regelmäßigen Abständen geprüft und, soweit erforderlich, Luft nachgefüllt werden.
- Die Maschine und das gesamte Zubehör an einem sauberen, trockenen und vom Wetter geschützten Ort lagern. Die Ausrüstung niemals in der Nähe von offenen Flammen oder Funken, die den Kraftstoff oder die Kraftstoffdämpfe entzünden könnten, lagern.

#### **Batterie**

- Die Batterie entfernen, reinigen und aufrecht an einem kühlen und trockenen Ort lagern.
- 2. Die Batterie prüfen und während der Lagerung alle 60 bis 90 Tage aufladen.
- Die Batterien an einem kühlen und trockenen Ort lagern. Um die Selbstentladungsrate zu reduzieren, darf die Raumtemperatur 27 °C nicht überschreiten oder unter -7 °C abfallen, um ein Gefrieren des Elektrolyts zu verhindern.

#### Motor

1. Während der Motor warm ist, die Verschlußschraube entfernen, das Öl vom Kurbelgehäuse ablassen und das Ölfilter auswechseln. Die Verschlußschraube wieder anbringen und mit frischem Öl auffüllen. Die Verschlußschraube auf ein Drehmoment von 30 Nm anziehen.

- 2. Den äußeren Bereich des Motors reiniaen. Freigelegtes Metall lackieren oder eine dünne Schicht Rostschutzöl auftragen.
- Ein Kraftstoffreinigungs- oder Biozidmittel in den Kraftstoff geben, um eine Gelbildung oder ein Bakterienwachstum zu verhindern. Wenden Sie sich dazu bitte an Ihren örtlichen Kraftstofflieferanten.

#### Schneidvorrichtungen

- Die Schneidvorrichtungen gründlich waschen, dann alle beschädigten und freigelegten Metallteile reparieren oder lackieren.
- Alle Schmierstellen und Reibungspunkte schmieren.
- Eine dünne Schicht Rostschutzöl auf die scharfen Messerkanten auftragen.

#### Nach der Lagerung

- Die Batterie überprüfen und wieder anbringen.
- Das Kraftstoffilter und Luftfilter überprüfen oder warten.
- Den Kühlflüssigkeitsstand im Kühler prüfen.
- Den Ölstand im Kurbelgehäuse des Motors und im Hydrauliksystem prüfen.
- Den Kraftstofftank mit frischem Kraftstoff auffüllen. Das Kraftstoffsystem entlüften.
- Sicherstellen, daß die Reifen richtig mit Luft gefüllt sind.
- Alles Öl von den Schneidzylindern und vom Grundmesser entfernen. Das Grundmesser und die Schnitthöhe einstellen.
- 8. Den Motor anlassen und bei Halbgas betreiben. Warten, bis der Motor richtig erwärmt und geschmiert



Bedienen Sie den Motor nie ohne gut funktionierende Lüftung, denn ein Einatmen der Auspuffgase kann tödliche Folgen haben.

#### 4.23 WARTUNGSPLAN

# **A** ACHTUNG

Vor dem Reinigen, Einstellen oder Reparieren dieser Ausrüstung alle Antriebe lösen, die Vorrichtungen auf den Boden senken, die Feststellbremse anziehen, den Motor abstellen und den Zündschlüssel abziehen, um Verletzungen zu verhindern.

Zum reibungslosen Betrieb aller Hebel, Drehpunkte und anderen Reibungsstellen, die nicht auf dem Schmierplan angegeben sind, alle 50 Stunden oder bei Bedarf mehrere Tropfen Öl SAE30 auftragen.

Die Räder entfernen und das Lager einmal pro Jahr neu packen.

#### Empfohlene Wartungs- und Schmierabstände


	Täglich vor dem Arbeits beginn	Alle 25 Std.	Alle 50 Std.	Alle 100 Std.	Alle 250 Std.	Jährlich	Siehe Abschn	Schmier mitteltyp
Luftreinigeranzeige	I						4.7	
Luftreinigerelement			R-AR			R	4.7	
Batterie				I-C		I-C	4.10	
Schwenkradlager		Α*		L		I-A	4.20	I
Motorkeilriemen		*		I-A			**	
Motoröl	I-A	R*			R		4.5	III
Motorölfilter		R*			R		4.5	
Kraftstoffilter						R	4.9	
Wasser vom Kraftstoffilter ablassen				С			**	
Schmiervorrichtungen - F1			L				4.24	II
Schmiervorrichtungen - F2				L			4.24	II
Hydraulikflüssigkeit	I-A					R	4.14	IV
Hydraulikflüssigkeitsfilter			R-AR		+	R	4.15	
Ölkühler	I-C***						4.16	
Kühlergitter	I-C						4.16	
Kühlerkühlmittel	I-A					R	4.16	
Reifen	<b> </b> ****					I-A	4.19	

A - Hinzufügen oder nachstellen C - Reinigen I - Inspizieren L - Schmieren R - Austauscheb AR - nach Bedarf

ı

- \* Zeigt erste Wartung für neue Maschinen an.
- \*\* Siehe Motorhandbuch.
- \*\*\* Nach Bedarf reinigen.
- \*\*\*\* Drehmoment der Radbolzen während der ersten 100 Betriebsstunden täglich prüfen.
- Die Lager mit NLGI Klasse 2 ausfüllen (Wartungsklasse LB).
- II Manuelles Schmieren mit Schmierpistole mit NLGI Klasse 2 (Wartungsklasse LB).
- III Motoröl siehe Abschnitt 4.5.
- IV Jacobsen Hydrauliköl VG ISO 68.

# 4.24 SCHMIERTABELLE \_



### Position der Schmiereinrichtungen

	50 Stunden e Woche)	Menge	9	Achselschenkel Radschenkel	(1) (2)
1 2 3	Schwenkradspindeln Schwenkradachsen Radstelzenachsen	(10) (10) (2)	11 12	Hubarm – seitl. Schneidvorrichtung Hubzylinder – seitl. Schneidvorrichtung	(2) (4)
4	Hubzylinder – vordere Schneidvorrichtung	(4)	F2 -	150 Stunden	Menge
5 6	Hubarm- vordere Schneidvorrichtung Schenkel, seitliche	(2)	13 14 15	Antriebswellen-U-Gelenk Antriebswellengleitgelenk Rückführkannisterdrehun	` '
7 8	Schneidvorrichtungen Lenkzylinder Zugstange	(6) (2) (2)	13	raoma mai ilisterare ilan	y (0)

# 5.1 ALLGEMEINE INFORMATIONEN \_\_\_\_\_

Die folgende Fehlersuchtabelle listet die grundsätzlichen Probleme auf, die beim Anlassen und Betrieb entstehen können. Ausführlichere Informationen über das Hydraulik- und elektrische System erhalten Sie vom Vertragshändler von Jacobsen Dealer an Ihrem Ort.


Symptome		Mögliche Ursachen		Maßnahme
Der Motor springt	1.	Feststellbremse gelöst oder PTO-	1.	Das Bedienerschutzsystem und das Anlaßverfahren
nicht an.		Schalter eingeschaltet.		prüfen.
	2.	Die Glühkerze hat sich nicht abgeschaltet.	2.	Den Zündschalter rücksetzen und die Glühkerze abschalten lassen, bevor der Motor angekurbelt wird.
	3.	Die Batterie ist nur schwach aufgeladen oder fehlerhaft.	3.	Den Zustand der Batterie und die Batterieanschlüsse prüfen.
	4.	Der Kraftstofftank ist leer oder schmutzig.	4.	Mit frischem Kraftstoff auffüllen. Das Kraftstoffilter auswechseln. Die Kraftstoffleitungen entlüften.
	5.	Die Sicherung ist durchgebrannt.	5.	Neue Sicherung anbringen.
	6.	Relais defekt.	6.	Das Relais testen und auswechseln.
	7.	Fahrpedal nicht in Neutralstellung.	7.	Pedalposition prüfen. Verbindung nachstellen.
	8.	Neutralschalter an der Antriebspumpe funktioniert nicht.	8.	Schalter testen, nachstellen oder austauschen.
	9.	Vorwärtssensorschalter an der Antriebspumpe funktioniert nicht.	9.	Schalter testen, nachstellen oder austauschen.
Der Motor läßt sich nur schwer anlassen oder er läuft ungleich-mäßig.	1.	Der Kraftstoffstand ist niedrig, der Kraftstoff oder das Kraftstoffilter ist verschmutzt.	1.	Mit frischem Kraftstoff füllen. Das Kraftstoffilter auswechseln. Die Kraftstoffleitungen entlüften.
	2.	Das Luftfilter ist verschmutzt.	2.	Das Luftfilter prüfen und auswechseln.
	3.	Einspritzdüsen, Kraft-stoffpumpe.	3.	Das Handbuch für den Motor einsehen.
	4.	Problem mit dem Motor.	4.	Das Handbuch für den Motor einsehen.
Der Motor stirbt ab.	1.	Der Kraftstofftank ist leer.	1.	Mit frischem Kraftstoff füllen und die Kraftstoffleitungen entlüften.
	2.	Die gegenseitige Verriegelung wurde vor Verlassen des Fahrersitzes nicht eingestellt.	2.	Die Feststellbremse anziehen und den Mähschalter auf AUS stellen.
Der Motors überhitzt sich.	1.	Der Kühlmittelstand ist niedrig.	1.	Prüfen und ein Kühlmittel nachfüllen.
	2.	Der Lufteinlaß ist blockiert.	2.	Den Lufteinlaß am Kühler reinigen.
	3.	Der Riemen der Wasserpumpe ist	3.	Den Riemen anziehen oder auswechseln. Siehe
		abgerissen oder locker.		Motorhandbuch.
Die Batterie bleibt nicht aufgeladen.	1.	Die Batterieklemmen sind lose oder verrostet.	1.	Die Batterieklemmen prüfen und reinigen.
Die Batterieanzeige ist erleuchtet.	2.	Der Elektrolytstand ist niedrig.	2.	Auf den richtigen Stand füllen.
	3.	Der Lichtmaschinenriemen ist lose oder abgerissen.	3.	Den Riemen anziehen oder auswechseln. Siehe Motorhandbuch.
	4.	Das Ladesystem ist fehlerhaft.	4.	Das Handbuch für den Motor einsehen.
Die Schneidzylinder schneiden ungleichmäßig.	1.	Die Schnitthöhe ist nicht gleichmäßig eingestellt.	1.	Prüfen, daß die Schneideinrichtungen auf gleicher Höhe sind. Die Schnitthöhe prüfen und einstellen.
	2.	Die Motordrehzahl ist zu niedrig.	2.	Motordrehzahl prüfen, wenn Gashebel auf Schnell steht.
	3.	Die Mähgeschwindigkeit ist nicht dem Rasenzustand entsprechend eingestellt.	3.	Die Mähgeschwindigkeit für den optimalen Schnitt einstellen.
	4.	Der Luftdruck in den Schwenkrädern ist nicht richtig eingestellt.	4.	Den Reifendruck prüfen und auf den richtigen Druck bringen.


# 1.1 TABLE OF CONTENTS\_\_\_\_\_

Body	
1.1 Decals-Tractor	32
2.1 Hood	34
3.1 Cowlings and Skirts	36
4.1 Seat Pan and Heat Shield	
Tanks	40
5.1 Control Panel Mounting	40
Controls	
6.1 Instrument Panel	42
7.1 Throttle Cable	44
8.1 Lift Valve and Controls	46
9.1 Accelerator Pedal	48
10.1 Steering Assist	50
11.1 Parking Brake	
<u> </u>	-
Frame	- 4
12.1 Frame	
13.1 Frame With ROPS	
14.1 Steering Axle	
15.1 Steering Axle Installation	
16.1 Battery Tray	
17.1 Tilt Steering	62
Engine and Radiator	
18.1 Radiator	64
19.1 Oil Cooler	66
20.1 Air Cleaner and Muffler	
21.1 Remote Engine Oil Filter	
22.1 Engine Mounting	
23.1 Engine and Pump Assembly	
	74
Tanks	
3	
25.1 Fuel Tank	78
Traction Pump	
26.1 Pump and 4WD Valve Mounting	80
27.1 Pump Assembly	
Lift Arms and Deck Valves	
	82
28.1 Front Lift Arms and Cylinders	-
29.1 Front Deck Latch	84
30.1 Side Lift Arms	
31.1 Side Lift Cylinders and Return Canisters	88
32.1 Front Deck Valves	90
33.1 Wing Deck Valves	91
Hydraulics and Electrical	
34.1 Side Deck Valve Supply	92
35.1 Front Deck Valve Supply	93
36.1 Pump Supply	94
37.1 Return Manifold	95
38.1 Traction Hydraulics	96
39.1 Return Hydraulics	98
· · · · · · · · · · · · · · · · · · ·	90 100
·	100
<u> </u>	101 102
72. 1 Liit vaive i iyulaullos	102

43.1 Power Steering Hoses	104
44.1 Engine Compartment Clamps	106
45.1 Wire Harness Routing	107
Components	
46.1 Steering Valve	108
47.1 Air Suspension	110
48.1 Seat Assembly	112
49.1 Steering Cylinder	113
50.1 Rear Wheel Motor	114
51.1 Deck Return Canister	115
52.1 Lift Valve	116
53.1 Front Lift Cylinder	118
54.1 Wing Lift Cylinders	119
55.1 Deck Valve	120
56.1 4WD Valve	121
Decks	
57.1 Decals - Decks	122
58.1 Front Deck	124
59.1 Front Deck Center Section	126
60.1 Front Deck Winglets	128
61.1 Front Deck Hydraulics	130
62.1 Wing Decks	132
63.1 Wing Deck Hydraulics	134
64.1 Caster Assemblies	136
65.1 Wheel and Tire Assemblies	137
66.1 Gage Wheels and Latch	138
Schematics	
67.1 Hydraulic Schematic	140
67.1 Hydraulic Schematic	142
67.1 Hydraulic Schematic	

# 1.1 Decals-Tractor






Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	360053	1	Decal, Brake	
2	3008521	1	Decal, Traction	
3	2812396	1	Decal, Towing Caution	
4	365956	1	Decal, Radiator Cap Warning	
5	3001435	1	Decal, Battery Danger	
6	339237	1	Decal, Heat Warning	
7	363994	1	Decal, Daily Service	
8	3000435	1	Decal, Start Assist Fluids	
9	363995	1	Decal, Antifreeze	
10	363704	2	Decal, Latch Pin Warning	
11	3009266	2	Decal, Stored Energy Warning	
12	4125771	1	Decal, Patent	
13	4122243	1	Decal, Left Side Stripe	
14	4122244	1	Decal, Right Side Stripe	
15	4124692	2	Decal, HR-9016 Turbo 4WD	
16	557844	1	Decal, ROPS Structure	Used On 70529 Only
17	3004287	2	Pad, Center Panel	
18	3009268	1	Pad, Step	
19	3009267	1	Pad, Floorboard	
20	4124759	1	Emblem, Jacobsen	
21	3009073	1	Decal, Control Panel	
22	4137295	1	Decal, Instrument Panel	
23	5002952	1	Decal, ROPS Seat Belt	Used On 70529 Only

> Change from previous revision


2.1 Hood
Serial No. All



Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	4126099	1	Hood	
2	1003679	1	Pivot, Hood	
3	3006644	2	Pin, Special Clevis	
4	460028	2	Cotter pin, 1/8 x 1"	
5	440120	4	Carriage Bolt, 3/8-16 x 1-1/4"	
6	452008	4	Flat Washer, 3/8	
7	446142	8	Lockwasher, 3/8 Heavy	
8	443110	6	Nut, 3/8-16 Hex	
9	354989	2	Stop, Rubber	
10	443112	2	Nut, 3/8-24 Hex	
11	444310	8	Nut, #10-24 Hex	
12	340795	1	Handle, Hood	
13	402230	2	Screw, 1/4-20 x 1" Slotted	
14	446128	2	Lockwasher, 1/4	
15	443102	2	Nut, 1/4-20 Hex	
16	1004686	2	Latch, Flexible Draw	
17	403914	8	Screw, #10-24 x 3/4" Truss Head	
18	3009793	2	Spring, Gas	Model 70528 and 70529
18	3009793	1	Spring, Gas (One Side Only	Model 70530
18	2809834	1	Spring, Gas (One Side Only)	Model 70530 Only
19	4136563	1	Support, Rear Hood	
20	400264	4	Screw, 3/8-16 x 1-1/4" Hex Head	
21	446116	8	Lockwasher, #10	
22	4119015	1	Foam, Top Hood	
23	4119016	1	Foam, Lower Rear Side Hood-Left	Model 70530 Only
24	4119017	1	Foam Lower Rear Side Hood-Right	Model 70530 Only
25	4119018	1	Foam, Lower Front Hood-Left	Model 70530 Only
26	4119019	1	Foam, Lower Front Hood-Right	Model 70530 Only
27	4119020	1	Foam, Upper Hood-Left	Model 70530 Only
28	4119021	1	Foam, Upper Hood-Right	Model 70530 Only

> Change from previous revision


# 3.1 Cowlings and Skirts



Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	447414	8	Lockwasher, 3/8 External Tooth	
2	404118	8	Screw, 3/8-16 x 7/8" Truss Head	
3	3006663	1	Left Side Cowling	
4	3006664	1	Right Side Cowling	
5	352604	6	Grommet	
6	3005604	8	Receptacle, #85 1/4 Turn	
7	3007704	8	Stud, #85 1/4 Turn	
8	3005603	8	Retainer	
9	443110	12	Nut, 3/8-16 Hex	
10	3006915	4	Bracket, Cowling Mounting	
11	446142	8	Lockwasher, 3/8 Heavy	
12	3006723	1	Left Side Skirt	
13	3006724	1	Right Side Skirt	
14	3007099	1	Bracket, Left Side Skirt Mounting	
15	3007100	1	Bracket, Right Side Skirt Mounting	
16	440120	4	Carriage Bolt, 3/8-16 x 1-1/4"	
17	452008	12	Flat Washer, 3/8	
18	3008015	2	Bracket, Front Skirt	
19	4119022	1	Foam, Side Skirt-Right	Model 70530 Only
20	4119023	1	Foam, Side Skirt-Left	Model 70530 Only

> Change from previous revision


# 4.1 Seat Pan and Heat Shield



Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	3007032	1	Seat Pan	
2	400264	4	Screw, 3/8-16 x 1-1/4" Hex Head	
3	443110	2	Nut, 3/8-16 Hex	
4	446142	4	Lockwasher, 3/8 Heavy	
5	452008	6	Flat Washer, 3/8	
6	5003457	1	Plate, Floorboard	
7	404118	4	Screw, 3/8-16 x 7/8" Truss Head	
8	-	1	Seat with Air Suspension	0474
	5003625	1	Air Ride Suspension     Seet Assembly	See 47.1
9	5003626 361005	1 4	Seat Assembly     Serow M8.1.25 x 25mm Hey Head	See 48.1
	446136	7	Screw, M8-1.25 x 25mm Hex Head	
10 11	452006	7	Lockwasher, 5/16 Heavy Flat Washer, 5/16	
12	3006880	1	Heat Shield	
13	400182	3	Screw, 5/16-18 x 5/8" Hex Head	
14	3010013	1	Shield, Floor	Used On 70528 and 70530
14	3010013	1	Shield, ROPS Floor	Used On 70529
15	5003617	1	Seat Belt Assembly	Used On 70529 Only
16	400370	2	Screw, 7/16-20 x 1" Hex Head	Used On 70529 Only
17	446148	2	Lockwasher, 7/16 Heavy	Used On 70529 Only

> Change from previous revision


# **5.1 Control Panel Mounting**




	Item	Part No.	Qty.	Description	Serial Numbers/Notes
•	1	403910	2	Screw, #10-32 x 1/2" Truss Head	
	2	366670	1	Horn	REFERENCE U11, See 68.1
	3	364016	1	Clamp, Wire Harness	
	4	400260	1	Screw, 3/8-16 x 7/8" Hex Head	
	5	453011	1	Flat Washer, 3/8	
	6	446140	1	Lockwasher, 3/8	
	7	443110	1	Nut, 3/8-16 Hex	
	8	3009544	1	Relay, Time Delay	REFERENCE U2, See 68.1
	9	403860	2	Screw, #8-32 x 5/8" Truss Head	
	10	453004	2	Flat Washer, #8	
	11	446112	2	Lockwasher, #8 Heavy	
	12	444306	2	Nut, #8-32 Hex	
	13	2822524	1	Bracket, Relay	
	14	452002	2	Flat Washer, #10	
	15	446118	2	Lockwasher, #10	
	16	444310	2	Nut, #10-24 Hex	
>	17	3001307	3	Relay, SPDT with Resistor	REFERENCE K15, K16, K17, See 68.1
	18	REF	1	Harness, Kubota Key Switch	See 45.1
	19	_	1	Control Panel	See 7.1 and 8.1
	20	_	1	Instrument Panel	See 5.1
	21	400182	3	Screw, 5/16-18 x 5/8" Hex Head	
	22	446134	3	Lockwasher, 5/16	
	23	453009	3	Flat Washer, 5/16	
	24	404022	4	Screw, 1/4-20 x 1" Truss Head	
	25	453023	4	Flat Washer, 1/4	
	26	446128	4	Lockwasher, 1/4	
	27	443102	4	Nut, 1/4-20 Hex	

> Change from previous revision

# **6.1 Instrument Panel**




	Item	Part No.	Qty.	Description	Serial Numbers/Notes
>	1	4116910	1	Panel, Dash	
	2	403920	4	Screw, #10-24 x 2-1/2" Truss Head	
	3	366283	1	Handle	
	4	3006446	2	Switch, Test / 4WD-Reverse	REFERENCE SW12 & SW14, See 68.1
>	5	2721505	1	Switch, PTO	REFERENCE SW3, See 68.1
>	6	3006436	1	4WD Switch	REFERENCE SW13, See 68.1
	7	3006509	2	Hole Plug	
>	8	2810269	1	Switch, Ignition	REFERENCE SW1, See 68.1
>	9	N/S	1	<ul> <li>Lockwasher</li> </ul>	
>	10	N/S	1	• Nut	
>	11	2811020	1	• Key	
	12	366751	1	Indicator Light, Yellow	REFERENCE U8, See 68.1
	13	1002679	1	Gauge, Warning Light	REFERENCE U5, See 68.1
		5003091	3	<ul> <li>Light Bulb and Socket</li> </ul>	
	14	447006	1	Lockwasher, #10 External Tooth	
	15	444310	1	• Nut, #10-24 Hex	
	16	3005121	1	Gauge, Water Temperature	REFERENCE U10, See 68.1
	17	447002	3	Lockwasher, #6 External Tooth	
	18	444304	3	• Nut, #6-32 Hex	
	19	447206	2	Lockwasher, #8 Internal Tooth	
	20	444306	2	• Nut, #8-32 Hex	DEEEDENIOE 110 0 00 4
	21	365943	1	Gauge, Fuel Level	REFERENCE U9, See 68.1
	22	447002	3	Lockwasher, #6 External Tooth	
	23	444304	3	Nut, #6-32 Hex     Nut, #6-32 Hex	
	24	447206	2	Lockwasher, #8 Internal Tooth     New #9, 22 Heave	
	25	444306	2	Nut, #8-32 Hex     Course Heart Meter	DEEEDENCE US Coo CO 4
	26 27	162723 447006	1 1	Gauge, Hour Meter	REFERENCE U3, See 68.1
	28	444310	1	<ul><li>Lockwasher, #10 External Tooth</li><li>Nut, #10-24 Hex</li></ul>	
	29	3001307	13		REFERENCE K1 ~ K13, K15 ~ 17, See 68.1
	30	REF	1	Wire harness, Console	See 45.1
		5003278	8	• Fuse, 5 Amp (Tan)	REFERENCE F1, F2, F5 ~ F7, F9 ~ F11 See 68.1
		5003281	4	• Fuse, 15 Amp (Light Blue)	REFERENCE F3, F4, F8, F12, See 68.1
	31	555846	3	• Diode	REFERENCE D1 ~ 4, See 68.1
	32	400106	2	Screw, 1/4-20 x 5/8" Hex Head	
	33	446128	2	Lockwasher, 1/4	
	34	452002	12	Flat Washer, #10	
	35	446118	12	Lockwasher, #10 Heavy	
	36	444310	12	Nut, #10-24Hex	
	37	403910	8	Screw, #10-24 x 1/2" Truss Head	
	38	364016	1	Clamp, Wire Harness	
	39	1004992	1	Latch, Panel	




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	351956	1	Spring, Compression	
2	359979	1	Pad, Cork/Rubber, Bulk	
3	360885	2	Disc, Friction	
4	366768	1	Knob, Throttle	
5	367176	2	Spacer	
6	400108	1	Screw, 1/4-20 x 3/4" Hex Head	
7	400110	2	Screw, 1/4-20 x 7/8" Hex Head	
8	400116	2	Screw, 1/4-20 x 1-1/2" Hex Head	
9	400188	1	Screw, 5/16-18 x 1" Hex Head	
10	400274	1	Screw, 3/8-16 x 2-1/2" Hex Head	
11	440040	1	Bolt, Carriage 1/4-20 x 5/8"	
12	443102	7	Nut, 1/4-20 Hex	
13	443106	2	Nut, 5/16-18 Hex	
14	443110	3	Nut, 3/8-16 Hex	
15	444708	2	Locknut, 1/4-20 Center	
16	446130	5	Lockwasher, 1/4" Heavy	
17	446134	1	Lockwasher, 5/16"	
18	452008	1	Flat Washer, 3/8"	
19	453009	3	Flat Washer, 5/16"	
20	453023	6	Flat Washer, 1/4"	
21	3006729	1	Tab, Throttle Support	
22	3006730	1	Lever, Throttle	
23	3008738	1	Stop, Throttle Control	
24	3008901	1	Plate, Back-up	
25	4136191	1	Throttle Cable Assembly	
26	4132650	1	Bracket, Throttle Linkage	
27	554988	1	Pivot, Throttle Cable	
28	303962	1	Throttle Linkage Catch	

#### 8.1 Lift Valve and Controls




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	340061	2	Adapter, 90°	
2	1003611	1	Tube, Lift Valve to Backpressure	
3	3006737	1	Hinge, Control Panel	
4	404022	3	Screw, 1/4-20 x 1" Truss Head	
5	453023	5	Flat Washer, 1/4	
6	446128	7	Lockwasher, 1/4	
7	443102	7	Nut, 1/4-20 Hex	
8	1004584	1	Backpressure Valve	
	5003539	1	Seal Kit	
	5003538	1	Adjusting Knob	
9	340062	1	Adapter, 90°	
10	340029	1	Adapter, 45°	
11	400120	4	Screw, 1/4-20 x 2" Hex Head	
12	1001802	1	Lift Valve	See 52.1
13	340027	2	Adapter, 45°	
14	340026	3	Adapter, 45°	
15	366133	3	Chain, Master Link With Clip	
16	1003100	3	Lever, Lift	
17	361833	1	Pin	
18	3005157	3	Knob	
19	367631	2	Spacer	
20	461356	2	Roll Pin, 3/32 x 1/2"	
21	3010082	1	Stop, Dash Panel	

#### 9.1 Accelerator Pedal




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	1003244	1	Arm, Hydro Pedal	
	471214	1	Grease Fitting (Not Shown)	
2	3010305	2	Bushing	
3	1003071	1	Shaft	
4	400190	4	Screw, 5/16-18 x 1-1/4" Hex Head	
5	453009	1	Flat Washer, 5/16	
6	446134	3	Lockwasher, 5/16	
7	443106	3	Nut, 5/16-18 Hex	
8	1003145	1	Link, Hydro Control	
9	366974	2	Rod End	
10	443112	3	Nut, 3/8-24 Hex	
11	445785	1	Nut, 3/8-24 Hex Left Hand	
12	3006889	1	Turnbuckle	
13	3006886	1	Threaded Rod	
14	400268	1	Screw, 3/8-16 x 1-3/4" Hex Head	
15	446140	4	Lockwasher, 3/8	
16	443110	6	Nut, 3/8-16 Hex	
17	3006888	1	Pedal, Hydro	
18	3003475	2	Grip, Pedal	
19	3002695	1	Washer	
20	3007230	1	Stop, Mow Speed	
21	3007228	1	Plate, Activator	
22	3007220	1	Plate, Switch	
23	452004	2	Flat Washer, 1/4	
24	446128	4	Lockwasher, 1/4	
25	400106	2	Screw, 1/4-20 x 5/8" Hex Head	
26	333542	1	Tie Stud	
27	400266	1	Screw, 3/8-16 x 1-1/2" Hex Head	
28	400262	1	Screw, 3/8-16 x 1" Hex Head	
29	3009026	2	Angle, Switch	
30	3007392	2	Switch, Proximity	
31	403912	4	Screw, #10-24 x 5/8" Truss Head	
32	452002	4	Flat Washer, #10	
33	446118	4	Lockwasher, #10 Heavy	
34	444310	4	Nut, #10-24 Hex	
35	441606	2	Carriage Bolt, 1/4-20 x 3/4"	
36	453023	2	Flat Washer, 1/4	
37	443102	2	Nut, 1/4-20 Hex	
38	3004385	4	Seal, Rod End	
39	444718	1	Locknut, 5/16-18 Center	

## **10.1 Steering Assist**



Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	1003794	2	Steering Assist Pedal	
	471214	1	<ul> <li>Grease Fitting (Not Shown)</li> </ul>	
2	3010305	4	Bushing	
3	1003245	1	Shaft	
4	452006	1	Flat Washer, 5/16	
5	446134	3	Lockwasher, 5/16	
6	443106	3	Nut, 5/16-18Hex	
7	3006107	2	Spring, Pedal Return	
8	400188	3	Screw, 5/16-18 x 1" Hex Head	
9	3008342	1	Cable, Right Turn Assist	
10	3008343	1	Cable, Left Turn Assist	
11	461453	2	Clevis Pin, 5/16 x 1"	
12	460028	4	Cotter Pin, 1/8 x 1"	
13	1003825	2	Connector, Brake	
14	1003824	2	Pivot, Brake Lever	
15	364154	4	Bushing  Dia Claude	
16	3008344	2	Pin, Clevis	
17	3008907	1	Shield, Cable	
18 19	400262 452008	2	Screw, 3/8-16 x 1" Hex Head Flat Washer, 3/8	
20	446142	2	Lockwasher, 3/8 Heavy	
21	443110	2	Nut, 3/8-16 Hex	
22	1006812	2	Pad, Pedal	
23	3009607	2	Nut, M12-1.75 Hex Jam	
24	455048	2	Flat Washer, 3/4	
	100010	_	1 (4) (10)	


## 11.1 Parking Brake




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	1003838	1	Parking Brake Lever	
2	N/S	2	Stabilizer Bar	
3	545234	2	Clevis Pin	
4	460004	2	Cotter Pin	
5	545237	2	Spacer	
6	3006108	2	Cable, Parking Brake	
7	3008548	1	Mount, Brake Lever	
8	3008874	1	Plate, Switch Mount	
9	441672	2	Carriage Bolt, 5/16-18 x 2-1/2"	
10	453009	2	Flat Washer, 5/16	
11	446134	4	Lockwasher, 5/16	
12	443106	5	Nut, 5/16-18 Hex	
13	400188	2	Screw, 5/16-18 x 1" Hex Head	
14	461456	2	Clevis Pin, 5/16 x 1-5/8" Hex Head	
15	460016	2	Cotter Pin, 3/32 x 1"	
16	403746	2	Screw, #10-24 x 3/4" Truss Head	
17	3007392	1	Switch, Proximity	
18	452002	2	Flat Washer, #10	
19	446118	2	Lockwasher, #10 Heavy	
20	444310	2	Nut, #10-24 Hex	
21	441602	1	Carriage Bolt, 5/16-18 x 3/4"	
22	354081	1 5	Clamp, Wire Harness	
23	3009193	5	Shim, Switch	

12.1 Frame

Serial No. 70528 All
Serial No. 70530 All




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	4131870	1	Frame	
2	1002889	1	Cross Frame	
3	1002895	1	Cylinder Mount, Right	
4	1002896	1	Cylinder Mount, Left	
5	400416	4	Screw, 1/2-13 x 2-1/2" Hex Head	
6	446154	6	Lockwasher, 1/2 Heavy	
7	443118	6	Nut, 1/2-13 Hex	
8	3006814	1	Bracket, Right Radiator	
9	3006815	1	Bracket, Left Radiator	
10	400616	8	Screw, 5/8-11 x 2" Hex Head	
11	446166	8	Lockwasher, 5/8 Heavy	
12	443126	8	Nut, 5/8-11 Hex Head	
13	400406	2	Screw, 1/2-13 x 1-1/4" Hex Head	
14	1004938	1	Charge Filter Assembly	
	556417	1	Head	
	5003691	1	<ul> <li>Oil Filter Cartridge</li> </ul>	
	556419	1	<ul> <li>Charge Pressure Switch</li> </ul>	REFERENCE SW15, See 68.1
15	3007919	1	Bracket, Valve Mounting	
16	340075	1	Adapter, 90°	
17	339996	1	Adapter, Straight	
18	452008	4	Flat Washer, 3/8	
19	446140	4	Lockwasher, 3/8	
20	400260	4	Screw, 3/8-16 x 7/8" Hex Head	
21	3007920	1	Bracket, Deck Valve Mounting	
22	453017	8	Flat Washer, 1/2	
23	1004691	2	Tie Down	
24	3009197	2	Bracket, Hose	
25	REF	1	Plate, Serial Number	
26	1004308	1	Mount, Fuel Tank Rear	
27	1004309	1	Mount, Hydraulic Tank Rear	
28	400778	8	Screw, 3/4-10 x 2-1/2" Hex Head	
29	452018	4	Flat Washer, 3/4	
30	446178	8	Lockwasher, 3/4 Heavy	
31	443130	8	Nut, 3/4-10 Heavy	
32	453004	1	Flat Washer, #8	
33	409701	1	Screw, #8-18 x 3/8" Thread Form	
34	3010035	2	Plate	




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	4131870	1	Frame	
2	1002889	1	Cross Frame	
3	1002895	1	Cylinder Mount, Right	
4	1002896	1	Cylinder Mount, Left	
5	400416	4	Screw, 1/2-13 x 2-1/2" Hex Head	
6	446154	6	Lockwasher, 1/2 Heavy	
7	443118	6	Nut, 1/2-13 Hex	
8	3006814	1	Bracket, Right Radiator	
9	3006815	1	Bracket, Left Radiator	
10	400616	8	Screw, 5/8-11 x 2" Hex Head	
11	446166	8	Lockwasher, 5/8 Heavy	
12	443126	8	Nut, 5/8-11 Hex Head	
13	400406	2	Screw, 1/2-13 x 1-1/4" Hex Head	
14	1004938	1	Charge Filter Assembly	
	556417	1	Head	
	5003691	1	Oil Filter Cartridge	
	556419	1	<ul> <li>Charge Pressure Switch</li> </ul>	REFERENCE SW15, See 68.1
15	3007919	1	Bracket, Valve Mounting	
16	340075	1	Adapter, 90°	
17	339996	1	Adapter, Straight	
18	452008	4	Flat Washer, 3/8	
19	446140	4	Lockwasher, 3/8	
20	400260	4	Screw, 3/8-16 x 7/8" Hex Head	
21	3007920	1	Bracket, Deck Valve Mounting	
22	453017	8	Flat Washer, 1/2	
23	1004691	2	Tie Down	
24	3009197	2	Bracket, Hose	
25	REF	1	Plate, Serial Number	
26	1004308	1	Mount, Fuel Tank Rear	
27	1004309	1	Mount, Hydraulic Tank Rear	
28	400778	8	Screw, 3/4-10 x 2-1/2" Hex Head	
29	452018	4	Flat Washer, 3/4	
30	446178	8	Lockwasher, 3/4 Heavy	
31	443130	8	Nut, 3/4-10 Heavy	
32	453004	1	Flat Washer, #8	
33	409701	1	Screw, #8-18 x 3/8" Thread Form	
34	1002893	1	ROPS	Includes Decals and Seat Belt

## 14.1 Steering Axle




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	5003540	2	Wheel Motor	See 50.1
2	460030	4	Cotter Pin, 1/8 x 1-1/4"	
3	443842	1	Nut, 1-1/8 -12 Hex Jam	
4	401208	8	Screw, 1/2-13 x 1-3/4" Grade 8	
5	5003530	1	Frame, RH Wheel Motor	
6	5003529	1	Frame, LH Wheel Motor	
7	5003521	2	Hub, Wheel	
8	5003526	1	Axle, Center Section	
9	5003518	2	Washer, Thrust	
10	5003515	2	Washer, Thrust	
11	5003528	2	Bushing, Bronze	
12	5003527	4	Bushing, Bronze	
13	5003522	1	Tie Rod	
14	5003519	1	Nut, 1-1/8 -12 Left Hand Thread	
15	5003523	1	Tie Rod End, Left Hand Thread	
16	5003524	1	Tie Rod End, Right Hand Thread	
17	5003541	1	Cylinder, Steering	See 49.1
	5003542	1	Seal Kit	
18	5003562	2	Screw, 5/8-11 Socket Head Set	
19	443826	2	Nut, 5/8-11 Hex Jam	
20	471214	3	Grease Fitting	
21	460035	2	Cotter Pin, 1/8 x 2"	
22	458126	2	Snap Ring	
23	5003520	2	Snap RIng, External	
24	5003531	2	Plug, Expansion	
25	5003543	1	Socket Assembly	

# 15.1 Steering Axle Installation




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	-	1	Steering Axle	See 14.1
2	1003001	1	Pivot Shaft	
3	3006475	AR	Washer, 3/32" Thick Thrust	
4	363766	1	Washer	
5	445642	1	Nut, 1-1/2 -12 Slotted Hex	
6	460072	1	Cotter Pin, 1/4 x 2-1/2"	
7	400408	1	Screw, 1/2-13 x 1-1/2" Hex Head	
8	446152	1	Lockwasher, 1/2	
9	443118	1	Nut, 1/2-13 Hex	
10	3003101	AR	Washer, 1/32" Thick Thrust	
11	3007683	12	Wheel Bolt, 1/2-20	
12	5003419	2	Tire, 24 x 12-12 Turf Trac	
13	5003420	2	Wheel	
14	360111	2	Valve, Inflation	
15	453017	1	Flat Washer, 1/2	

# 16.1 Battery Tray




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	440078	3	Bolt, Carriage 5/16-18 x 3/4"	
2	440118	2	Bolt, Carriage 3/8-16 x 1"	
3	443106	3	Nut, 5/16-18 Hex	
4	443109	2	Nut, 3/8-16 Hex	
5	446134	3	Lockwasher, 5/16	
6	446142	2	Lockwasher, 3/8 Heavy	
7	452006	3	Flat Washer, 5/16	
8	453011	2	Flat Washer, 3/8	
9	3008461	3	Angle, Battery Clamp	
10	3010346	2	Terminal Bolt, Side	
11	4108140	1	Battery	REFERENCE B1, See 68.1
12	4133043	1	Cable, Negative Battery	
13	4133044	1	Cable, Positive Battery	
14	4133224	2	Support, Weldment	
15	4136131	1	Tray, Battery	
16	4136563	1	Support Bracket, Hood Rear Assy	
17	64163-46	4	Washer, .388 x .880	
18	800709	11	Bolt, Flange Head 3/8-16 x 1-1/4:	
19	444762	4	Locknut, 3/8-16 Center	

## 17.1 Tilt Steering




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	5002918	1	Actuator, Gas Spring	
2	5002919	1	Cable, Actuator	
3	2811346	1	Tower, Steering	
4	1002800	1	Pump, Steering	See 46.1
	339979	5	<ul> <li>Adapter, Straight</li> </ul>	
5	2811364	1	Steering Wheel	
6	2811365	1	<ul> <li>Cap, Steering Wheel</li> </ul>	
7	3010651	1	Cover, Steering Tower	
8	3005981	1	Bracket, Steering Pump	
9	3005934	2	Bolt, Shoulder	
10	400192	1	Screw, 5/16-18 x 1-1/2" Hex Head	
11	444718	3	Locknut, 5/16-18 Center	
12	444849	2	Locknut, 3/4-10 Center Jam	
13	444754	4	Locknut, 5/16-24 Center	
14	447224	1	Lockwasher, 5/8 Internal	
15	400216	1	Screw, 5/16-18 x 2-3/4" Hex Head	
16	443106	4	Nut, 5/16-18 Hex	
17	416911	2	Screw, #10-24 x 1/2" Thread Cutting	
18	404016	6	Screw, 1/4-20 x 5/8: Truss Head	
19	446142	2	Lockwasher, 3/8 Heavy	
20	400258	2	Screw, 3/8-16 x 3/4" Hex Head	
21	441602	4	Carriage Bolt, 5/16-18 x 3/4"	
22	446406	4	Lookwasher F/16 Hoovy	
23 24	446136	4	Lockwasher, 5/16 Heavy Tinnerman Nut	
24 25	445245 2811547	6 1	Washer	
23	2011347	1	wasilei	
İ				

#### 18.1 Radiator




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	1003075	1	Radiator Firewall	
2	1002953	1	Radiator	
	555867	1	Radiator Cap	
3	400258	12	Screw, 3/8-16 x 3/4" Hex Head	
4	446142	22	Lockwasher, 3/8 Heavy	
5	4132213	1	Radiator Fan Shroud	
6	452008	10	Flat Washer, 3/8	
7	4132168	1	Hose, Upper Radiator	
8	326799	4	Clamp, Hose	
9	4132169	1	Hose, Lower Radiator	
10	366526	4	Clamp, Hose	
11	3007731	1	Reserve Tank	
12	162479	1	Drain Cock	
13	440086	4	Carriage Bolt, 5/16-18 x 1-1/2"	
14	443110	10	Nut, 3/8-16 Hex	
15	3008885	1	Brace, Cooler	
16	440120	10	Carriage Bolt, 3/8-16 x 1-1/4"	
17	453009	4	Flat Washer, 5/16	
18	444718	4	Locknut, 5/16-18 Center	
19	3009537	1	Cap, Reserve Tank	
20	554748	AR	Hose, 5/16 I.D.	
21	3008203	AR	Seal (10 Foot Roll)	
22	2810492	1	Plate, Indent	
23	3006233	6	Washer, Isolator	
24	4136512	1	Bracket, Remote Engine Oil Filter	
25	440080	1	Carriage Bolt, 5/16-18 x 3/4"	
26	445781	1	Nut, 5/16-18 Whiz Lock	
27	831846	4	Nut, Isolation	

19.1 Oil Cooler




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	1002952	1	Oil Cooler	
2	3004113	2	Bushing	
3	2810633	1	Plate, Cap Mounting	
4	3007011	1	Bracket, Cooler Pivot	
5	400270	2	Screw, 3/8-16 x 2" Hex Head	
6	452008	4	Flat Washer, 3/8	
7	446142	3	Lockwasher, 3/8 Heavy	
8	443110	3	Nut, 3/8-16 Hex	
9	1004028	1	Pin, Cooler Pivot	
10	400186	1	Screw, 5/16-18 x 7/8" Hex Head	
11	452006	1	Flat Washer, 5/16	
12	446134	1	Lockwasher, 5/16	
13	443106	5	Nut, 5/16-18 Hex	
14	3008562	1	Angle, Cooler Top	
15	3008563	2	Plate, Cooler Lock	
16	400190	2	Screw, 5/16-18 x 1-1/4" Hex Head	
17	446136	4	Lockwasher, 5/16 Heavy	
18	362008	2	Knob	
19	358794	4	Washer	
20	3007674	1	Fitting, 90°	
21	1003011	1	Return Filter	
	5002693	1	Return Filter Cartridge	
	556419	1	Switch	
22	460016	1	Cotter Pin, 3/32 x 1"	
23	1004172	1	Stand, Cooler Pivot	
24	361723	1	Stop, Rubber	
25	351491	1	Grip	
26	551651	AR	Molding	
27	1003942	1	Screen	
28	3008561	2	Guide, Screen	
29	409804	8	Screw, #10-24 x 1/2" Thread Cut	
30	3009095	2	Seal, Neoprene	
31	3008554	1	Cap, Right Side	
32	2810634	1	Cap, Left Side	
33	3010014	1	Shield, Screen	
34	440082	4	Carriage Bolt, 5/16-18 x 1"	
35	453011	3	Flat Washer, 3/8	

#### 20.1 Air Cleaner and Muffler




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	162236	1	Clamp	
2	3002042	4	Screw, M10-1.25 x 22 SHCS	
3	363485	6	Lockwasher, M10 Heavy	
4	365979	4	Bolt, M12-1.25 x 25	
5	400404	2	Screw, 1/2-13 X 1" Hex Head	
6	4135602	1	Bracket, Support	
7	4135603	1	Bracket, Air Filter/Heat Shield	
8	4136469	2	Bracket, Heat Shield	
9	446154	6	Lockwasher, 1/2 Heavy	
10	4132212	1	Hose, Air Intake	
11	4132214	1	Muffler, Weldment Assembly	
12	4132420	1	Tailpipe Assembly	
13	4136616	2	Isolator, Muffler	
14	4135922	1	Gasket, Exhaust Flange	
15	359615	1	Clamp, Hose	
16	361898	2	Screw, M8-1.25 x 16MM	
17	362615	2	Flat Washer	
18	4132211	1	Hose, Turbo Filter Assembly	
19	366884	2	Bolt, M10-1.25 x 20 Hex Head	
20	440082	9	Bolt, Carriage 5/16-18 x 1"	
21	440084	2	Carriage BOlt, 5/16-18 x 1-1/4"	
22	443106	8	Nut, 5/16-18 Hex	
23	444718	1	Locknut, 5/16-18 Center	
24	446136	8	Lockwasher, 5/16 Heavy	
25	3009505	1	Clamp, Air Cleaner Mount	
26	453009	8	Flat Washer, 5/16	
27	1001752	1	Indicator, Mini Kit	
28 29	1004417 813689	1 3	Air Cleaner Assembly	
29	013009	3	Clamp, Hose	

## 21.1 Remote Engine Oil Filter




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	450190	2	Screw, M8-1.25 x 16 Hex Head	
2	4136120	1	Adaptor, Oil Filter	Part of Engine
3	4137099	1	Adaptor, 90°, 3/8-18 x 13/16	
4	4133242	1	O Ring	Part of Engine
5	4133240	1	Plug, Oil Filter	Part of Engine
6	4137101	1	Adaptor, 90° 3/8-18 x 11/16	
7	4133243	1	Cover, Oil Filter	Part of Engine
8	4137100	1	Adaptor, 90° 1/2 x 13/16	
9	4137894	1	Filter	Part of Engine
10	446136	2	Lockwasher, 5/16 Heavy	
11	4133241	1	O Ring	Part of Engine
12	4135261	1	Hose, Pump Right Side Tube	
13	340063	1	Elbow, 90°	
14	340070	1	Elbow, 90°	
15	4137611	2	Mounting Block, Rubber	
16	367559	2	Washer, Oil Cooler Mounting	
17	441618	2	Bolt, Carriage 5/16-18 x 2"	
18	440118	2	Bolt, Carriage 3/8-16 x 7/8"	
19	443110	2	Nut, 3/8-16 Hex	
20	446142	2	Lockwasher, 3/8	
21	452008	2	Flat Washer, 3/8	
22	3009860	1	Cooler, 3 Row	
23	4135761	1	Bracket, Engine Oil Cooler	
24	4136646	1	Hose Assembly, Inlet	
25	4136647	1	Hose Assembly, Return	
26	444718	2	Locknut, 5/16-18 Center	

## **22.1 Engine Mounting**




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	_	1	Engine and Pump Assembly	See 22.1
2	4136298	1	Fan	Mounting Hardware Part of Engine
3	3008821	1	Temperature Sender	REFERENCE U6, See 68.1
4				
5	4136286	1	Engine Mount, Right Hand	
6	4136285	1	Engine Mount, Left Hand	
7	4132013	2	Engine Mount, Rear	
8	365979	19	Screw, M12-1.25 x 25mm Hex Head	
9	446154	19	Lockwasher, 1/2 Heavy	
10	4134448	1	Drive Shaft	
11	400266	2	Screw, 3/8-16 x 1-1/2" Hex Head	
12	446142	8	Lockwasher, 3/8 Heavy	
13	443110	8	Nut, 3/8-16 Hex	
14	4137616	2	Isolator, Rear	
15	4136227	2	Isolator, Front	
16	323943	2	Washer, 2"O.D. x 17/32" I.D.	
17	400264	8	Screw, 3/8-16 x 1-1/4" Hex Head	
18 19	400422 452012	2 2	Screw, 1/2-13 x 4" Hex Head	
20	446166	2	Flat Washer, 1/2 Lockwasher, 5/8" Heavy	
20	443118	2	Nut, 1/2-13 Hex	
22	361071	2	Flat Washer, Isolator	
23	4136245	4	Screw, M8-1.25 x 50mm Hex Flange	
24	444762	2	Locknut, 3/8-16 Center	
25	443128	2	Nut, 5/8-18 Hex	
26	363996	1	Switch, Temperature Warning	REFERENCE SW17, See 68.1
27	446154	2	Lockwasher, 1/2" Heavy	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
28	400656	2	Screw, 5/8-18 x 4" Hex Head	
29	452016	2	Flat Washer, 5/8	

## 23.1 Engine and Pump Assembly




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	REF	1	Kubota Engine Assembly	
		1	Engine Oil Filter	
		1	Fan Belt	
		1	Fuel Filter	
2	339989	3	Connector, Straight Thread	
3	362263	8	Bolt, M10-1.25 X 25 Hex Head	
4	363485	20	Lockwasher, M10 Heavy	
5	400336	8	Screw, 7/16-14 X 1-1/4" Hex Head	
6	400406	4	Screw, 1/2-13 X 1-1/4" Hex head	
7	446148	8	Lockwasher, 7/16 Heavy	
8	446154	4	Lockwasher, 1/2 Heavy	
9	453017	4	Flat Washer, 1/2	
10	1003247	1	Pump, Triple	
	5003163	1	Seal Kit, Front Section	
	5003164	1	Seal Kit, Section	One kit required for each section
11	3002042	12	Bolt, M10-1.25 X 22 Socket Head	
12	3006238	1	Hub	
13	3006240	1	Flange, 10"	
14	3006829	2	Fitting, 4-Bolt Flange	
15	3006835	2	O-Ring, 1.750 O.D. X 1.500 I.D.	
16	4132016	1	Flywheel Cover, Rear	

## 24.1 Tank Mounting




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	3006264	1	Tank, Hydraulic oil	
2	3008808	1	Cap, Breather Filler	
3	3009203	1	Sensor, Oil Level	REFERENCE SW11, See 68.1
4	441689	2	Carriage Bolt, 1/2-13 x 8-1/2"	
5	3009236	1	Wall, Fender	
6	3008219	1	Bracket, Hose Retainer	
7	452012		Flat Washer, 1/2	
8	443118	4	Nut, 1/2-13 Hex	
9	3009980	1	Fender, Right Side	
10	400188		Screw, 5/16-18 x 1" Hex Head	
11	446136		Lockwasher, 5/16 Heavy	
12	362615	8	Washer, Special	
13	440088	2	Carriage Bolt, 5/16-18 x 1-3/4"	
14	452006	8	Flat Washer, 5/16	
15	443106		Nut, 5/16-18 Hex	
16	3006566		Strainer	
	339904		O-Ring SAE -32	
17	3006847	1	Fitting, Beaded	
	339904		O-Ring SAE -32	
18	3002397	1	Plug, Magnetic	



Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	554752	1	Fuel Line, Engnie Overflow Return	Cut to 82", 3/16" I.D.
2	132647	1	Fuel Shutoff	
3	340481	1	Cover, Sender	
4	554748	1	Fuel Line, Tank to Pre-Filter	Cut to xx", 5/16" I.D.
5	554748	1	Fuel Line, Pre-Filter to Fuel Pump	Cut to xx", 5/16" I.D.
6	554748	1	Fuel Line, Fuel Pump to Fuel Filter	Cut to xx", 5/16" I.D.
7	361117	3	Bushing	
8	361748	1	Valve, Overflow	
9	362615	4	Washer, Special	
10	366526	8	Clamp, Hose	
11	400188	6	Screw, 5/16-18 x 1" Hex Head	
12	400264	1	Screw, 3/8-16 x 1-1/4" Hex Head	
13	403910	5	Screw, #10-24 x 1/2" Truss Head	
14	441606	1	Bolt, Carriage 1/4-20 x 3/4"	
15	441614	1	Bolt, Carriage 5/16-18 x 1"	
16	441689	2	Carriage Bolt, 1/2-13 x 8-1/2"	
17	443102	1	Nut, 1/4-20 Hex	
18	443106	7	Nut, 5/16-18 Hex	
19	443110	2	Nut, 3/8-16 Hex	
20	443118	4	Nut, 1/2-13 Hex	
21	446130	1	Lockwasher, 1/4 Heavy	
22	446136	7	Lockwasher, 5/16 Heavy	
23	446140	2	Lockwasher, 3/8	
24	452006	9	Flat Washer, 5/16	
25	452008	3	Flatwasher, 3/8	
26	452012	1	Flat Washer, 1/2	
27	453023	1	Flat Washer, 1/4	
28	2721806	1	Cap, Fuel	
29	2810702	1	Valve, Needle	
30	3006265	1	Tank, Fuel	
31	3006639	1	Sender, Fuel	
32	3008820	1	Clamp, Double Hose (5/8" O.D.)	
33	3009236	1	Wall, Fender	
34	3009979	1	Fender	
35	5001182	1	Filter, Pre Fuel	
36	4135918	1	Pump, Fuel	
37	446142	1	Lockwasher, 3/8 Heavy	


## 26.1 Pump and 4WD Valve Mounting



9016-06

Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	-	1	Pump Assembly	See 27.1
2	4135556	1	4WD Valve with Oil Shuttle	See 56.1
3	400406	4	Screw, 1/2-13 x 1-1/4" Hex Head	
4	446154	6	Lockwasher, 1/2 Heavy	
5	453017	4	Flat Washer, 1/2	
6	400412	2	Screw, 1/2-13 x 2" Hex Head	
7	3006658	1	Bracket, Pump Support	
8	443118	2	Nut, 1/2-13 Hex	
9	440082	4	Carriage Bolt, 5/16-18 x 1"	
10	452006	4	Flat Washer, 5/16	
11	446136	4	Lockwasher, 5/16 Heavy	
12	443106	4	Nut, 5/16-18 Hex	
13	3006913	1	Bracket, Pump Support	
14	446140	2	Lockwasher, 3/8	Included with Pump
15	443110	2	Nut, 3/8-16 Hex	Included with Pump


## 27.1 Pump Assembly



9016-07


Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	1002927	1	Pump, Traction	
	5003034	1	Seal Kit	
	5003432	1	Control Kit	
	5003433	1	Shaft Seal Kit	
	5003544	1	<ul> <li>System Relief Kit</li> </ul>	
2	1003248	1	Pump, Double	
	5003165	1	<ul> <li>Seal Kit, Front Section</li> </ul>	
	5003166	1	<ul> <li>Seal Kit, Rear Section</li> </ul>	
3	362743	1	O-RIng	
4	400262	2	Screw, 3/8-16 x 1" Hex Head	
5	446142	2	Lockwasher, 3/8 Heavy	
6	340077	1	Adapter, 90°	
7	340269	1	Adapter, Tee	
8	340070	2	Adapter, 90°	
9	3006829	1	Fitting, 4 Bolt Flange	
10	3006835	1	O-Ring, 1-3/4" O.D. x 1-1/2" I.D.	
11	400336	4	Screw, 7/16-14 x 1-1/4" Hex Head	
12	446148	4	Lockwasher, 7/16 Heavy	
13	339984	1	Adapter, Straight	
14	339999	1	Adapter, Straight	

## 28.1 Front Lift Arms and Cylinders




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	1002785	1	R.H. Front Lift Arm	
2	1003900	1	L.H. Front Lift Arm	
3	342033	4	Bushing	
4	471214	2	Grease Fitting	
5	3006490	4	Bracket, Front Deck Pivot	
6	3007091	1	Angle, R.H. Valve Mount	
7	3007092	1	Angle, L.H. Valve Mount	
8	400412	28	Screw, 1/2-13 x 2" Hex Head	
9	453017	4	Flat Washer, 1/2	
10	446154	28	Lockwasher, 1/2 Heavy	
11	443118	28	Nut, 1/2-13 Hex	
12	3006008	2	Front Lift Cylinder	See 53.1
13	340061	2	Adapter, 90°	
14	339979	2	Adapter, Straight	
15	3006491	4	Bracket, Front Cylinder Pivot	
16	1003274	2	Pin, Front Cylinder	
17	1003275	2	Pin, Front Lift Arm Pivot	
18	3007468	1	Bracket, Switch	
19	403746	2	Screw, #10-24 x 3/4" Truss Head	
20	3007392	1	Switch, Proximity	REFERENCE SW8, See 68.1
21	452002	2	Flat Washer, #10	
22	446118	2	Lockwasher, #10 Heavy	
23	444310	2	Nut, #10-24 Hex	
24	3007680	2	Pin, Front Deck Mounting	
25	460054	2	Cotter Pin, 3/16 x 1-3/4"	
26	400192	2	Screw, 5/16-18 x 1-1/2" Hex Head	
27	3004410	2	Spacer	
28	3009269	2	Clamp, Wire Harness Twisted	
29	452006	2	Flat Washer, 5/16	
30	446134	2	Lockwasher, 5/16	
31	443106	2	Nut, 5/16-18 Hex	
32	455004	2	Flat Washer, 1"	
33	3010015	4	Spacer	
34	364830	AR	Thrust Washer	
35	3009193	5	Shim, Switch	

#### 29.1 Front Deck Latch




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	1003483	1	Brace, Stand Up	
2	365826	2	Spacer	
3	400430	1	Screw, 1/2-13 x 5-1/2" Hex Head	
4	1003277	2	Pin, Cylinder Rod End	
5	446154	1	Lockwasher, 1/2 Heavy	
6	443118	3	Nut, 1/2-13 Hex	
7	1003484	1	Latch, Front Deck	
8	352936	2	Bushing	
9	3008472	1	Spring, Torsion	
10	441690	1	Carriage Bolt, 1/2-13 x 7"	
11	453017	2	Flat Washer, 1/2	
12	3008453	1	Stop, Anti Sway Latch	
13	352435	1	Spacer	
14	319755	1	Washer	
15	400264	1	Screw, 3/8-16 x 1-1/4" Hex Head	
16	446142	4	Lockwasher, 3/8 Heavy	
17	443110	4	Nut, 3/8-16 Hex	
18	3007297	1	Tab, Spring	
19	400114	2	Screw, 1/4-20 x 1-1/4" Hex Head	
20	3007712	2	Shim	
21	446128	2	Lockwasher, 1/4	
22	443102	2	Nut, 1/4-20 Hex	
23	400194	1	Screw, 5/16-18 x 1-3/4" Hex Head	
24	346802	1	Spring, Extension	
25	443806	1	Nut, 5/16-18 Hex Jam	
26	444718	1	Locknut, 5/16-18 Center	
27	361723	3	Stop, Rubber	
28	400186	1	Screw, 5/16-18 x 7/8" Hex Head	
29	354081	1	Clamp, Wire Harness	
30	446134	1	Lockwasher, 5/16	
31	443106	1	Nut, 5/16-18 Hex	

#### 30.1 Side Lift Arms




005016 005017 304569 332351 471214 006294 006295 400412 446154 444758 809628 006727 002885 002886 471214 350800 362464 346294	1 4 4 6 2 2 20 20 20 20 2 4 1 1	Pivot, Left Side Arm Pivot, Right Side Arm Bushing Bushing Grease Fitting Plate, Side Arm Pivot Plate, Side Arm Pivot Screw, 1/2-13 x 2" Hex Head Lockwasher, 1/2 Heavy Locknut, 1/2-13 Center Pin, Side Arm Pivot Washer, Thrust Left Side Lift Arm	
304569 332351 471214 006294 006295 400412 446154 444758 809628 006727 002885 002886 471214 350800 362464	4 4 6 2 2 20 20 20 2 4 1	<ul> <li>Bushing</li> <li>Bushing</li> <li>Grease Fitting</li> <li>Plate, Side Arm Pivot</li> <li>Plate, Side Arm Pivot</li> <li>Screw, 1/2-13 x 2" Hex Head</li> <li>Lockwasher, 1/2 Heavy</li> <li>Locknut, 1/2-13 Center</li> <li>Pin, Side Arm Pivot</li> <li>Washer, Thrust</li> </ul>	
332351 471214 006294 006295 400412 446154 444758 809628 006727 002885 002886 471214 350800 362464	4 6 2 2 20 20 20 2 4 1	<ul> <li>Bushing</li> <li>Grease Fitting</li> <li>Plate, Side Arm Pivot</li> <li>Plate, Side Arm Pivot</li> <li>Screw, 1/2-13 x 2" Hex Head</li> <li>Lockwasher, 1/2 Heavy</li> <li>Locknut, 1/2-13 Center</li> <li>Pin, Side Arm Pivot</li> <li>Washer, Thrust</li> </ul>	
471214 006294 006295 400412 446154 444758 809628 006727 002885 002886 471214 350800 362464	6 2 2 20 20 20 2 4 1	Grease Fitting     Plate, Side Arm Pivot     Plate, Side Arm Pivot     Screw, 1/2-13 x 2" Hex Head     Lockwasher, 1/2 Heavy     Locknut, 1/2-13 Center     Pin, Side Arm Pivot     Washer, Thrust	
006294 006295 400412 446154 444758 809628 006727 002885 002886 471214 350800 362464	2 2 20 20 20 2 4 1	Plate, Side Arm Pivot Plate, Side Arm Pivot Screw, 1/2-13 x 2" Hex Head Lockwasher, 1/2 Heavy Locknut, 1/2-13 Center Pin, Side Arm Pivot Washer, Thrust	
006295 400412 446154 444758 809628 006727 002885 002886 471214 350800 362464	2 20 20 20 2 4 1	Plate, Side Arm Pivot Screw, 1/2-13 x 2" Hex Head Lockwasher, 1/2 Heavy Locknut, 1/2-13 Center Pin, Side Arm Pivot Washer, Thrust	
400412 446154 444758 809628 006727 002885 002886 471214 350800 362464	20 20 20 2 4 1	Screw, 1/2-13 x 2" Hex Head Lockwasher, 1/2 Heavy Locknut, 1/2-13 Center Pin, Side Arm Pivot Washer, Thrust	
446154 444758 809628 006727 002885 002886 471214 350800 362464	20 20 2 4 1	Lockwasher, 1/2 Heavy Locknut, 1/2-13 Center Pin, Side Arm Pivot Washer, Thrust	
444758 809628 006727 002885 002886 471214 350800 362464	20 2 4 1 1	Locknut, 1/2-13 Center Pin, Side Arm Pivot Washer, Thrust	
809628 006727 002885 002886 471214 350800 362464	2 4 1 1	Pin, Side Arm Pivot Washer, Thrust	
006727 002885 002886 471214 350800 362464	4 1 1	Washer, Thrust	
002885 002886 471214 350800 362464	1 1		
002886 471214 350800 362464	1	Left Side Lift Arm	
471214 350800 362464			
350800 362464	2	Right Side Lift Arm	
362464		Grease Fitting	
	4	Bushing	
346294	16	Wheel Bolt	
	8	Wheel Nut	
446142	8	Lockwasher, 3/8 Heavy	
443110	16	Nut, 3/8-16 Hex	
361723	8	Stop, Rubber	
007897	1	Bracket, Left Side Deck Latch	
007896	1	Bracket, Right Side Deck Latch	
009163	1	Bolt, Left Side Deck Latch	
009162	1	Bolt, Right Side Deck Latch	
009309	2	Spring, Compression	
453020	2	Flat Washer, 5/8	
460052	2	Cotter Pin, 3/16 x 1-1/2"	
461408	2	Spring Pin, 1/4 x 1-1/2"	
452012	6	Flat Washer, 1/2	
60297.2	2	Chain, Dump Box	
006204	2	Collar	
401030	2	Screw, 3/8-16 x 3-3/4" Hex Head	
363572	AR	Washer	
62716.2	8	Shackle, Chain	
366978	2	Eyebolt	
008374	2	Spring, Extension	
005018	2	Pin, Lift Arm	
809630	2	Retaining Ring, Side Arm Pivot	
010825	2	Retaining Ring, Lift Arm	
811064	1	Plate, Left Side Bottom	
444730	8	Locknut, 7/16-20 Hex	
010811	2	Collar	
363746	4	Chain	
	452012 0297.2 006204 401030 363572 2716.2 366978 008374 005018 309630 010825 811064 444730 010811	452012 6 0297.2 2 006204 2 401030 2 363572 AR 2716.2 8 366978 2 008374 2 005018 2 309630 2 010825 2 811064 1 444730 8 010811 2	6 Flat Washer, 1/2 0297.2 2 Chain, Dump Box 006204 2 Collar 401030 2 Screw, 3/8-16 x 3-3/4" Hex Head 363572 AR Washer 2716.2 8 Shackle, Chain 366978 2 Eyebolt 008374 2 Spring, Extension 005018 2 Pin, Lift Arm 309630 2 Retaining Ring, Side Arm Pivot 010825 2 Retaining Ring, Lift Arm 1 Plate, Left Side Bottom 1444730 8 Locknut, 7/16-20 Hex 010811 2 Collar

### 31.1 Side Lift Cylinders and Return Canisters




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	5003371	2	Canister, Deck Return	See 51.1
2	1003823	2	Pin, Canister Mount	
3	400266	2	Screw, 3/8-16 x 1-1/2" Hex Head	
4	446140	2	Lockwasher, 3/8	
5	443110	4	Nut, 3/8-16 Hex	
6	3009535	2	Pin, Shear	
7	458039	4	Retaining Ring	
8	455004	4	Flat Washer	
9	453011	2	Flat Washer, 3/8	
10	3006293	4	Plate, Side Cylinder Mounting	
11	400412	14	Screw, 1/2-13 x 2" Hex Head	
12	446154	14	Lockwasher, 1/2 Heavy	
13	444758	14	Locknut, 1/2-13 Center	
14	3004092	4	Spacer	
15	1003277	1	Pin, Cylinder Rod End Mounting	
16	452012	2	Flat Washer, 1/2	
17	3006249	2	Cylinder, Rear Lift	See 54.1
18	340061	2	Adapter, 90°	
19	340078	2	Adapter, 90°	
20	1003272	2	Pin, Side Cylinder Mounting	
21	400408	2	Screw, 1/2-13 x 1-1/2" Hex Head	
22	453017	2	Flat Washer, 1/2	
23	441606	2	Carriage Bolt, 1/4-20 x 3/4"	
24	403912	4	Screw, #10-24 x 5/8" Truss Head	
25 26	453023	2	Flat Washer, 1/4	
27	443102 444310	2 4	Nut, 1/4-20 Hex Nut, #10-24 Hex	
28	446118	4	Lockwasher, #10 Heavy	
29	452002	8	Flat Washer, #10	
30	441614	2	Carriage Bolt, 5/16-18 x 1"	
31	354081	2	Clamp, Wire Harness	
32	443106	2	Nut, 5/16-18 Hex	
33	446134	2	Lockwasher, 5/16	
34	3007392	2	Switch, Proximity	REFERENCE SW4 & SW9, See 68.1
35	3009026	2	Angle, Switch	NEI ENENGE 3114 & 3116, 335 3311
36	446128	2	Lockwasher, 1/4	
	110120	_	Lookwashol, 17 1	

#### 32.1 Front Deck Valves



Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	4135582	2	Valve, Deck	See 55.1
2	339989	4	Adapter, Straight	
3	441624	1	Carriage Bolt, 3/8-16 x 1"	
4	340070	4	Adapter, 90°	
5	340065	2	Adapter, 90°	
6	364945	2	Fitting, Diagnostic	
7	363030	2	Cover, Dust	
8	452008	6	Flat Washer, 3/8	
9	446142	3	Lockwasher, 3/8 Heavy	
10	443110	3	Nut, 3/8-16 Hex	
11	401225	2	Screw, 3/8-16 x 6-1/2" Hex Head	
12	3008820	2	Clamp, Double Hose	
13	3008357	1	Angle, L.H. Valve Mount	


### 33.1 Wing Deck Valves



9016-23

Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	4135582	2	Valve, Deck	See 55.1
2	339989	2	Adapter, Straight	
3	340070	6	Adapter, 90°	
4	363030	2	Cover, Dust	
5	365466	2	Fitting, Diagnostic	
6	401028	4	Screw, 3/8-16 x 3-1/4" Hex Head	
7	452008	4	Flat Washer, 3/8	
8	446142	4	Lockwasher, 3/8 Heavy	
9	443110	4	Nut, 3/8-16 Hex	


## 34.1 Side Deck Valve Supply



9016-31

Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	400264	2	Screw, 3/8-16 x 1-1/4" Hex Head	
2	446142	2	Lockwasher, 3/8 Heavy	
3	443110	2	Nut, 3/8-16 Hex	
4	4135253	1	Plate, Tube Mounting	
5	4135262	1	Hose, Pump to Right Side Tube	
6	4135408	1	Hose, Pump to Left Side Tube	
7	339963	2	Locknut, Bulkhead	
8	339899	2	O-Ring, SAE #10	
9	4135259	1	Tube, Right Side Deck Valve Supply	
10	4135260	1	Tube, Left Side Deck Valve Supply	


### 35.1 Front Deck Valve Supply



9016-32

Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	400264	1	Screw, 3/8-16 x 1-1/4" Hex Head	
2	452008	1	Flat Washer, 3/8	
3	446142	1	Lockwasher, 3/8 Heavy	
4	443110	1	Nut, 3/8-16 Hex	
5	1003607	1	Hose, Pump to Left Front Valve	
6	4135589	1	Hose, Pump to Right Front Valve	
7	339963	2	Locknut, Bulkhead	
8	339899	2	O-Ring, SAE #10	
9	4135409	1	Tube, Right Front Valve	
10	1003587	1	Hose, Pump to Tube	
11	4135425	1	Bracket, Tube	
12	473144	1	Tie Wrap (Not Shown)	


### **36.1 Pump Supply**



9016-30


Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	4135240	1	Hose, Rear Pump Suction	
2	4136342	4	Clamp	
3	3007775	2	Hose, Rear Pump Inlet	
4	4135233	1	Manifold, Rear Pump Suction	
5	4136343	2	Plate, Clamp	
6	359615	3	Clamp, Hose	
7	326112	5	Clamp, Hose	
8	400208	4	Screw, 5/16-18 x 4-1/2" Hex Head	
9	446136	4	Lockwasher, 5/16 Heavy	
10	443106	4	Nut, 5/16-18 Hex	
11	3007060	1	Hose, Front Pump Inlet	
12	4136341	1	Bracket, Rear Plumbing	
13	400264	2	Screw, 3/8-16 x 1-1/4" Hex Head	
14	446142	2	Lockwasher, 3/8 Heavy	
15	443110	2	Nut, 3/8-16 Hex	

#### 37.1 Return Manifold




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	1003891	1	Return Manifold	
2	400266	2	Screw, 3/8-16 x 1-1/2" Hex Head	
3	452008	2	Flat Washer, 3/8	
4	446140	2	Lockwasher, 3/8	
5	3007061	1	Hose, Return	
6	3008820	1	Clamp, Double Hose	
7	359615	2	Clamp, Hose	

#### **38.1 Traction Hydraulics**




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	1002769	2	Wheel Motor, Front	
	5003641	1	Brake Shoe Kit	
	5003642	1	<ul> <li>Mechanical Control Kit</li> </ul>	
	5003643	1	<ul> <li>Adjusting System Kit</li> </ul>	
	5003651	1	Motor Seal Kit	
2	340074	4	Adapter, 90°	
3	400410	20	Screw, 1/2-13 x 1-3/4" Hex Head	
4	446154	20	Lockwasher, 1/2 Heavy	
5	443118	20	Nut, 1/2-13 Hex	
6	1003307	2	Hose, Tee to Right Wheel Motor	
7	340147	2	Adapter, Tee	
8	340219	2	Adapter, Bulkhead Tee	
9	339965	2	Nut, Bulkhead	
10	1003308	2	Hose, Tee to Left Wheel Motor	
11	1003310	1	Hose, Traction Pump to Front Tee	
12	1003309	1	Hose, Traction Pump to Rear Tee	
13	339994	2	Adapter, Straight	
14	339989	4	Adapter, Straight	
15	1003313	4	Hose, 4WD Valve to Rear Motors	
16	1003311	1	Hose, Rear Tee to 4WD Valve	
17	1003312	1	Hose, Front Tee to 4WD Valve	
18	339990	4	Adapter, Straight	
19 20	5003421 5003422	2 2	Tire, 29 x 14-15 Ultra Trac TL Wheel	
20	363233	2	Inflation Valve	
22	3007683	12	Wheel Bolt, 1/2-20	
22	3007003	12	Wileer Bolt, 1/2-20	

#### 39.1 Return Hydraulics



Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	_	1	Return Manifold	See 37.1
2	1003573	1	Hose, Pump to Return Manifold	
3	1003575	1	Hose, 4WD Valve to Pump	
4	339911	1	O-Ring, SAE #10 Face Seal	
5	340065	1	Adapter, 90°	
6	1003604	2	Hose, Rear Wheel Motor Drain	
7	1003577	1	Hose, Right Tee to 4WD Valve	
8	339961	2	Locknut, Bulkhead	
9	340143	1	Adapter, Tee	
10	1003574	1	Hose, Right Tee to Left Tee	
11	340144	1	Adapter, Tee	
12	340215	2	Adapter, Bulkhead Tee	
13	1003988	1	Manifold, Cooler Inlet	
14	339966	1	Locknut, Bulkhead	
15	339899	3	O-ring, SAE #10	
16	1003862	1	Tube, Right Front Valve to Inlet	
17	1003860	1	Tube, Right Side Valve to Inlet	
18	1003861	1	Tube, Left Side Deck to Inlet	
19 20	1004266	1	Hose, Cooler Inlet to Cooler	
20	3006835 3009496	1 2	O-Ring, 1-3/4" O.D. x 1-1/2" I.D.	
21	400336	4	Flange Half, 1-1/4 SAE #20 Screw, 7/16-14 x 1-1/4 Hex Head	
23	446148	4	Lockwasher, 7/16 Heavy	
24	3007767	1	Hose, Cooler to Return Manifold	
25	3008673	2	Clamp, Constant Torque	
26	339974	2	Adapter, Straight	
27	340118	1	Adapter, Tee	
28	1003592	1	Hose, Tee to Return Manifold	
29	1003603	1	Hose, Right Motor to Left Motor	
30	365660	1	Grommet	
31	339909	2	O-Ring, SAE #6 Face Seal	
32	339972	2	Adapter, Straight	
33	2810188	1	Hose, Front Deck Motor Case Drain	
34	1003608	1	Hose, Back Pressure Valve Return	
35	339910	1	O-Ring, SAE #8 Face Seal	


#### 40.1 4WD Hose Clamps



9016-41

Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	400210	2	Screw, 5/16-18 x 5" Hex Head	
2	366114	2	Spacer	
3	3008792	5	Spacer Plate	
4	3008793	6	Clamp, Double Hose	
5	366424	2	Clamp, Hose	
6	452006	3	Flat Washer, 5/16	
7	443106	4	Nut, 5/16-18 Hex	
8	400204	1	Screw, 5/16-18 x 3-1/2" Hex Head	
9	444718	2	Nut, 5/16-18 Center	
10	473144	2	Tie Wrap (Not Shown)	Used on rear motor hoses after clamp.
11	365566	1	Clamp, Wire Harness	


## **41.1 Charge Pressure**



9016-40


Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	340069	1	Adapter, 90°	
2	340217	1	Adapter, Tee	
3	339963	1	Locknut, Bulkhead	
4	340377	1	Adapter, 90°	
5	1003878	1	Tube, 4WD Valve to Tee	
6	1003605	1	Hose, Tee to Pump	
7	1003865	1	Tube, Lift Valve to Filter	
8	1003864	1	Tube, Filter to Tee	

#### 42.1 Lift Valve Hydraulics




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	1003599	1	Hose, Right Side Cylinder Base End	
2	1003600	1	Hose, Right Side Cylinder Rod End	
3	1003601	1	Hose, Left Side Cylinder Base End	
4	1003602	1	Hose, Left Side Cylinder Rod End	
5	340167	1	Adapter, 90° Bulkhead	
6	339961	1	Nut, Bulkhead	
7	340143	1	Adapter, Tee	
8	1003591	2	Hose, Front Cylinders Rod End	
9	1003590	1	Hose, Lift Valve to Tee	
10	339909	2	O-Ring, SAE #6 Face Seal	
11	1003598	1	Hose, Right Front Cylinder Rod End	
12	1002940	1	Hose, Left Front Cylinder Rod End	
13 14	3008459 443106	1 4	Plate, Hose Retaining Clamp Nut, 5/16-18 Hex	
15	1003594	1	Hose, Steering Valve to Lift Valve	
16	1003394	1	Hydraulic Tank	See 23.1
17	_	1	Lift Valve	See 8.1
''			Liit vaivo	555 5.1

#### **43.1 Power Steering Hoses**



Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	1003876	1	Tube, RT Hose to Rod End Hose	
2	1003875	1	Tube, LT Hose to Base End Hose	
3	339961	2	Locknut, Bulkhead	
4	339909	2	O-Ring, SAE #6 Face Seal	
5	1003606	2	Hose, Valve to Cylinder Tubes	
6	1003593	1	Hose, Valve to Return Manifold	0 40 . 4
7	4000500	1	Hose, Steering Valve to Lift Valve	See 42.1
8	1003596 339979	1 2	Hose, Gear Pump to Valve Adapter, Straight	
10	340239	2	Adapter, Straight Bulkhead	
11	339961	2	Locknut, Bulkhead	
12	1003597	1	Hose, LT Tube to Cylinder Base End	
13	1003595	1	Hose, RT Tube to Cylinder Rod End	
10	1000000		Tiose, it i rube to cylinder ited End	


## **44.1 Engine Compartment Clamps**




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	3000359	2	Breaker, Circuit-50 Amp	REFERENCE CB1 & CB2, See 68.1
2	364774	2	Boot, Protective	
3	131905	1	Solenoid	
4	441606	2	Bolt, Carriage 1/4-20 x 3/4"	
5	443102	2	Nut, 1/4-20 Hex	
6	446130	3	Lockwasher, 1/4 Heavy	
7	364190	1	Clamp, 1-1/2"	
8	333801	1	Clamp, Hose	
9	3008820	1	Clamp, Double Hose	
10	365980	1	Bolt, M12 x 1.25 x 18 Hex Head	
11	446152	1	Lockwasher, 1/2	

#### **45.1 Wire Harness Routing**


- A Instrument Panel
- B Oil Level, Horn and Seat Relay
- C Front Limit Switch and Cruise Magnet
- D Front Deck Valves
- **E Neutral and Forward Switches**
- F Seat Switch and Air Ride
- **G** Parking Brake
- H Right Wing Deck Valve
- I Right Deck Limit Switch J - Left Wing Deck Valve and Charge Filter



L - 4WD Valve











**Glow Plug Light Adapter Located under Instrument Panel** 



**Kubota Key Switch Adapter Located under Instrument Panel** 




9016-44

Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	4116909	1	Wire Harness, Console	
2	4135549	1	Wire Harness, Chassis	
3	4133830	1	Wire Harness, Engine	
4	1004931	1	Wire Harness, Glow Plug Light	REFERENCE U5.2, See 68.1
5	2822523	1	Wire Harness, Kubota Keyswitch	

### 46.1 Steering Valve


Part Number 1002800



Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	443108	4	Locknut, 5/16-18 Center	
2	N/S	1	Port Cover	
3	С	1	Seal, O-Ring	
4	С	4	Seal, O-RIng	
5	С	4	Seal, O-RIng	
6	443828	1	Nut, 5/8-18 Hex Jam	
7	N/S	4	Special Bolt	
8	N/S	1	Port Manifold	
9	В	3	Spring, Port Side	
10	503387	1	Hex Drive	
11	A and E	9	Needle Roller	
12	503398	1	Valve Ring	
13	503398	1	Valve Plate	
14	В	3	Spring, Shaft Side	
15	554854	1	Isolation Manifold	
16	551105	1	Drive Link	
17	N/S	1	Metering Ring	
18	Α	11	Screw, Socket Head	
19	С	1	Seal, Commutator	
20	Α	1	Commutator Cover	
21	Α	1	Commutator RIng	
22	Α	1	Commutator	
23	Α	1	Spacer	
24	Α	1	Rotor	
25	Α	1	Stator	
26	Α	1	Drive Plate	
27	554855	1	Spacer	
28	554856	1	Thrust Bearing	
29	С	1	Face Seal	
30	N/S	1	Ball, 9/32"	
31	554857	1	Seal, Spacer	
32	N/S	1	Upper Cover Plate	
33	D	1	Shaft	
34	D	1	Retaining RIng	
35	D	1	Bushing	
36	D	1	Seal	
37	D	1	Jacket	
38	557733	1	Relief Valve Cartridge	
39	339979	5	Adapter, Straight	
			Service Kits	
А	5003548	1	Metering Assembly Kit	
В	502924	1	Spring Kit	
С	557738	1	Seal Kit	
D	5003219	1	Jacket Tube Kit	
Е	502925	1	Needle Roller Kit	

#### **47.1 Air Suspension**


Part No. 5003625



Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	N/S	1	Lower Housing	
2	N/S	1	Scissors	
3	N/S	1	Upper Housing	
	5003627	1	Compressor Kit	
4	N/S	1	<ul> <li>Compressor</li> </ul>	
5	N/S	1	Tie Wrap	
6	N/S	1	<ul> <li>Clamp, Compressor</li> </ul>	
7	N/S	4	Tie Wrap	
8	N/S	1	Bushing, Strain	
	5003628	1	Air Fitting/Tubing Kit	
9	N/S	1	Braided Sleeve	
10	N/S	1	Fitting, Tee	
11	N/S	1	• 3/16 O.D. Tubing	
12	N/S	1	• 3/16 O.D. Tubing	
13	N/S	1	• Fitting, 90°	
14	N/S	1	<ul> <li>Fitting, Straight</li> </ul>	
	5003629	1	Boot and Clip Kit	
15	N/S	1	Boot with Label	
16	N/S	21	Clip, Christmas Tree	
17	N/S	6	Clip, Christmas Tree	
	5003630	1	Airspring Kit	
18	N/S	1	<ul> <li>Airspring</li> </ul>	
19	N/S	1	Cap Screw	
20	N/S	1	Cap Screw	
21	5003631	1	Valve Kit	
	5003632	1	Damper Kit	
22	N/S	2	<ul> <li>Bearing, Flanged</li> </ul>	
23	N/S	1	Threaded Pin	
24	N/S	1	Nut, Hex Lock	
25	N/S	1	<ul> <li>Damper</li> </ul>	
	5003633	1	Miscellaneous Kit	
26	N/S	2	Shaft, Threaded	
27	N/S	4	Bearing, Flanged	
28	N/S	2	Bumper	
29	N/S	4	• Roller	
30	N/S	2	Tether	
31	N/S	4	Jam Nut	
32	N/S	4	<ul> <li>Lockwasher</li> </ul>	

### 48.1 Seat Assembly


Part No. 5003626



9016-63

Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	5003634	1	Pad, Back	
2	5003635	1	Pad, Seat	
3	5003636	1	Arm Rest, Left Side	
4	5003637	1	Arm Rest, Right Side	
5	5003690	1	Adjuster Assembly	
6	554390	1	Seat Switch	REFERENCE SW2, See 68.1
7	3003928	1	Literature Pouch	
8	409757	2	Screw, Seat Switch	
9	5003769	1	Wire Assembly	

# 49.1 Steering Cylinder Part No. 5003541




9016-64

Item	Part No.	Qty.	Description	Serial Numbers/Notes
	5003542	1	Seal Kit	
1	N/S	1	Retaining Ring	
2	N/S	1	O-Ring, Piston	
3	N/S	1	Seal, Piston	
4	N/S	1	Seal, Rod	
5	N/S	1	Wiper	
6	N/S	1	<ul> <li>Backup Ring, Gland</li> </ul>	
7	N/S	1	O-Ring, Gland	
8	443126	1	Nut, 5/8-11 Hex	
9	5003543	1	Socket Assembly	
10	N/S	1	Piston	
11	N/S	1	Screw, Piston	
12	471214	2	Grease Fitting	
13	N/S	1	Gland	
14	N/S	2	Nut, 7/8-14 Castle	

#### **50.1 Rear Wheel Motor**

**Part Number 5003540** 


Serial No. All Serial No. All



Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	558066	8	Screw, Torx	
2	5002110	1	Front Retainer	
3	558063	1	Shaft and Bearing Kit	
4	557624	1	Nut, Hex	
5	557623	1	Key	
6	558064	1	Bearing Housing	
7	557629	1	Drive	
8	5003590	1	Geroler	
9	557632	1	Drive, Valve	
10	557631	1	Plate, Valve	
11	557633	1	Valve	
12	557637	1	Balance Ring and Pins	
<b>♦</b> 13	557634	1	Seal, Inner Face	
<b>♦</b> 14	557635	1	Seal, Outer Face	
15	557636	2	Spring	
16	557650	3	Bolt, 5-3/4"	
17	5003591	1	Housing, Valve	
18	557639	2	Check Plug Assembly	
19	557642	2	Spring	
20	557640	2	Ball, Steel	
21	5000318	1	Bolt	
22	557641	1	Plug	

## **51.1 Deck Return Canister**

Part Number 5003371




9016-47

Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	•	1	O-Ring	
2	•	1	Back Up Ring	
3	•	1	Loaded U-Cup	
4	•	1	Rod Wiper	
5	471214	1	Grease Fitting	
6	443132	1	Nut, 3/4-16 Hex	
7	5003428	1	Collar Assembly	
•	5003427	1	Seal Kit	Gold Star Return Canisters
•	5003662	1	Seal Kit	HDM Return Canisters

## 52.1 Lift Valve


#### Part Number 1001802



Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	558005	1	Plug Assembly, Relief Valve	
2	500745	3	Plug Assembly, Port Adapter	
3	545914	3	Spring, Lockout	
4		3	Poppet Assembly	
5	500736	3	Seat Assembly	
6	5001599	1	Plunger, Lockout	
7	5001603	2	Plunger, Lockout	
8	558004	3	Cap Assembly	
9	558007	3	Retaining Ring	
10	5001613	1	Seat	
11	558011	3	Spacer	
12	5001616	3	Spring, Spool Centering	
13	545921	3	Bushing	
14		6	O-Ring	
15	5001614	1	Spring Relief Valve (Yellow)	
16	5001615	1	Poppet, Relief Valve	
17	•	3	Plug Assembly, Plunger Detent	
18 19	•	3 3	Spring, Detent	
20	351122	3	Plunger, Detent Hex Plug Assembly	
21	500750	3	Plug Assembly	
22	558008	3	Washer	
23	545925	AR	Shim (.015 Thick)	
20	545926	AR	Shim (.010 Thick)	
	545927	AR	Shim (.035 Thick)	
24	546112	AR	Disc, Plain	
25	5001617	3	Wiper Seal	
•	5001612	1	Detent Reapir Kit	
	558010	1	Seal Kit	
_		•		

## 53.1 Front Lift Cylinder

Part Number 3006008




9016-49

Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	•	1	PSP Seal	
2	•	2	Back Up Ring	
3	•	1	O-Ring	
4	•	1	O-Ring	
5	•	1	Back Up Ring	
6	•	1	Internal Snap Ring	
7	•	1	External Snap Ring	
8	•	1	Loaded U-Cup	
9	•	1	Rod Wiper	
10	471214	3	Grease Fitting	
11	5003415	1	Bushing	
12	5003566	2	Bushing	
•	5003414	1	Seal Kit	Gold Star Cylinders
•	5003667	1	Seal Kit	HDM Cylinders

## **54.1 Wing Lift Cylinders**

Part Number 3006249




9016-50

Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	•	1	PSP Seal	
2	•	2	Back Up Ring	
3	•	1	O-Ring	
4	•	1	O-Ring	
5	•	1	Back Up Ring	
6	•	1	Internal Snap Ring	
7	•	1	External Snap Ring	
8	•	1	Loaded U-Cup	
9	•	1	Rod Wiper	
10	471214	2	Grease Fitting	
•	5003413	1	Seal Kit	Gold Star Cylinders
•	5003659	1	Seal Kit	HDM Cylinders

### 55.1 Deck Valve

#### **Part Number 4135582**




9016-51

Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	5002911	1	Relief Valve	
	5003579	1	Seal Kit	
2	5002912	1	Relief Valve	
	5003554	1	Seal Kit	
3	3010199	1	Plug, SAE #6	Located opposite Diagnostic port
	339897	1	O-Ring	
4	5002913	1	Solenoid Valve	
	5003579	1	Seal Kit	
5	4134530	1	Coil, 12 Volt DC	REFERENCE SOL2, SOL3, SOL4, SOL8, See 68.1

### **56.1 4WD Valve**

Part Number 4135556



Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	5003342	1	Check Valve	
	5003582	1	Seal Kit	
2	5003344	1	Shuttle, Hot Oil	
	5003582	1	Seal Kit	
3	5003346	1	3-Way Spool	
	5003583	1	Seal Kit	
4	5003348	1	Solenoid Vlave	
	5003583	1	Seal Kit	
5	4134530	1	Coil, 12 Volt DC	REFERENCE SOL6 See 68.1
6	5003350	1	Solenoid Valve	
	5003578	1	Seal Kit	
7	4134532	1	Coil, 12 Volt DC	REFERENCE SOL7 See 68.1
8	5003353	3	Plug, SAE #6	
	339897	3	O-ring	
9	5003353	1	Plug, Orifice	

5

#### 57.1 Decals - Decks



Serious injury or death can result from blade contact or from objects being thrown very long distances

- Do not operate machine with discharge chute or guards flipped up or removed.
- Do not operate machine with bent components or with implement in raised position.
- Keep yourself and others away from the mower when in operation

1

Deck Flip Up Procedure

- Rotate anti-sway mechanism downward. (Located under tractor floorboard)
- 2. Start tractor engine and raise deck until gage wheels are off the ground.
- 3. Remove cut height adjustment pins from rear gage wheel arms.
- 4. Raise deck to full raised position.
- 5. Turn tractor engine off.

3

Rotate front of deck upward until support is securely latched.

Cut Height lumber of Spacers Under Mount Middle Lower 0 1-1/2 Lower Thrust 2 2 Washer Mount Lower and -2-1/2 Lower Leveling 2-1/2 Middle 0 3 Middle 3-1/2 Middle 2 Middle 4 3 Spacers Under 4 Upper 0 Mount 4-1/2 Upper 2 5 Upper 5-1/2 Upper 3

Never reposition the thrust washer(s) (1/16 th'k) and leveling washer(s) (1/8 th'k) when setting cut height


B © D E  $\bigcirc$ 1234 (5) 6<sub>7</sub> 8 E R Wheel Mounting 3 Α F 1-1/2 В F 2 2 С F Wheel Mounting Instructions While Roatating wheel, tighten nut until wheel is difficult to 2-1/2 3 D F rotate.

2. Loosen nut 1/4 turn or just until wheel rotates freely.

3. Lock nut into place using F F 3 4 3-1/2 В F С F 4 6 second nut. Do not allow first nut to rotate when 4-1/2 7 D F tighteneing second nut secu Rotate wheel to check for free rotation with zero end 5 8 Ε F 5-1/2




9016-64




9016-63

Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	3009317	5	Decal, Caster Cut Height	
2	3009318	2	Decal, Gage Wheel Cut Height	
3	3009319	1	Decal, Flip Up Deck	
4	366609	2	Decal, No Step	
5	3002502	7	Decal, Danger	



Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	1003430	8	Hinge Assembly	
2	400286	12	Screw, 3/8-16 x 2-3/4" Hex Head	
3	446142	32	Lockwasher, 3/8 Hvy	
4	444762	32	Locknut, 3/8-16 Center	
5	400264	12	Screw, 3/8-16 x 1-1/4" Hex Hd	
6	453011	20	Flat Washer, 3/8	
7	3007678	4	Pin, Clevis	
8	460050	4	Cotter Pin, 3/16 x 1-1/4"	
9	3003939	2	Wheel, Deck	
10	3003714	2	Spacer, Wheel	
11	3004113	36	Bushing	
12	453020	4	Flat Washer, 5/8	
13	446152	2	Lockwasher, 1/2	
14	444758	2	Locknut, 1/2-13 Center	
15	400420	2	Screw, 1/2-13 x 3-1/2" Hex Head	
16	1003325	1	Skid Assembly, Anti Scalp	
17	1003321	1	Skid Assembly, Anti Scalp	
18	441624	8	Carriage Bolt, 3/8-16 x 1"	
19	3008840	2	Flap, Rear	
20	3009175	2	Hold Down, Drag Flap	
21	441606	8	Carriage Bolt, 1/4-20 x 3/4"	
22	452004	2	Flat Washer, 1/4	
23	444708	8	Locknut, 1/4-20 Center	
24	_	1	Front Deck Center Section	See 59.1
25	_	1	Right Side Winglet	See 60.1
26	_	1	Left Side Winglet	See 60.1


### **59.1 Front Deck Center Section**



Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	5003188	1	Deck, Front Assembly	
2	352936	2	Bushing	
3	2810069	3	Motor, Spindle Assembly	
	5003763	1	Seal Kit	
4	REF	1	Serial Plate, Front Deck	
5	440124	18	Carriage Bolt, 3/8-16 x 1-3/4"	
6	453011	26	Flat Washer, 3/8	
7	446142	40	Lockwasher, 3/8 Hvy	
8	444762	22	Locknut, 3/8-16 Center	
9	1003424	1	Bracket Assembly, RH	
10	1003425	1	Bracket Assembly, LH	
11	400274	6	Screw, 3/8-16 x 2-1/2" Hex Head	
12	400262	14	Screw, 3/8-16 x 1" Hex Head	
13	361723	2	Stop, Rubber	
14	163302	1	Roller	
15	552824	2	<ul> <li>Bushing</li> </ul>	
16	455048	2	Flat Washer, 3/4	
17	1003429	1	Shaft Assembly, Roller	
18	3007374	1	Plate, Shaft Support	
19	3008388	3	Adapter, Blade	
20	2810030	3	Bar, Rotary Mower Cutter	Models 70528 & 70529
20	4119024	3	Bar, Rotary Mower Cutter	Model 70530 Only
21	3007764	3	Washer, Blade	
22	400410	3	Screw, 1/2-13 x 1-3/4" Hex Head	
23	3007368	1	Arm, Winglet Support	
24	3007369	1	Arm, Winglet Support	
25	2810195	1	Angle, Bulkhead	
26	443110	18	Nut, 3/8-16 Hex	


### **60.1 Front Deck Winglets**

(Right Winglet Shown)



Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	5003186	1	Deck, RH Winglet	
2	5003187	1	Deck, LH Winglet	
3	2810069	2	Motor, Spindle Assembly	
	5003763	1	Seal Kit	
4	366613	4	Shim	
5	440124	12	Carriage Bolt, 3/8-16 x 1-3/4"	
6	453011	24	Flat Washer, 3/8	
7	446142	20	Lockwasher, 3/8 Hvy	
8	400264	4	Screw, 3/8-16 x 1-1/4" Hex head	
9	366473	2	Bumper, Arm	
10	400262	8	Screw, 3/8-16 x 1" Hex Head	
11	444762	4	Locknut, 3/8-16 Center	
12	3003939	2	Wheel, Deck	
13	3003714	2	Spacer, Wheel	
14	3004113	4	Bushing	
15	455012	2	Flat Washer, 1/2	
16	446152	2	Lockwasher, 1/2	
17	444758	2	Locknut, 1/2-13 Center	
18	400420	2	Screw, 1/2-13 x 3-1/2" Hex Head	
19	3008388	2	Adapter, Blade	
20	2810030	2	Bar, Rotary Mower Cutter	Models 70528 & 70529
20	4119024	2	Bar, Rotary Mower Cutter	Model 70530 Only
21	400410	2	Screw, 1/2-13 x 1-3/4"Hex Head	
22	3007764	2	Washer, Blade	
23	3007376	2	Arm, Winglet Support, Front	
24	443110	12	Nut, 3/8-16 Hex	


## **61.1 Front Deck Hydraulics**



Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	340070	2	Adapter, 90°	
2	339989	8	Adapter, Straight	
3	340055	2	Adapter, 90°	
4	340095	3	Adapter, Tee	
5	REF	1	Hose, Front Deck Motor Case Drain	See 39.1
6	1003557	2	Hose, Winglet	
7	2810190	2	Hose, Winglet Motor Drain	
8	1003607	1	Hose, Left Center to Center Motor	
9	2810189	1	Hose, Tee to Left Center Motor Drain	
10	2810191	2	Hose, Right Center and Center Drain	
11	1003559	1	Hose, Right Valve to Right Winglet	
12	1003556	1	Hose, Left Valve to Left Center	
13	1003558	1	Hose, Left Winglet to Left Valve	
14	1003562	1	Hose, Center Motor to Right Valve	
15	473144	6	Tie Wrap	
16	363514	3	Clamp, 1-1/8" Diameter	
17	400188	3	Screw, 5/16-18 x 1" Hex Head	
18	443106	2	Nut, 5/16-18 Hex	
19	340214	1	Adapter, Bulkhead Tee	
20	339960	1	Locknut, Bulkhead	
21	446134	3	Lockwasher, 5/16	
22	453009	1	Flat Washer, 5/16	
		1		


### **62.1 Wing Decks**

Right Wing Shown




Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	5003190	1	Deck, Right Wing	
2	5003189	1	Deck, Left Wing	
3	2810069	6	Motor, Spindle Assembly	
	5003763	1	Seal Kit	
4	REF	2	Wing Deck Serial Plate	
5	440124	36	Carriage Bolt, 3/8-16 x 1-3/4"	
6	453011	48	Flat Washer, 3/8	
7	446142	50	Lockwasher, 3/8 Hvy	
8	444762	14	Locknut, 3/8-16 Center	
9	116686	2	Deck Mount Assembly	
10	363574	4	Bushing	
11	363562	4	Bushing	
12	471214	6	Fitting, Grease 1/4-28	
13	363568	4	Washer, Thrust	
14	163306	4	Pin Assembly	
15	400264	4	Screw, 3/8-16 x 1-1/4" Hex Head	
16	3008388	6	Adapter, Blade	
17	2810030	6	Bar, Rotary Mower Cutter	Models 70528 & 70529
17	4119024	6	Bar, Rotary Mower Cutter	Model 70530 Only
18	3007764	6	Washer, Blade	
19	400410	6	Screw, 1/2-13 x 1-3/4" Hex Head	
20	1003321	1	Skid, Right Wing Anti-Scalp	
21	1003325	1	Skid, Left Wing Anti Scalp	
22	400420	4	Screw, 1/2-13 x 3-1/2" Hex Head	
23	3004113	8	Bushing	
24	3003714	4	Spacer, Wheel	
25	3003939	4	Wheel, Deck	
26	361723	2	Stop, Rubber	
27	446152	4	Lockwasher, 1/2	
28	444758	4	Locknut, 1/2-13 Center	
29	441624	8	Carriage Bolt, 3/8-16 x 1"	
30	443110	36	Nut, 3/8-16 Hex	

### **63.1 Wing Deck Hydraulics**




**Right Wing Deck Hydraulics** 



**Left Wing Deck Hydraulics** 

Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	340070	4	Adapter, 90°	
2	339989	8	Adapter, Straight	
3	339972	2	Adapter, Straight	
4	340095	4	Adapter, Tee	
5	1003580	2	Hose, Outside to Center Motor	
6	1003579	2	Hose, Inside to Center Motor	
7	2810194	2	Hose, Center to Inside Motor Drain	
8 9	2810193	2 2	Hose, Outside to Center Motor Drain	
10	2810192 1003584	2	Hose, Wing Motor Drain to Tee Hose, Wing Motor Pressure	
11	1003584	2	Hose, Wing Motor Return	
12	359860	2	Clamp, Hose	
13	400206	2	Screw, 5/16-18 x 4" Hex Head	
14	473144	6	Tie Wrap	
15	446136	2	Lockwasher, 5/16 Heavy	
16	443106	2	Nut, 5/16-18 Hex	
17	REF	2	Adapter, Bulkhead Tee	See 39.1

## **64.1 Caster Assemblies**




9016-62

Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	1004276	8	Yoke, 11" Tire	Wing Decks Only
1	1004275	2	Yoke, 13" Tire	Front Deck Only
2	1004277	10	Tube, Yoke Pivot	
3	363539	2	Bushing	
4	471214	1	Grease Fitting	
5	366593	20	Spacer, Caster Wheel	
6	365772	30	Spacer, Caster Wheel	
7	361648	10	Washer, Thrust	
8	1004023	8	Wheel and Tire, 11"	Wing Decks Only, See 65.1
8	1004024	2	Wheel and Tire, 13"	Front Deck Only, See 65.1
9	441690	8	Carriage Bolt, 1/2-13 x 7"	Wing Decks Only
9	441689	2	Carriage Bolt, 1/2-13 x 8-1/2"	Front Deck Only
10	443118	20	Nut, 1/2-13 Hex	
11	401028	20	Screw, 3/8-16 x 3-1/4" Hex Head	
12	446142	20	Lockwasher, 3/8 Heavy	
13	443110	20	Nut, 3/8-16 Hex	
14	3004894	10	Pin, Klik Type	

## **65.1 Wheel and Tire Assemblies**


### Part Numbers 1004023 and 1004024



9016-61


Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	550346	1	Tire, 11 x 4-5 Smooth	1004023 Only
1	5003200	1	Tire, 13 x 6.5-6 Multi Rib	1004024 Only
2	5003196	1	Wheel	1004023 Only
2	5003201	1	Wheel	1004024 Only
3	5003197	2	Grease Seal	
4	5003198	2	Bearing Cone	
5	360111	1	Inflation Valve	
6	346883	2	Spacer	
7	5003199	1	Spacer	1004023 Only
7	5003202	1	Spacer	1004024 Only


## 66.1 Gage Wheels and Latch



Item	Part No.	Qty.	Description	Serial Numbers/Notes
1	461495	1	Clevis pin, 1/2 x 2-1/2"	
2	460028	2	Cotter Pin, 1/8 x 1"	
3	1003423	2	Yoke, Gage Wheel	
4	3007442	2	Spacer, Arm Pivot	
5	3004113	4	Bushing	
6	441690	4	Carriage Bolt, 1/2-13 x 7"	
7	446152	2	Lockwasher, 1/2	
8	443118	8	Nut, 1/2-13 Hex	
9	3007679	2	Clevis Pin, 5/8 x 9-5/16"	
10	342675	2	Snap Ring	
11	1003902	1	Latch, Standup	
12	3008471	1	Spring, Torsion	
13	453017	1	Flat Washer, 1/2	
14	3008478	1	Rod, Latch	
15	453009	1	Flat Washer, 5/16	
16	460014	1	Cotter Pin, 3/32 x 3/4"	0 054
17	1004023	2	Wheel and Tire, 11"	See 65.1
18	3010075	1	Deflector, Left Side Grass	
19	3010074	1	Deflector, Right Side Grass	
20	441614	4	Carriage Bolt, 5/16-18 x 1"	
21 22	452006 444718	4	Flat Washer, 5/16 Locknut, 5/16-18 Center	


### **67.1 Hydraulic Schematic**






#### **68.1 Electrical Schematic**

#### Interlock, Starting, Charging and Cruise Control Circuits




### **68.1 Electrical Schematic**

#### 4WD, Mow and Seat Control Circuits



### **68.1 Electrical Schematic**

#### **Gauges and Warning Lights**



Item	Reference Illustration	Part Number	Description	Serial Numbers/Notes
B1	See 16.1	4108140	Battery	
CB1	See 44.1	3000359	50 Amp Circuit Breaker - Main	
CB-2	See 44.1	3000359	50 Amp Circuit Breaker - Pre Heat	
D1	See 6.1	555846	Interlock System Diode	
D2	See 6.1	555846	Test Diode	
D3	See 6.1	555846	Alarm Diode	
D4	See 6.1	555846	4WD Diode	
F1	See 6.1	5003278 Spare 5 Amp Fuse		
F2	See 6.1	5003278 Spare 5 Amp Fuse		
F3	See 6.1	5003281	Spare 15 Amp Fuse	
F4	See 6.1	5003281	Spare 15 Amp Fuse	
F5	See 6.1	5003278	5 Amp Fuse - Ignition Switch	
F6	See 6.1	5003278	5 Amp Fuse - Gauges	
F7	See 6.1	5003278	5 Amp Fuse - Interlock Circuit	
F8	See 6.1	5003281	15 Amp Fuse - Air Ride Seat	
F9	See 6.1	5003278	5 Amp Fuse - Cruise Control	Optional Cruise Control Kit
F10	See 6.1	5003278	5 Amp Fuse - 4WD	
F11	See 6.1	5003278	5 Amp Fuse - Deck Limit Switches	
F12	See 6.1	5003281	15 Amp Fuse - Mow Circuit	
K1	See 6.1	3001307	Interlock Relay	
K2	See 6.1	3001307	Run Circuit Relay	
K3	See 6.1	3001307	Start Circuit Relay	
K4	See 6.1	3001307	Brake (Start) Relay	
K5	See 6.1	3001307	Brake (Run) Relay	
K6	See 6.1	3001307	Neutral (Start) Relay	
K7	See 6.1	3001307	Neutral (Run) Relay	
K8	See 6.1	3001307	Neutral (Cruise Control) Relay	
K9	See 6.1	3001307	Left Mow Relay	
K10	See 6.1	3001307	Center Mow Relay	
K11	See 6.1	3001307	Right Mow Relay	
K12	See 6.1	3001307	Cruise Control Relay	
K13	See 6.1	3001307	4WD Relay	
K14	_	131905	Starter Solenoid	
K15	See 23.1	3001307	Run Circuit Cutout Relay	
K16	See 23.1	3001307	Auxiliary Circuit Relay	
K17	See 23.1	3001307	Ignition Circuit Relay	
M1	Not Shown		Starter Motor	Included with Engine
R1	Not Shown		Air Intake Pre Heat Timer	Optional Cold Start Kit
SOL1	Not Shown	4404500	Fuel Solenoid	Included with Engine
SOL2	See 55.1	4134530	Left Wing Mow Solenoid Coil	Included in 1004337 Deck Valve
SOL3	See 55.1	4134530	Center Mow Solenoid 1 Coil	Included in 1004337 Deck Valve
SOL4	See 55.1	4134530	Right Wing Mow Solenoid Coil	Included in 1004337 Deck Valve
SOL5	Not Shown	3008975	Cruise Control Magnet	Optional Cruise Control Kit
SOL6	See 56.1	4134530	4WD Solenoid Coil	Included in 1002977 4WD Valve

## HR-9016

Item	Reference Illustration	Part Number	Description	Serial Numbers/Notes
SOL7	See 56.1	4134532	4WD Reverse Solenoid Coil	Included in 1002977 4WD Valve
SOL8	See 55.1	4134530	Center Mow Solenoid 2 Coil	Included in 1004337 Deck Valve
SW1	See 6.1	2810269	Ignition Switch	
SW2	See 48.1	554390	Seat Switch	
SW3	See 6.1	2721505	PTO Switch	
SW4	See 31.1	3007392	Left Wing Limit Switch	
SW5	Not Shown	3006442	Cruise Control Switch	Optional Cruise Control Kit
SW6	See 8.1	3007392	Neutral Switch	
SW7	See 10.1	3007392	Parking Brake Switch	
SW8	See 28.1	3007392	Front Limit Switch	
SW9	See 31.1	3007392	Right Wing Limit Switch	
SW10	See 8.1	3007392	Forward Switch	
SW11	See 23.1	3009203	Hydraulic Level Switch	
SW12	See 6.1	3006446	4WD Reverse Switch	
SW13	See 6.1	3006436	4WD Switch	
SW14	See 6.1	3006446	Test Switch	
SW15	See 11.1	556419	Charge Filter Switch	
SW16	Not Shown		Engine Oil Switch	Included with Engine
SW17	See 22.1	363996	Temperature Switch	
SW18	Not Shown	3007392	Left Brake Pedal Switch	Optional Cruise Control Kit
SW19	Not Shown	3007392	Right Brake Pedal Switch	Optional Cruise Control Kit
U1	Not Shown		Pre Heat Timer Relay	Optional Pre Heat Kit
U2	See 23.1	3009544	Seat Time Delay Relay	
U3	See 6.1	162723	Hour Meter	
U4	See 23.1	3006639	Fuel Sender	
U5	See 6.1	1002679	Light Gauge	
U5.2	See 45.1	1004931	Glow Plug Light	
U6	See 22.1	3008821	Temperature Sender	
U7	Not Shown		Alternator	Included with Engine
U8	See 6.1	366751	Hydraulic Oil Light	
U9	See 6.1	365943	Fuel Gauge	
U10	See 6.1	3005121	Temperature Gauge	
U11	See 23.1	366670	Alarm	
U12	See 47.1	5003625	Air Ride Seat Suspension	

# Fluids and Compounds


	Hydraulic Fluid*	
5001405	Two 2-1/2 Gallon Container of ISO VG68 Oil	
5001404	One 5 Gallon Pail of ISO VG68 Oil	
2500548	Two 2-1/2 Gallon Container of 10W30 Oil	
2500546	One 5 Gallon Pail of 10W30 Oil	
503409	Two 2-1/2 Gallon Container of ATF Fluid	
503407	One 5 Gallon Pail of ATF Fluid	
	2-Cycle Oil	A
554600	Twenty Four 16 Ounce Plastic Container	
554599	Twenty Four 8 Ounce Plastic Container	
	Grease	
5000067	One 5 Gallon Pail OO-Grease	
5000068	Twenty Four 8 Ounce Tube OO-Grease	
	Paint	_
5003469	16 Ounce Gray Aerosol	
554598	Six 12 Ounce Orange Aerosol	
2500789	Twelve 1 Quart Can Orange	
546409	Two 1 Gallon Can Orange	
	Lapping Compound	
5002488	One 10 Pound Pail of 80 Grit	
5002490	One 25 Pound Pail of 80 Grit	
5002489	One 10 Pound Pail of 120 Grit	
5002491	One 25 Pound Pail of 120 Grit	_
	Specialty Compound	
365422	5.3 Ounce Tube of Electrical Insulating Gel	
5001581	14 Ounce Can of Lubriplate Multi Lube A	
	Biodegradable Hydraulic Fluid*	
5003102	One 55 Gallon Drum TGTSP GreensCare 68	
5003103	One 5 Gallon Pail TGTSP GreensCare 68	
5003105	One 55 Gallon Drum TGTSP GreensCare 46	
5003104	One 5 Gallon Pail TGTSP GreensCare 46	
4115976	One 55 Gallon Drum TGTSP GreensCare 32	
4115977	One 5 Gallon Pail TGTSP Greens Care 32	
5003106	Twenty Four 14 Ounce Tube Greens Care Grease	
	O-Ring Kit	
5002452	SAE O-Ring Boss (3/32 ~ 2" Tube O.D.)	
5002453	Common O-Ring Kit	
5002454	O-Ring Face Seal ORFS (-4 ~ -24 ORS Tube Size)	
	Right Start Kit for New Machines	
	See your local TGTSP Dealer	
	On-Time Maintenance Kit	
	See your local TGTSP Dealer	
Defer to the On	erator's manual or the Parts & Maintenance Manual for the co	prost budraulia ail requiremente for vour machine

<sup>\*</sup> Refer to the Operator's manual or the Parts & Maintenance Manual for the correct hydraulic oil requirements for your machine.

Textron Golf, Turf & Specialty Products offers a High Usage Parts Catalog illustrating commonly used Parts through easy to read line Drawings. See your local TGTSP Dealer for a copy.

#### Serial No. All

### 69.1 O-Ring Chart



Adapter Part Number.	Dash Size	Adapter Type	(W) O-Ring	(X) O-Ring	(Y) O-Ring	(Z) O-Ring
339972	4-4	Straight Adapter	339908	339896		
339974	4-6	Straight Adapter	339908	339897		
339979	6-6	Straight Adapter	339909	339897		
339984	8-8	Straight Adapter	339910	339898		
339989	10-10	Straight Adapter	339911	339899		
339990	10-12	Straight Adapter	339911	339900		
339994	12-12	Straight Adapter	339912	339900		
339996	12-16	Straight Adapter	339912	339901		
339999	16-16	Straight Adapter	339913	339901		
340026	6-6	45° Adapter	339909	339897		
340027	6-8	45° Adapter	339909	339898		
340029	8-8	45° Adapter	339910	339898		
340055	4-4	90° Adapter	339908	339896		
340061	6-6	90° Adapter	339909	339897		
340062	6-8	90° Adapter	339909	339898		
340065	8-6	90° Adapter	339910	339897		
340069	10-8	90° Adapter	339911	339898		
340070	10-10	90° Adapter	339911	339899		
340074	12-12	90° Adapter	339912	339900		
340075	12-16	90° Adapter	339912	339901		
340077	16-16	90° Adapter	339913	339901		
340078	6-6	90° Adapter	339909	339897		
340095	4-4-4	Straight Thread Branch Tee	339908	339908	339896	
340118	4-4-4	Swivel Run Tee	339908	339908		
340143	6-6-6	Swivel Branch Tee	339909	339909		
340144	8-8-8	Swivel Branch Tee	339910	339910		
340147	16-16-16	Swivel Branch Tee	339913	339913		
340167	6-6	90° Bulkhead Adapter	339909	339909		
340214	4-4-4	Bulkhead Run Tee	339908	339908	339908	
340215	6-6-6	Bulkhead Run Tee	339909	339909	339909	
340217	10-10-10	Bulkhead Run Tee	339911	339911	339911	
340219	16-16-16	Bulkhead Run Tee	339913	339913	339913	
340239	6-6	Union Bulkhead Adapter	339909	339909		
340269	10-12-12	Straight Thread Run Tee	339911	339899	339912	
340377	10-10	90° Swivel Adapter	339911			

:	SAE Boss O-Rings	5	ORS Face Seal O-Rings			
Dash Size	Thread Size	O-Ring	Tube Size	Thread Size	O-Ring	
4	7/16-20	339896	4	9/16-18	339908	
6	9/16-18	339897	6	11/16-16	339909	
8	3/4-16	339898	8	13/16-16	339910	
10	7/8-14	339899	10	1-14	339911	
12	1 1/16-12	339900	12	1 3/16-12	339912	
14	1 3/16-12	459296	16	1 7/16-12	339913	
16	1 5/16-12	339901	20	1 11/16-12	339914	
20	1 5/8-12	339902	24	2-12	339915	
24	1 7/8-12	339903				
32	2 1/2-12	339904				

# **INDEX**

1001802	47	1003587	03	100501687	3005603	37
1002679		1003590		100501787		37
1002769		1003591		100501887		63
1002785		1003591		100681251		63
1002800		1003592		116686133		83
1002885		1003593		12309663		51
1002886		1003594		132647 79		53
		1003595		16247965		87
1002889		1003596		162716.2 87		75
	_					
1002895		1003598		162723 43		75
1002896		1003599		163302 127		89
1002927		1003600		163306 133		77
1002940		1003601		2721505 43		79
1002952		1003602		2721806 79		89
1002953		1003603		2809628 87		87
1003001		1003604		2809630 87		87
1003011		1003605		2810030 127, 129, 133		43
1003100		1003606		2810069 127, 129, 133		43
1003145	_	1003607		2810188 99		60
1003244		1003608		2810189 131		83
1003245		1003611		2810190131		83
1003247		1003679		2810191 131		43
1003248		1003794		2810192 135		77
1003272		1003823	89	2810193 135		79
1003274		1003824		2810194 135	3006644	35
1003275		1003825	51	2810195 127	3006658	80
1003277	85, 89	1003838	53	2810269 43	3006663	37
1003307	97	1003860	99	2810492 65	3006664	37
1003308	97	1003861	99	2810633 67	3006723	37
1003309	97	1003862	99	2810634 67	3006724	37
1003310	97	1003864	101	2810702 79	3006727	87
1003311	97	1003865	101	2811020 43	3006737	47
1003312	97	1003875	105	2811547 63	3006814	55, 57
1003313	97	1003876		2812396 33	3006815	55, 57
1003321	125, 133	1003878		2822524 41		75, 81
1003325		1003891		3000435 33		75, 81, 99
1003423.2	,	1003900		300130741, 43		77
1003424		1003902		3001435 33		39
1003425		1003942		300204275		49
1003429		1003988		300239777		49
1003430		1004023		3002502123		49
1003483		1004024		300269549		80
1003484		1004028		300310160		37
1003556		1004020		300347549		67
1003557		1004172		3003714125, 129, 133		39
1003558		1004275		3003928 123, 129, 133		94
1003559		1004275		3003939 125, 129, 133		95
1003562		1004276				83
				300409289		
1003573		1004308	,	300411367, 125, 129,		83
1003574		1004309		133,		37
1003575		1004584		3004287 33		37
1003577		1004686		3004385 49		49
1003579		1004691		3004410 83		49
1003580		1004931		3004894136		49
1003583		1004938	,	3005121 43		85
1003584	135	1004992	43	3005157 47	3007368	127

# **INDEX**

3007369 127	3009175 125	33997299, 135	36011160, 137
3007374127	300919353, 83	33997499	36100539
3007376 129	3009197 55, 57	33997963, 83, 105, 109	36107173
300739249, 53, 83, 89	3009203 77	339984 81	36111779
3007442139	3009236 77, 79	339989 75, 90, 91, 97,	361648136
3007468 83	3009266 33	131,135	361723 35, 67, 85, 87,
300767467	3009267 33	33999097	127,133
3007678 125	3009268 33	33999497	36174879
3007679139	3009269 83	33999655, 57	36183347
3007680 83	3009309 87	33999981	36200867
300768360, 97	3009317 123	340026 47	36226375
300770437	3009318 123	340027 47	36246487
300771285	3009319 123	340029 47	36261577, 79
300773165	3009496 99	340055 131	36274381
3007764 127, 129, 133	3009535 89	34006147, 83, 89	36303090, 91
300776799	3009537 65	340062 47	36323397
300777594	3009544 41	34006371	36348575
3007896 87	3009607 51	34006590, 99	363514131
3007897 87	3009793 35	340069 101	363539136
300791955, 57	3009860 71	340070 71, 81, 90, 91,	363562133
300792055, 57	300997979	131,135	363568133
300801537	3009980 77	340074 97	36357287
300821977	301001339	34007555, 57	363574133
300834251	301001467	340077 81	36370433
300834351	3010015 83	340078 89	36374687
300834451	3010035 55	340095 131, 135	363746.287
300835790	3010074 139	34011899	36376660
300837487	3010075 139	34014399, 103	36399433
3008388 127, 129, 133	301008247	34014499	36399533
300845385	3010199120	34014797	36401641, 43
3008459103	301030549, 51	340167 103	36415451
300846161	301034661	340214 131	36483083
3008471139	3010651 63	34021599	36494590
300847285	301078939	340217 101	36546691
3008478139	3010811 87	34021997	365566100
300852133	301081287	340239 105	36566099
300854853	3010825 87	340269 81	365772136
300855467	304569 87	340377 101	36582685
300856167	319755 85	34048179	36594343
300856267	323943 73	34079535	36595633
300856367	32611294	34203383	366114100
300867399	32679965	342675 139	36613347
3008792100	332351 87	34629487	36628343
3008793100	333542 49	34680285	366424100
300880877	339237 33	346883 137	366473129
300882079, 90, 95	339897 120, 121	35080087	36652665, 79
300882173	339899 92, 93, 99	351122 117	366593136
3008840125	339904 77	35149167	366609123
300887453	339909 99, 103, 105	35243585	366613129
300888565	339910 99	35260437	36667041
300890751	339911 99	35293685, 127	36675143
300902649, 89	339960 131	35408153, 85, 89	36682263
300907333	339961 99, 103, 105	35879467	36697449
3009075 67	339963 92, 93, 101	35961594, 95	36697887
3009162 87	339965 97	359860 135	36755971
3009163 87	339966 99	36005333	36763147
000910007	333300 39	30003333	30703147

# **INDEX**

4108140	61	E004602	117	5003518	F0	E02024	109
4116910		5001603 5001612		5003518			109
4122243		5001613		5003519			109
4122244		5001614		5003521			109
4124692		5001615		5003522			53
4124759		5001616		5003523			53
4125771		5001617		5003524			117
41318705		5002110		5003526			117
4132013		5002693	_	5003527			117
4132016		5002911		5003528			117
4133043		5002912		5003529			117
4133044	_	5002913		5003530			117
4133224		5002918		5003531			137
4133240	71	5002919	63	5003538	47	551105	109
4133241	71	5002952	33	5003539	47	551651	67
4133242	71	5003034	81	5003540	59	552824	127
4133243	71	5003091	43	5003541	59	554390	112
4134448	73	5003163	75	5003542	59, 113	554748	65, 79
4134530120	, 121	5003164	75	5003543	59, 113	554752	79
4134532		5003165	81	5003544	81	554854	109
4135233		5003166		5003548	109	554855	109
4135240		5003186		5003554			109
4135253		5003187		5003562	_		109
4135259		5003188		5003566			43
4135260		5003189		5003578	_		65
4135261		5003190		5003579			55, 57
4135262		5003196		5003582			55, 57, 67
4135408		5003190		5003583			114
4135409		5003197		5003590			114
4135425		5003198		5003590			114
4135556		5003199		5003591			114
		5003201					114
41355829				5003625			
4135761		5003202		5003626			114
4135918	-	5003219		5003627			114
4136120		5003278		5003628			114
4136131		5003281	_	5003629			114
4136227		5003342		5003630			114
4136285		5003344		5003631			114
4136286		5003346		5003632			114
4136298		5003348		5003633			114
4136341		5003350		5003634			114
4136342		5003353		5003635			114
4136343		5003371		5003636			109
4136563	61	5003413		5003637			109
4136646	71	5003414	118	5003641			33
4136647	71	5003415	118	5003642	97	558004	117
4137099	71	5003419	60	5003643	97	558005	117
4137100	71	5003420	60	5003651	97	558007	117
4137101	71	5003421	97	5003662	115	558008	117
4137295	33	5003422	97	5003690	112	558010	117
4137611	71	5003427	115	5003691	55, 57	558011	117
4137616	73	5003428	115	5003763 12	,	558063	114
4137894	71	5003432	81	5003769			114
5000318		5003433		500736			114
5001182		5003457		500745			
5001599		5003515		500750			

### **World Class Quality, Performance And Support**

Equipment from Jacobsen is built to exacting standards ensured by ISO 9001 and ISO 14001 registration at all of our manufacturing locations.

A worldwide dealer network and factory trained technicians backed by Textron Parts Xpress provide reliable, high-quality product support.



